

GEA Hilge

HYGIANA I / II / III Bloc

Installation and operating instructions English

Translation of the original operating manual

BA.001.BYY.001.01.10.GB

Declaration of conformity

Declaration of conformity as per EC Directive 2006/42/EC, Appendix II A

The declaration refers to complete pump units (with and without motor).

We,

HILGE GmbH & Co. KG
Hilgestraße 37-47
D-55294 Bodenheim

hereby declare that the complete machine

- Type: HYGIANA
- Design: Bloc, Bloc-SUPER, Bloc-V

is in compliance with the following requirements:

- Directive 2006/42/EC
(Machine Directive, Appendix II A)
- Directive 2004/108/EC
(EMC Directive)

Harmonised standards employed:

- DIN EN ISO 12100-1, Safety of machines; basic terms, general principles of design – Part 1: Basic terminology
- DIN EN ISO 12100-2, Safety of machines; basic terms, general principles of design – Part 2: Basic technical principles
- EN 809 / A1, Pumps and pump units for liquids
- DIN EN 60204-1, Safety of machines – electrical equipment of machines

The signatory is authorised to compile the documentation.

Bodenheim, January 1, 2010



Dr. Boris Kneip, Director of Design

1. Introduction	5
1.1 Target group	5
1.2 Symbols and formatting	5
1.3 References to the document	5
2. Safety	6
2.1 Instructions for the operator	6
2.1.1 General information	6
2.2 Safety instructions in the operating manual	6
2.3 Identification of instructions in the operating manual	7
2.3.1 Structure of safety instructions	7
2.4 Qualifications and training of personnel	8
2.5 Hazards upon failure to follow the safety instructions	8
2.6 Safety-conscious work	8
2.7 Safety instructions for the operator / user	9
2.8 Unauthorized modifications and production of spare parts	9
2.9 Improper operation	9
2.10 Transport	10
2.11 Cleaning	10
2.12 Repair contract	11
3. Product description	12
3.1 Pump Overview	12
3.2 Description	12
3.2.1 Areas of application	12
3.3 Proper usage	13
3.3.1 Pumped liquids	13
3.3.2 Minimum flow rate Q_{\min}	13
3.3.3 Connections and pipelines	13
3.3.4 Motor activation	13
3.3.5 Design	13
3.4 Technical data	13
3.4.1 Pump denomination	14
3.4.2 Pump serial number	14
3.4.3 Nameplate	14
3.4.4 Performance data	14
3.4.5 Weights	15
3.4.6 Noise emissions	16
3.4.7 Maximum operating temperature	17
3.4.8 Maximum operating pressure	18
4. Mounting, installation and connection	19
4.1 Inspection before pump installation	19
4.1.1 Check failure-free running of the impeller	19
4.2 Set-up and alignment of the pump assembly	20
4.2.1 Space requirements	21
4.2.2 Reduction of noise and vibration	21
4.3 Installation in the pipeline	22
4.4 Connections for flushing system	24
4.4.1 Double mechanical seal	24
4.4.2 Double mechanical seal - back-to-back-arrangement	25
4.4.3 Double mechanical seal - tandem arrangement	25
4.5 Electrical connections	26
4.5.1 Star connection	26
4.5.2 Delta connection	26
4.5.3 Checking the direction of rotation after connection	27

5. Start-up / shut-down _____ 28

5.1 Start-up _____	28
5.1.1 Check application conditions _____	28
5.1.2 Starting up the pump _____	28
5.1.3 Functional check of mechanical seal _____	29
5.2 Shut-down _____	29
5.2.1 Shutting down the pump _____	29
5.2.2 Cleaning the pump after shut-down _____	29

6. Maintenance / servicing _____ 30

6.1 Safety instructions for maintenance, inspection and installation work _____	30
6.2 Maintenance of the pump _____	31
6.3 Maintenance of the motor _____	31
6.4 Assembly _____	32
6.4.1 Parts overview _____	32
6.4.2 Instructions for assembly _____	34
6.4.3 Assembly of Bloc lantern _____	35
6.4.4 Mechanical seal arrangements _____	35
6.4.5 Assembly of the single mechanical seal _____	36
6.4.6 Assembly of impellers and casings _____	37
6.5 Troubleshooting _____	41
6.6 Disposal _____	42
6.7 HILGE assembly tool kit _____	43
6.7.1 Content and use _____	43

7. Certificate of non-objection _____ 44

7.1 Certificate of non-objection _____	44
--	----

1. Introduction

Overview

This section describes the requirements which are important for reading and understanding this manual. You will learn the symbols and formats that make the reading easier.

1.1 Target group

This operating manual is intended for:

- the operators of the pump and
- maintenance and repair personnel.

It is assumed that all such personnel will have the basic technical background required for the start-up, maintenance, and repair of pump systems.

Sections aimed only for specially authorised personnel are indicated by a preceding notation to this effect.

1.2 Symbols and formatting

The following symbols and formats are intended to make it easier to read this document:

- Listed items

Instructions

Instructions that must be carried out in a specific sequence are numbered in the corresponding order.



Important information and helpful tips are identified with the index finger symbol.

Safety instructions

The system used to identify safety instructions is described in section 2.3.

1.3 References to the document

Copyright

This document may not be copied, translated into other languages, or made available to third parties without our explicit written approval.

Technical changes

Design variants, technical data, and spare part numbers are subject to technical change.

The right to make changes for the sake of further technical development is reserved.

2. Safety

Overview

This section describes what you have to consider for your own safety. You will learn the structure and identification of safety instructions. Read this important section attentively!

2.1 Instructions for the operator

2.1.1 General information

All our pumps are professionally packed before they leave our warehouse to avoid damage during transport.

Unpacking

If, after carefully unpacking and inspecting the shipment, you however find damage, you must promptly inform the shipping agent (railway, post office, lorry driver, shipping line, etc.).

Your claim should be filed with the shipping agent. The shipping risk passes to the customer as soon as the shipment leaves our warehouse.

Storage

If the pump is not put into service immediately, it is important that it is stored properly to ensure that it will function correctly later. This is just as important as proper installation and maintenance.

The pump must be protected from cold, moisture, and dust as well as from mechanical influences.

Specially trained personnel is required to install and maintain the pump properly.

2.2 Safety instructions in the operating manual

Read safety instructions!

The operating manual contains all the basic information required for the set-up, operation, and maintenance of the pump. The installer as well as the technical personnel or operator responsible for the pump must therefore read this manual before installing and starting the pump. The operating manual must always be available at the site where the machine/system is being used. Not only the general safety instructions presented in this section but also the specific safety instructions in later sections must be followed.

2.3 Identification of instructions in the operating manual

Symbol The safety instructions presented in this operating manual are identified as shown below.




Fig. 1 Symbol for safety instructions

K.0319V1 | K.0320V1

- A: Failure to follow these safety instructions can endanger personnel.
- B: Safety instructions which involve warnings against electrical voltage.
- C: Failure to follow these safety instructions can endanger the machine and its operation.

Signal words In order to classify the safety labels they are distinguished by the following signal words:

- **Danger**
Characterises an imminent hazard with a high risk which can cause death or grievous bodily harm.
- **Warning**
Characterises a possible hazard with medium risk which can cause death or bodily harm if it is not avoided.
- **Caution**
Characterises a hazard with minor risk which can causes minor or medium bodily harm if it is not avoided.

Don't remove instructions from machine Instructions attached directly to the machine, such as rotational direction arrow must be noted and kept in completely legible condition.

Damaged or illegible instructions must be replaced.

2.3.1 Structure of safety instructions

WARNING	Description of danger!
	<p>▲ Possible consequence.</p> <p>▷ Action to eliminate the danger.</p>
Example:	
DANGER	Electrical shock if electrical parts are touched!
	<p>▲ Death, serious bodily injury, damage to property.</p> <p>▷ Before attempting to diagnose any fault, make sure that the main switch has been switched off. It must be ensured that the electricity supply cannot be accidentally switched on.</p>

2.4 Qualifications and training of personnel

The employees operating, maintaining, inspecting, and installing the pump must have the appropriate qualifications for this work. The operator must define in detail the tasks for which the employees are responsible, the tasks of which they are in charge, and the manner in which they are supervised.

If the employees do not have the necessary knowledge, they must be instructed and trained accordingly. This can be done, if necessary, by the manufacturer/supplier under contract to the operator. The operator must also guarantee that the employees fully understand the contents of the operating manual.

2.5 Hazards upon failure to follow the safety instructions

If these safety instructions are not followed employees, the machine itself and the environment will be in danger.

Failure to follow the safety instructions can lead to the loss of the right to file claims for damages.

Failure to follow instructions can, for example, lead in particular to the following hazards:






- Breakdown of important functions of the machine/system
- Failure of recommended methods of maintenance and repair
- Endangerment of personnel by electrical, mechanical, and chemical hazards
- Endangerment of the environment by leakage of hazardous materials.

2.6 Safety-conscious work

The safety instructions given in this operating manual, the existing national regulations for accident prevention, and any applicable internal working, operating, and safety instructions of the operator must be followed.

Safety

2.7 Safety instructions for the operator / user

CAUTION 	Burn hazard from hot or cold mechanical components! ▲ Serious bodily injury. ▷ Take structural measures to prevent contact with them!
WARNING 	Trapping hazard! ▲ Death, serious bodily injury, damage to property. ▷ Do not remove protection against contact with moving parts (e.g. coupling guard) while the machine is operating. ▷ Replace defect safety equipment immediately.
WARNING 	Contact with hazard substances (e. g. inhale)! ▲ Death, serious bodily injury, damage to property. ▷ Drain away leakage of hazardous pumping media in such a way that there is no danger to personnel or to the environment. ▷ Follow legal regulations. ▷ If shaft seal fails switch off the pump. Replace seal before next start-up.
WARNING 	Tripping hazard from electric power cable! ▲ Death, serious bodily injury. ▷ Route the electric power cable in such a way that no one can trip over it (in case of portable pumps).
WARNING 	Electrical hazard due to unsuitable equipment! ▲ Death, serious bodily injury. ▷ Only use acceptable electric cables and plugs.

2.8 Unauthorized modifications and production of spare parts

No modifications or changes to the machine may be made without written approval of the manufacturer. In the interest of safety, only original spare parts and accessories authorized by the manufacturer may be used. The use of other parts can exempt the manufacturer from liability for damage which may thus be caused.

2.9 Improper operation

The operational reliability of the delivered machine can be guaranteed only when it is used properly as indicated in the following sections.



The given limit values may not be exceeded under any circumstances.

2.10 Transport

WARNING



Falling loads!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Transport work must only be performed by persons qualified to do so, and all safety instructions must be observed.
- ▷ Use suitable load carrying equipment with sufficient capacity to transport the pump.
- ▷ Make certain there are no persons under the suspended load.
- ▷ Make certain the pump is aligned horizontally when it is lifted.

ATTENTION

Incorrect lifting points!

- ▲ Damage to property.
- ▷ Fasten the rope to suitable lifting points.
- ▷ Never fasten a rope to the pump casing or intake/discharge branch.
- ▷ In case of SUPER design¹: Remove shroud before transporting.

2.11 Cleaning

CIP and SIP methods must be in accordance with the latest current guidelines of the EC.

When special cleaning agents and methods are used, the supplier must confirm that they are safe for the materials involved.

WARNING



Pressure surge!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Before sterilisation always evacuate the system completely!

1. Option.

Safety

2.12 Repair contract

The duty to follow the legal regulations on work safety and the regulations on environmental protection means that all commercial enterprises must protect their employees, the public at large, and the environment from the harmful effects of hazardous materials. Examples of legal regulations on work safety:

- the Workplace Act (ArbStättV)
- the Hazardous Materials Act (GefStoffV)
- the accident prevention regulations (BGV A1)
- and all applicable laws, rules, guidelines, regulations etc. in the country of operation.

Examples of regulations on environmental protection:

- the Recycling and Waste Law (KrW/AbfG)
- the Water Economy Law (WHG)
- and all applicable laws, rules, guidelines, regulations etc. in the country of operation.

Certificate of non-objection

The certificate of non-objection attached to the shipment is a component of the inspection/repair contract. This does not affect our right to refuse acceptance of this contract for other reasons. The certificate of non-objection can be found on page 44.

HILGE products and their parts will only be inspected/repaired if the certificate of non-objection is present and has been correctly completed by authorized and qualified technical personnel. Pumps which have been operated in media exposed to radiation will not be accepted.

If any additional safety measures are required even after the careful draining and cleaning of the pump, the necessary information must be provided.

3. Product description

Overview

This section describes the pump as well as its design and application. Section „Technical Data“ describes limits for application. You must know and keep these limits.

3.1 Pump Overview




Fig. 2 Overview HYGIANA

K.0283V1

0107 - discharge branch
 0153 - suction branch
 0156 - discharge branch
 0180 - foot (motor foot design)
 0340 - lantern
 0802 - close coupled motor
 (Vertical mounting and SUPER design without figure).

3.2 Description

The pump is a multi-stage end-suction centrifugal pump with a modular design. All parts which come in contact with the medium are in accordance with „hygienic design“ guidelines.

3.2.1 Areas of application

Standard design

Pumps of the standard design are used for:

- industrial application
- CIP processes
- all systems and processes involved in the food product, dairy, and beverage industries.

Product description

3.3 Proper usage

WARNING



Improper usage!

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Pump only media that are specified in the order. The pump has been specially designed for that purpose.
 - ▷ Operate the pump only in the electrical network specified in the order.
-

3.3.1 Pumped liquids

Only pure or slightly contaminated liquids with a maximum particle size of 0.4 mm may be pumped. These liquids may not chemically or mechanically attack the pump materials or lower their strength. If liquids with a viscosity greater than that of water are to be pumped, make sure that the motor will not be overloaded. The pump may not be operated beyond the maximum allowable values. Even short periods of pressure overload (e.g., as a result of a pressure surge) should be avoided.

3.3.2 Minimum flow rate Q_{\min}

Do not operate the pump below minimum flow rate of $Q_{\min} = 10 - 15 \% Q_{\text{opt}}$.

3.3.3 Connections and pipelines

The nominal diameters of the system pipelines should be equal to or greater than the nominal diameters of the pump, i.e., DNE (suction side) and DNA (pressure side), and the connecting elements to the pump must conform exactly to the design standard/specification of the mating connector piece installed on the pump. The suction line must be absolutely leak-tight and laid in such a way that no air pockets can form. Avoid tight elbows and do not install valves immediately upstream of the pump. The suction head of the system may not be greater than the suction head guaranteed by the pump.

3.3.4 Motor activation

Do not start and stop the motor more than 15 times per hour.

3.3.5 Design

All information and descriptions in this Operating Manual concerning the use and operation of the pumps are based exclusively on the standard designs.

These rules do not apply to special designs, to customer specific modifications, or to random external influences which may occur during use and operation.

3.4 Technical data

WARNING



Overloading the pump!

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Use the pump only under the indicated operating conditions.
 - ▷ Also avoid short overpressure situation (e.g. caused by pressure surge).
-

3.4.1 Pump denomination

The HILGE pump denomination is structured as shown below:

HYGIANA	I	Bloc	40/40	3	4
pump type					
size					
design					
nominal diameter DN _s / DN _D					
power [kW]					
number of poles					

Tab. 1 HILGE pump denomination (example)

3.4.2 Pump serial number

The pump can be identified by the pump serial number. When ordering spare parts give always the pump serial number.


Pump serial number (example) 001 / 08 / 1248

The pump serial number includes:

- pump type (001, HYGIANA I)
- year of manufacture (08)
- reg. number (1248)

3.4.3 Nameplate

HILGE GmbH & Co. KG
Hilgestraße - D - 55294 Bodenheim



Pump-Type ①

No. ②

Q ③ m3/h H ④

P ⑤ kW n ⑥ min-1

Doc.-No. ⑦

MADE BY HILGE

K.0109V2

Fig. 3 HILGE nameplate, example

- 1 - pump type
 - 2 - pump serial number
 - 3 - capacity Q
 - 4 - head H
 - 5 - motor power P
 - 6 - drive speed n
 - 7 - number of operating manual
- NOTE: The nameplate can deviate from the one shown.

3.4.4 Performance data

The performance data of the pump, namely, its head and delivery rate, are determined in accordance with DIN EN ISO 9906 - appendix A , class 2 and are documented on the acceptance records.

Product description

3.4.5 Weights

Design features of the described standard pumps:

Caution:

The weights can - depending on design and accessories - differ from those presented. The manufacturer gives you when given the pump / order number precise information.

- Motor foot mounting
- Single mechanical seal
- SIEMENS motor

Motor power[kW]	Motor size	Stage	Weight [kg]
1,5	090S	2	25
		3	27
2,2	090L	2	24
		3	27
		4	34
3	100L	2	26
		3	34
		4	36
4	112M	3	48
		4	52
5,5		5	57
		6	58

Tab. 2 Weights HYGIANA I

Motor power[kW]	Motor size	Stage	Weight [kg]
5,5	112M	2	62
		3	70
7,5	132S	2	84
		3	96
11	132M	2	87
		3	105
		4	113
15	160M	3	106
		4	114
		5	130
18,5	160L	5	130

Tab. 3 Weights HYGIANA II

Motor power[kW]	Motor size	Stage	Weight [kg]
18,5	160L	2	240
		3	270
22	180M	2	245
		3	280
30	200L	2	250
		3	290
		4	340

Tab. 4 Weights HYGIANA III

3.4.6 Noise emissions

Measurements in accordance with DIN EN ISO 3746 for pump units, uncertainty 3dB (A).

	Motor power kW	L _{pfa} [dB (A)]	Poles
HYGIANA	1,5	67	2
	2,2	67	
	3	73	
	4	73	
	5,5	73	
	7,5	74	
	11	74	
	15	75	
	18,5	76	
	22	76	
	30	77	
	37	77	

Tab. 5 Noise emissions

Noise caused by a pump will be significantly influenced by their application. The values given here therefore provide as a guide only. Refer to the manufacturer for details.

Product description

3.4.7 Maximum operating temperature

WARNING



Exceeding the max. permitted operating temperature!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Never exceed the specified operating temperatures.


Design	Temp. [° C]
Standard design	95
Special design	150
Sterilization (SIP)	140

Tab. 6 Operating temperatures

Variations of those mentioned temperatures are possible.
See order papers for applicable values.

3.4.8 Maximum operating pressure

WARNING



Pressure overload!

▲ Death, serious bodily injury, damage to property.

▷ The pump must be operated according to the order pdata.

▷ Never exceed the specified maximum operating pressures.

Pump operating pressure

The maximum permitted operating pressure depends on various factors:

- pump type
- design of connections
- design of mechanical seal.

For the values that apply to your pump, please refer to the order documents.

4. Mounting, installation and connection

Overview

This chapter is intended for the maintenance and repair personnel.

This section describes how to mount, adjust and install the pump. You get to know what to consider when you connect the pump to the electric mains supply and how to improve the flow in order to avoid dry running of the shaft seals.

4.1 Inspection before pump installation

4.1.1 Check failure-free running of the impeller

Check the failure-free impeller running in this way:

1. Remove motor shroud¹.
2. Remove fan cover of motor.
3. Consider direction of rotation (arrow).
4. Rotate shaft slowly by hand via the fan.

The shaft must rotate easily. If the impeller rubs against the pump casing (for example due to transport damage) it has been damaged .

When the impeller rubs against the casing: Contact HILGE Service.

When the impeller runs failure free:

5. Re-fit fan cover of the motor.
6. Re-fit motor shroud¹.

1. SUPER design only

4.2 Set-up and alignment of the pump assembly

WARNING**Misalignment of the pump due to an improper foundation!**

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Ensure that the foundation on which the pump is set up is clean and flat and has sufficient load capacity.
 - ▷ Mount the pump – especially when it is to be set up vertically¹ – with the use of suitable heavy-duty anchors. As the centre of gravity is higher, the pump can tip.
 - ▷ The mounting points provided must be bolted to the foundation according to the standard rules of mechanical engineering to ensure the satisfactory set-up of the pump.
-

WARNING**Short circuit!**

- ▲ Death, serious bodily injury, damage to property.
 - ▷ In case of a vertical installation: Under no circumstances the motor should be positioned underneath the pump. If there is leakage the motor could be damaged.
-

Align the pump in this way:

1. Use an engineer's spirit level laid across the machined surface of the discharge branch connection to align the assembly.
2. After aligning the assembly, tighten the mounting bolts uniformly in a crosswise manner.

1. Not applicable for F&B-HYGIA®, SIPLA, NOVALobe and for all base plate design (CN).

Mounting, installation and connection

4.2.1 Space requirements

ATTENTION

Overheating!

- ▲ Damage to property.
- ▷ Ensure sufficient ventilation.
- ▷ Make sure not to reabsorb warm cooling air. Consider other heat sources in the area.
- ▷ Keep minimum distances.

Pay attention to motor power. Keep the minimum distances.




Fig. 4 Minimum distances

K.0317V1

4.2.2 Reduction of noise and vibration

Noise and vibration are generated by the pulsating flow of the rotors and by the flow in pipes and fittings. The effect on the environment is subjective and depends on correct installation and the state of the remaining system. One way of reducing noise and vibrations is by installing expansion joints.




Fig. 5 Expansion

K.0346V1

- A - Expansion joints
- B - Foundation
- C - vibration absorber

Function of expansion joints:

- Absorbability of expansions/contractions in the pipework caused by changing the temperature of the pumped medium.

Mounting, installation and connection

- Reduction of mechanical strains in connection with pressure surges in the pipework.
- Insulation of mechanical structure-borne noise in the pipework (only rubber bellows expansion joints).



Do not install expansion joints to compensate for inaccuracies in the pipework such as centre displacement of flanges. Fit expansion joints at a distance of minimum 1 to 1½ times the nominal flange diameter away from the pump on the suction as well as on the discharge side. This will prevent the development of turbulence in the expansion joints, resulting in better suction conditions and a minimum pressure loss on the pressure side. At high viscosity or velocities, we recommend you to install larger expansion joints corresponding to the pipework.

4.3 Installation in the pipeline

WARNING



Mechanical overload!

- ▲ Death, bodily injury or damage to property.
- ▷ Do not use the pump or its connecting sleeves to support the pipeline (EN 809 5.2.1.2.3 and EN ISO 14847).
- ▷ In addition to the general rules of machine-building and plant construction, also follow the instructions provided by the manufacturer of the connecting elements used (e.g., flanges) when installing the pump in the pipeline or plant. These specifications will contain data on torques, maximum allowable angular offset and tools / auxiliary materials to be used.
- ▷ After connecting the pipes, check the alignment of the coupling.
- ▷ It is absolutely necessary to avoid twisting the pump.

ATTENTION

Mechanical overload due to foreign objects!

- ▲ Damage to property.
- ▷ The suction and delivery ports are sealed with sheets of plastic, the flushing and drain lines with plastic caps. These must be removed before the pump is installed in the system.

Details about dry running

What is dry running?

To seal the pump shaft against the pump casing the mechanical seal needs lubrication between its rotating faces.

This lubrication is provided by the pumped liquid. If the pump is fitted with a quench the lubrication for the quench must be provided from an external source.

Dry running occurs when the lubrication fails. Dry running destroys the mechanical seal in few seconds.

Mounting, installation and connection




Fig. 6 Lubrication between slide surfaces

K.0075V2

P - pump side
0433.00 - mechanical seal
L - lubrication
A - atmosphere side

CAUTION



Dry running!

▲ Damage to property.

- ▷ The suction line must be absolutely leak proof and laid in such a way that no air pockets can form.
- ▷ Avoid tight elbows and valves immediately upstream of the pump. They interfere with the incoming flow to the pump and thus with the NPSH of the system.
- ▷ The head of the system may not be greater than the head guaranteed by the pump.
- ▷ The head of the system may not be greater than the head guaranteed by the pump.
- ▷ The nominal pipeline diameters of the system should be equal to or greater than the DNS or DND connectors of the pump.
- ▷ A foot valve should be used in suction mode.
- ▷ To prevent air pockets from forming, the suction line must be laid so that it rises to the pump; a gravity feed line must be laid with a slight downward gradient to the pump.
- ▷ If local conditions do not allow the suction line to ascend continuously, install a venting device at the highest point of the line.
- ▷ A shut off valve should be installed in the suction line near the pump. This valve must be completely open during operation and may never be used as a control valve.
- ▷ A shut off valve should be installed in the discharge line, near the pump, to control the delivery rate.




Fig. 7 Installation in the pipeline

K.0076V2

above: gravity feed mode
below: suction mode
P - pump | M - motor


4.4 Connections for flushing system

4.4.1 Double mechanical seal

HILGE pumps with double mechanical seal are equipped with a seal cartridge.

Depending on the seal design the barrier or flushing fluid flows inside this seal cartridge.

The connection must be carry out as shown in Fig. 8. So you can ensure that the fluid can flush the mechanical seal effectively.



K.0298V1

Fig. 8 Flushing connection

- A - feed line
- B - outlet line
- N - direction of rotation (pump)

CAUTION



Dry running!

- ▲ Damage to property.
- ▷ Connect the lines of the flushing system in that way that a liquid supply is guaranteed.
- ▷ Always keep the fill level in the liquid pot between the upper and lower marks.

Connect the flush in this way:

1. Connect feed line A
Note the dependence between arrangement and rotating direction N. See Fig. 8
2. Connect outlet line B
3. Check tightness of connection.

Mounting, installation and connection

4.4.2 Double mechanical seal - back-to-back-arrangement

Barrier liquid

In order to continue functioning, the mechanical seals require a barrier liquid, some of its purposes being:

- Pressurisation in the sealing space
- Prevent the feed liquid from penetrating into the sealing gap
- Dry-run protection
- Lubrication and cooling of the mechanical seals.

A pure liquid, compatible with the pumped liquid, serves as a sealing liquid.

Ensure the functioning in this way:

1. Open feed line of barrier liquid
2. Bleed seal cartridge
3. Ensure liquid is circulating at required barrier pressure.

The barrier pressure should be at least 1.5-2 bar above the highest pressure to be sealed. The sealing liquid should not be above 60°C on exit and should on no account exceed the boiling point.

4.4.3 Double mechanical seal - tandem arrangement

Flushing liquid

In order to continue functioning, the mechanical seals require a flushing liquid, some of its purposes being:

- Preventing leaks
- Dry-run protection
- Lubrication and cooling of the mechanical seals
- cutting off the air from substances which react unfavourably with oxygen.

A pure liquid, compatible with the pumped liquid, serves as a flushing liquid.

Ensure the functioning in this way:

1. Open feed line for flushing liquid
2. Bleed seal cartridge
3. Ensure unpressurised circulation.

A pure liquid, compatible with the pumped liquid, serves as a flushing liquid.

In case of abrasive media provide a „lost“ flushing, i.e. where the flushing liquid is discharged directly.

4.5 Electrical connections

WARNING



Electric shock!

- ▲ Death, serious bodily injury.
- ▷ The electrical connections must be made by a qualified electrician.
- ▷ VDE specifications and any local regulations must be followed, especially those pertaining to safety measures.

WARNING



Capacity overload!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Check the voltage stated on the rating plate of the motor against the operating voltage!
- ▷ Install an electrical circuit breaker.

4.5.1 Star connection

Star-connection 3-phase system for high voltage.

Connect the pump as specified in the order documents. The figure below shows the scheme for star connection.




Fig. 9 Star connection

K.0079V1

4.5.2 Delta connection

Delta-connection for low voltage.

Connect the pump as specified in the order documents. The figure below shows the scheme for delta-connection.




Fig. 10 Delta connection

K.0080V1

Mounting, installation and connection

4.5.3 Checking the direction of rotation after connection

ATTENTION

Dry running of the mechanical seal!

▲ Damage to property.

▷ Before checking of the direction of rotation: Fill and vent the pump.

▷ Connect the motor and briefly (for about 2 seconds) check the direction of rotation.

Note the directional arrow (red) on the pump. If the pump is turning in the wrong direction the mechanical seal can be destroyed.

Check the rotating direction in this way:

1. After electrical connection: Mount all safety equipment again.
2. Check tightness of hydraulic connection.
3. Fill pump (plant).
4. Observe arrow of rotation.
5. Switch on motor short-time (1-2 seconds).
6. Compare directions (motor / arrow).
7. Correct connection if need be.

Operation with frequency inverter

See documentation of manufacturer.

5. Start-up / shut-down

Overview

This section describes how to start up and shut down the pump. You get to know which inspections contribute to failure-free operation and increased life of the pump.

5.1 Start-up

5.1.1 Check application conditions

Check the application conditions of the pump in this way:

1. Compare the data of the following documents with the provided application condition of the pump:
 - purchasing documents (confirmation of the order)
 - nameplate
 - operating manual.
2. Make sure that the pump will operate under the mentioned conditions only. This conditions apply to (e. g.) pressure, temperature, liquid pumped.

5.1.2 Starting up the pump

Start up the pump in this way:

1. Check tightness of connection.
2. Make sure that all safety equipment is installed.
3. Make sure that all electrical connections are correct.
4. Open the check valves in the system.
5. Fill the pump together with the system.
6. Vent the pump and system.
7. Fully open the check valve on the suction side.
8. Close the check valve on the discharge side.
9. Start the pump.
10. Slowly open the check valve on discharge side.

WARNING



Overheating and pressure overloading!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Never operate the pump against a closed shut-off device. Operation with a shut-off device must on no account continue for longer than 30 seconds.

If delivery head does not rise after the pump has been turned on:

1. Switch off the pump.
2. Vent the pump (system) again.
3. Repeat steps 7 to 10.

Start-up / shut-down

5.1.3 Functional check of mechanical seal

Check the function of the mechanical seal in this way:

1. Watch the pump and check the mechanical seal for flawless functioning (leak test).
An intact mechanical seal works virtually without leakage.

If liquid pumped or flushing liquid leak:

1. Switch off the pump.
2. Renew the mechanical seal.
Observe section 6.1

5.2 Shut-down

5.2.1 Shutting down the pump

WARNING



Pressure surge!

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Always close shut-off devices (gates, valves) slowly!
-

What is a pressure surge?

A pressure surge is an abruptly pressure increasing in the system. This pressure increasing can - among other causes - be caused by a quick blocking of the flow in the discharge pipe. In case of a pressure surge, the maximum permitted pump pressure is temporarily exceeded manyfold.

Shut down the pump in this way:

1. Close the check valve on the discharge side.
2. Switch off the pump.
3. Close the check valve on the suction side.
4. Switch off the flushing system¹.
5. Make sure that the pump is depressurised.
6. Switch off pressure in barrier system².

5.2.2 Cleaning the pump after shut-down

ATTENTION

Jamming of the pump!

- ▲ Damage to property.
 - ▷ Clean the pump appropriately after shut down.
-

See section 2.11.

1. only for double mechanical seal or quench design
2. only for back-to-back arrangement

6. Maintenance / servicing

Overview

This chapter is intended for the maintenance and repair personnel.

This section gives important information concerning maintenance and servicing of the pump. Read this section before you carry out maintenance work or troubleshooting measures!

6.1 Safety instructions for maintenance, inspection and installation work

WARNING



Unprofessional work!

- ▲ Death, serious bodily injury, damage to property.
- ▷ The operator must ensure that all maintenance, inspection, and installation work is carried out by authorised and qualified technical personnel, who have acquired the required knowledge through study of the operating instructions.

DANGER



Electrical shock if electrical parts are touched!

- ▲ Death, bodily harm.
- ▷ Always turn off the electrical supply at the pump before eliminating any breakdown.

WARNING



Pressurized spray!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Depressurize the pump before eliminating any breakdown.

CAUTION



Hot components!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Always allow to cool down before eliminating any breakdown.

WARNING



Unintentioned switching on the pump!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Take appropriate measures to ensure that the machine cannot be unintentionally turned on again.

WARNING



Contact with hazardous substances (e. g. inhale)!

- ▲ Death, serious bodily injury, damage to property.
- ▷ Pumps or systems which convey hazardous media must be decontaminated.

WARNING**Missing protection and safety equipment!**

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Immediately after completing the work install the protection and safety equipment and make sure it functions.
-

ATTENTION**Improper tools for the pump assembly!**

- ▲ Damage to property.
 - ▷ In accordance with the design standard (3A0.01 to 3A3.37), all tools, possible support surfaces, and other auxiliary materials must ensure that all parts of the pump can be assembled without damage (e.g. scratches). See section 6.7.
-

ATTENTION**Frost!**

- ▲ Damage to property.
 - ▷ When there is danger of frost drain the pump completely.
-

6.2 Maintenance of the pump

The pump is a low-maintenance pump. In addition to cleaning, the only point to be kept in mind is the wear to the rotating mechanical seal.

6.3 Maintenance of the motor

See operating manual of the motor manufacturer.

6.4 Assembly

6.4.1 Parts overview




Fig. 11 Parts overview

K.0292V1

Maintenance / servicing

Qty.	Part No.	Description
1	0107.00	discharge casing
1	0112.02	diffusor casing ^a
1	0112.03	diffusor casing
1	0162.00	suction cover
1	0230.01	impeller
1	0230.02	impeller
1	0230.03	impeller
1	0340.00	lantern
1	0346.00	intermediate lantern ^d
1	0412.01	O-ring ^e
1	0412.11	O-ring
1	0412.12	O-ring
1	0412.13	O-ring
1	0433.00	mechanical seal
1	0433.01	mechanical seal
1	0471.00	seal cover
1	0507.00	deflector
1	0513.01	insert ring
1	0513.02	insert ring
1	0513.03	insert ring
1	0515.01	clamp ring
1	0516.00	locating ring
4	0554.02	washer

Qty.	Part No.	Description
4	0554.31	washer
4	0560.00	pin
1	0677.00	extension
1	0680.00	shroud (0686.01 guard) ^b
1	0802.00	close coupled motor
1	0891.00	open baseplate ^c
4	0901.02	hexagon head screw
4	0902.06	stud
2	0904.02	grub screw
4	0905.01	tie bolt
4	0914.09	socket head cap screw
4	0920.09	hexagon nut
4	0920.12	hexagon nut
8	0920.22	hexagon nut
4	0920.32	hexagon nut ^f
1	0922.00	impeller nut
4	0934.02	spring washer
4	0934.03	spring washer
4	0934.06	spring washer
1	0940.00	key
1	0970.00	nameplate
1	0970.01	sense of rotation arrow
4	1000.02	phillips screw

Table 7 Partslist HYGIANA Bloc-SUPER

- a. Parts which are depending on number of stages are partially without figure.
- b. Applies not to SUPER design.
- c. Foot design and fixing elements can vary.
- d. Option, without figure.
- e. Parts which are depending on double mechanical seal design are shown from page XX.
- f. HYGIANA III only

6.4.2 Instructions for assembly

DANGER



Disregarding of important instructions!

- ▲ Death, serious bodily injury, damage to property.
 - ▷ Before you maintain or assemble the pump note section 6.1.
-

ATTENTION

Important aspects!

- ▲ Damage to property.
 - ▷ Use tools from HILGE assembly tool kit in order to assemble the pump without damages and scratches.
 - ▷ To guarantee a good seal, use only O-ring seals with the original dimensions.
 - ▷ Never use grease which contains mineral oil when assembling the wet end parts¹.
 - ▷ Replace mechanical seals always in complete assembly.
 - ▷ As the impeller nut is being fitted, it must be possible to feel the self-locking action². It must be possible to tighten the nut without any problems. Tighten manually for the first two turns, so that the thread insert sits correctly on the shaft.
 - ▷ To tighten impeller nut 0922.00, use either a screw device or the impeller nut installing device because the torque applied to tighten must be absolutely concentric. Otherwise there is the danger that the pump shaft 0211.00 will be bent.
-

1. Parts which come in contact with the pumped medium.
2. Only apply to impeller nut with Helicoil thread insert.

6.4.3 Assembly of Bloc lantern

Assemble the bloc lantern and the motor in this way:

1. Join motor 0802.00 and bloc lantern 0340.00.
Use studs 0902.06, spring washers 0934.06 and
hexagon nuts 0920.09.^a
Torques: M10 - 37 Nm | M12 - 65 Nm |
M16 - 150Nm



Fig. 12 Motor

MF-649

2. Push deflector 0507.00 onto the shaft 0211.00.




Fig. 13 Deflector

MF-421

3. Grease the seat of the component which adjoins
the backplate 0161.00.
Use Klüberpaste UH1 96-402 from HILGE as-
sembly tool kit for this (pos. 6, fig. XX)



Fig. 14 Contact surface lantern

MF-420

- a. Fixing elements can vary.

6.4.4 Mechanical seal arrangements

Following mechanical seal arrangements are available:




Fig. 15 Single mechanical seal

K.0294V1

- A - pump side
 - B - atmosphere side

Figure / parts can differ insignificantly.




Fig. 16 Double mechanical seal, tandem

K.0293V1

- A - pump side
 - B - atmosphere side

Figure / parts can differ insignificantly.

Mechanical seal type	Fig.	Description on page
Single mechanical seal	15	36
Double mechanical seal, tandem	16	supplemental sheet
Double mechanical seal, back to back	without	supplemental sheet

6.4.5 Assembly of the single mechanical seal

Assemble the single mechanical seal in this way:

1. Coat the thread of the tie bolts 0905.01 with Loctite type 243 (HILGE assembly tool kit, pos. 10, fig. 45).
2. Hand-screw the tie bolts 0905.01 into the Bloc lantern 0340.00.



Fig. 17 Tie bolts

MF-553

3. Grease the back side of the discharge casing 0107.00.
Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this (pos. 6, fig. 45).



Fig. 18 Discharge casing

MF-672

4. Assemble the discharge casing 0107.00 onto the shaft 0211.00.



Fig. 19 Discharge casing

MF-381

5. HYGIANA III: Use hexagon nuts 0920.32 and washers 0554.31 in order to join discharge casing 0107.00 and lantern 0340.00.
Torque: M8 - 19 Nm.




Fig. 20 Discharge casing HYGIANA III

K.0295V1

6. Spray the stationary ring of the mechanical seal 0433.00 and the shaft 0211.00 with clean water. Use spray bottle from HILGE assembly tool kit (pos. 2, fig. 45).



Fig. 21 Stationary ring of the mechanical seal

MF-653

7. Slide the assembly sleeve from HILGE assembly tool kit (pos. 3, fig. 45) onto the shaft extension.



HILGE assembly tools avoid damages of the mechanical seal during the further assembly.




Fig. 22 Assembly sleeve

MF-656

8. Push the stationary ring of the mechanical seal 0433.00 into the seat of the discharge casing 0107.00.
Use installation sleeve from HILGE assembly kit (pos. 12, fig. 45) to do this.



Fig. 23 Stationary ring of the mechanical seal

MF-466

9. Slide the rotating part of the mechanical seal 0433.00 in complete assembly onto the shaft 0211.00 up to the stop.
Use installation sleeve from HILGE assembly kit (pos. 12, fig. 45) to do this.



Fig. 24 Rotary ring of mechanical seal

MF-469

For assembly of the impellers and casings read on at page 37.

6.4.6 Assembly of impellers and casings

ATTENTION

Bending of pump shaft!

▲ Damage to property.

- ▷ To tighten impeller nut 0922.00, use either a screw device or the impeller-fastening-aid which is mentioned below. The torque applied to tighten must be absolutely concentric.

Assemble the impellers and the casings in this way:

1. Insert key 0940.00.



Fig. 25 Key

MF-470

2. Grease the pump shaft 0211.00.
Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this, pos. 6, fig. 45.



Fig. 26 Pump shaft

MF-471



Impeller assembly




Fig. 27 Impeller arrangement

K.0296V1

A - closed impeller type

B - closed impeller type

C - last impeller

HYGIANA I: open or closed impeller with short collar

HYGIANA II: open or closed impeller

HYGIANA III: open impeller

3. Fit the impeller 0230.01.



Fig. 28 Impeller

MF-472

4. Fit insert ring 0513.01 into the discharge casing 0107.00.




Fig. 29 Spring

MF-473

5. Insert the O-ring 0412.11 into the discharge casing 0107.00.



Fig. 30 O-ring

MF-474

6. Insert the diffuser casing 0112.02.




Fig. 31 Diffuser casing

MF-475

To mount the following pump stages follow steps 3. to 6.

Take the different part numbers of impellers, diffuser casings and O-rings into account.

This manual describes the procedure to mount the **impeller nut with lock washers**.

If the pump is equipped with an **impeller nut with a threaded insert** take the following into account:



The pump can be equipped with two different types of impeller nuts:

- impeller nut with threaded insert
- impeller nut with lock washers

- As the impeller nut is being fitted, it must be possible to feel the self-locking action. It must be possible to tighten the nut without any problems. Tighten manually for the first two turns, so that the helicoil insert sits correctly on the shaft.

- Tightening torques:
M10 - 20 Nm (HYGIANA I)
M20 - 150 Nm (HYGIANA II / III)

7. Grease the Nord-Lock washer 0930.00 by using Klüberpaste UH1 96-402 from the HILGE assembly tool kit pos. 6 Fig. 45.




Fig. 32 Nord-lock washer

MF-366

8. Insert the Nord-Lock washer 0930.00 into the impeller nut 0922.00.



Fig. 33 Nord-Lock washer in impeller nut

MF-367

9. If all impellers are mounted, screw on the impeller nut 0922.00 by hand.




Fig. 34 Impeller nut

MF-446

10. Mount the clamp ring 0515.01.




Fig. 35 Clamp ring

MF-447

11. Grease the threads of the tie bolts 0905.00. Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this, pos. 6, fig. 45.



Fig. 36 Clamp ring

MF-448

12. Screw the hexagon nuts 0920.22 and tighten them.
So the joints and O-rings can be set and the impeller nut can be tightened.




Fig. 37 Clamp ring

MF-449

13. Tighten the impeller nut 0922.00 using the following adjustments:

Torques:

M10x1.5: 20 Nm

M20x1.5: 100 - 120 Nm.




Fig. 38 Impeller nut

MF-450

14. Remove hexagon nuts 0920.22 and clamp ring 0515.01.




Fig. 39 Clamp ring

MF-447

15. Fit the last insert ring 0513.03 into the diffuser casing 112.03.




Fig. 40 Insert ring

MF-451

16. Fit the last O-ring 0412.13 into the diffuser casing 112.03.




Fig. 41 O-ring

MF-452

17. Fit the suction cover 0162.00 into the diffuser casing 112.03.




Fig. 42 Suction cover

MF-453

18. Mount the clamp ring 0515.01 and fix it by using the spring washers 0934.03 and hexagon nuts 0920.22.
Torques: 60-70 Nm




Fig. 43 Clamp ring

MF-454

19. Check that the shaft can rotate smoothly.



Fig. 44 Check

MF-455

6.5 Troubleshooting

Problem	Cause	Remedy
Pump does not deliver or delivers at a reduced rate.	<ol style="list-style-type: none"> 1. Incorrect electrical hook-up (2 phases). 2. Wrong rotational direction. 3. Air in the suction line or in the pump.^a 4. Back pressure too high. 5. Suction head too high, NPSH feed too low. 6. Lines clogged or foreign material in the impeller. 7. Air inclusions as a result of a defective seal. 	<ol style="list-style-type: none"> 1. Check the electrical connections and correct them if necessary. 2. Reverse the phases of the power supply (reverse the polarity). 3. Vent the suction line or the pump and refill. 4. Reset the operating point according to the data sheet. Check system for contamination. 5. Raise the liquid level on the suction side. Open the shut-off valve in the suction line all the way. Produce the conditions described in section 5.1.2. Consult manufacturer. 6. Open the pump and fix the problem. 7. Check the pipeline seals, the pump housing seals, and the shaft seals. Replace if necessary.
Motor safety switch turns motor off. Motor is overloaded.	<ol style="list-style-type: none"> 1. Pump jammed because of clogging. 2. Pump jammed by contact because pump body was twisted by the pipelines. (Check for damage). 3. Pump continues to run beyond the rated operating point. 4. The density or viscosity of the pumping medium is higher than the value stated in the order. 5. Motor safety switch not properly adjusted. 6. Motor running on 2 phases. 	<ol style="list-style-type: none"> 1. Open the pump and fix the problem. 2. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 3. Set the operating point according to the data sheet. 4. If it is acceptable for the performance to be lower than that stated, decrease the delivery rate on the pressure side. Otherwise, use a more powerful motor. Consult manufacturer. 5. Check the setting. Replace the safety switch if necessary. 6. Check the electrical connections. Replace defective fuses.
Pump produces too much noise. Pump runs roughly and vibrates.	<ol style="list-style-type: none"> 1. Suction head too high, NPSH feed too low. 2. Air in the suction line or in the pump.^a 3. Back pressure lower than stated. 4. Impeller out of balance. 5. Internal parts worn. 6. Pump is twisted (causing contact noises). Check for damage. 7. Bearings are defective. 8. Bearings have too little, too much, or the wrong kind of lubricant. 9. Motor cooling fan defective. 10. Gear ring of the coupling (power transmission) defective.^b 11. Foreign material in the pump. 	<ol style="list-style-type: none"> 1. Raise the liquid level on the suction side. Open the shut-off valve in the suction line all the way. Produce the conditions described in section 5.1.2. Consult manufacturer. 2. Vent the suction line or the pump and refill. 3. Set the operating point according to the data sheet. 4. Clean, inspect, and rebalance the impeller. 5. Replace parts. 6. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 7. Replace the bearings. 8. Add more lubricant, decrease the amount, or replace the lubricant. 9. Replace the motor cooling fan. 10. Replace the gear ring of the coupling. Realign the coupling. 11. Open the pump and clean it (install a screen in front of self-priming pumps, if necessary).

Tab. 8 Troubleshooting

Problem	Cause	Remedy
Leakage at the pump body, at the connections, at the mechanical seal and at the stuffing box or gland seal.	<ol style="list-style-type: none"> 1. Pump is twisted (causing leaks at the pump body or at the connections). 2. Housing seals and seals at the connections are defective. 3. Rotating mechanical seal dirty or stuck. 4. Rotating mechanical seal worn. 5. Stuffing box packing worn out. 6. Surface of shaft or shaft safety sleeve worn down. 7. Elastomer unsuitable for the pumping medium. 	<ol style="list-style-type: none"> 1. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 2. Replace the housing seals or the seals of the connections. 3. Inspect and clean the rotating mechanical seal. 4. Replace mechanical seal. 5. Tighten the stuffing box packing, add more packing, or replace the packing. 6. Replace the shaft or the shaft safety sleeve. Repack the stuffing box. 7. Use an elastomer suitable for the pumping medium and the temperature.
Unallowable temperature increase at the pump, bearing housing, or motor.	<ol style="list-style-type: none"> 1. Air in the suction line or in the pump.^a 2. Bearings have too little, too much, or the wrong kind of lubricant. 3. Pump and bearing housing are twisted. 4. Axial thrust too high.^a 5. Motor safety switch is defective or not properly adjusted. 6. Pressure valve closed. 	<ol style="list-style-type: none"> 1. Vent the suction line or the pump and refill. 2. Add more lubricant, decrease the amount, or replace it. 3. Install the pump so that there is no stress on it. Support the pipelines at fixed points. Check the alignment of the coupling. 4. Inspect the relief holes in the impeller and the split rings at the inlet. 5. Check the adjustment. Replace the motor safety switch if necessary. 6. Open the pressure valve.

Tab. 8 Troubleshooting

- a. Applies not to self priming pumps.
b. Applies to CN baseplate design.

6.6 Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest GEA Hilge company or service workshop.

6.7 HILGE assembly tool kit

Remove and install the mechanical seals safely and reliably by using tools of the HILGE assembly tool kit.




Fig. 45 HILGE assembly tool kit

K.0266V1

6.7.1 Content and use

The list below specifies the tools of the kit:

item (fig.)	description	HYGIANA I	HYGIANA II	HYGIANA III
1a	assembly sleeve Ø 19	•		
1b	assembly sleeve Ø 28		•	
2	spray bottle	•	•	•
4b	assembly sleeve Ø 38			•
5	ejector for mechanical seal - stationary ring	•	•	•
6	Klüberpaste UH1 84-201	•	•	•
7	socket wrench SW 32		•	
7	plastic socket spanner insert SW 27		•	
8	Optimol Paste TA	•	•	•
9	socket wrench SW 24	•		
9	plastic socket spanner insert SW 17	•		
10	screw locking Loctite Typ 243	•	•	•
11	socket wrench SW 14	•	•	
11	plastic socket spanner insert SW 10	•	•	
12b	mechanical seal installation sleeve with plastic adapter Ø 38 und Ø 40			•
12b	plastic adapter Ø 38			•
12c	mechanical seal installation sleeve with plastic adapter Ø 28 und Ø 30		•	
12c	plastic adapter Ø 28		•	
12d	mechanical seal installation sleeve with plastic adapter Ø 19 und Ø 22	•		
12d	plastic adapter Ø 19	•		
14	cross handle with 1/2" rectangle	•	•	
	HILGE assembly tool kit	•	•	•

Tab. 9 HILGE-assembly tool kit, tools for HYGIANA

7. Certificate of non-objection

Overview

This section contains a certificate of non-objection. In case of inspection or repairing send the pump including these certificate to HILGE.

7.1 Certificate of non-objection

The following pump and its accessories, together with this certificate of non-objection, are herewith contracted out by the undersigned for inspection/repair:

- Pump data
- Model:
 - No.:
 - Delivery Date:

Reason for inspection / repair contract:

The pump (please mark with a cross)

___ was not used in media hazardous to health

___ was used for the following: _____

Please state the last medium to be pumped, if known:

The pump was carefully drained and also cleaned inside and out before it was shipped/made available. (please mark with a cross)

___ No special safety measures are required in the course of further handling.

___ The following safety measures pertaining to flushing media, residual liquids, and disposal are required:

We confirm that the information given above is correct and complete and that shipment is in compliance with legal regulations.

Company (address):

Telephone, fax, email

Name (please print), title

Date

Company stamp / signature



Excellence

Passion

Integrity

Responsibility

GEA-versity

GEA Group is a global engineering company with multi-billion euro sales and operations in more than 50 countries. Founded in 1881, the company is one of the largest providers of innovative equipment and process technology. GEA Group is listed in the STOXX Europe 600 Index.



GEA Hilge

Hilge GmbH & Co. KG

Hilgestraße 37-47, 55294 Bodenheim, Germany
Phone: +49 6135 75-0, Fax: +49 6135 754955
gea.com