



# Aseptic Valves

GEA Aseptomag® AXV type double chamber valve

Operating instruction (Translation from the original language)

430BAL013017EN\_2

---

## **COPYRIGHT**

These Operating Instructions are the English translation of the original operating instructions in the sense of the EU Machinery Directive. This document is protected by copyright. All rights reserved. The document may not, in whole or in part, be copied, reproduced, translated or reduced to an electronic medium of machine-readable form without the express permission of GEA Tuchenhausen GmbH.

## **LEGAL NOTICE**

### **Word marks**

Aseptomag® and TEFASEP® are registered trademarks of GEA Aseptomag AG and may not be used without the permission of GEA Aseptomag AG.

T.VIS® is a protected trademark of GEA Tuchenhausen GmbH.

---

## TABLE OF CONTENTS

<b>1</b>	<b>General Information</b>	<b>5</b>
1.1	Information on the Document	5
1.1.1	Binding Character of These Operating Instructions	5
1.1.2	Notes on the Illustrations	5
1.1.3	Symbols and Highlighting	5
1.2	Manufacturer address	6
1.3	Customer service	6
1.4	EC Declaration of Incorporation	7
<b>2</b>	<b>Safety</b>	<b>8</b>
2.1	Intended use	8
2.1.1	Requirements for operation	10
2.1.2	Pressure equipment directive	10
2.1.3	ATEX directive	10
2.1.4	Improper operating conditions	10
2.2	Operator's Duty of Care	10
2.3	Subsequent changes	11
2.4	General safety instructions and dangers	11
2.4.1	Principles for safe operation	12
2.4.2	Environmental Protection	12
2.4.3	Electrical Equipment	12
2.5	Supplementary Regulations	13
2.6	Qualification of personnel	13
2.7	Safety equipment	14
2.7.1	Signs	14
2.8	Residual dangers	15
2.9	Danger zones	16
<b>3</b>	<b>Description</b>	<b>17</b>
3.1	Design of the Valve	17
3.2	Valve Identification	19
3.3	Sealing Concepts	21
3.3.1	"Shrink-on Fit" Version	21
3.3.2	System "separable"	21
<b>4</b>	<b>Transport and storage</b>	<b>23</b>
4.1	Storage conditions	23
4.2	Transport	23
4.2.1	Scope of supply	23
<b>5</b>	<b>Technical data</b>	<b>24</b>
5.1	Technical data	24
<b>6</b>	<b>Assembly and installation</b>	<b>26</b>
6.1	Safety instructions	26
6.2	Notes on installation	26
6.3	Welding In a Valve with Pipe Connection	26
6.3.1	Welding In and Installing a Valve	26
6.3.2	Welding post-treatment	27
6.4	Pneumatic connections	28
6.4.1	Overview switching positions	28
6.4.2	Air Requirement	29
6.4.3	Establishing the Compressed Air Supply	29
6.5	Electrical connections	30
<b>7</b>	<b>Start-up</b>	<b>31</b>
7.1	Safety instructions	31
7.2	Notes on commissioning	31
<b>8</b>	<b>Operation and control</b>	<b>32</b>
8.1	Safety instructions	32
<b>9</b>	<b>Cleaning</b>	<b>33</b>
9.1	Cleaning	33
9.2	Sterilisation	33
9.3	Passivation	33
<b>10</b>	<b>Maintenance</b>	<b>35</b>

10.1	Safety instructions	35
10.2	Inspections	36
10.2.1	Bellows	36
10.2.2	Piston rod seal	36
10.2.3	Pneumatic connections	36
10.2.4	Electrical connections	36
10.3	Maintenance intervals	37
10.4	List of tools	38
10.5	Prior to disassembly	44
10.6	Disassembling and Assembling the Valve	44
10.6.1	Dismantling and fitting the upper main valve	44
	Disassembling the Valve	44
	Assembling the Valve	47
10.6.2	Dismantling and fitting the lower main valve	47
	Disassembling the Valve	47
	Assembling the Valve	51
10.6.3	Torques for clamp	53
10.7	Disassemble and assemble the side valves	53
10.7.1	Overview disassembly / assembly side valve	53
10.7.2	Disassemble and assemble inside part (side valve) - versions "LVD" and "UV"	53
	Disassemble piston rod seal (side valve) - versions "LVD" and "UV"	53
	Assemble piston rod seal (side valve) - version "LVD" and "UV"	55
10.7.3	Disassemble and assemble piston rod seal (side valve) - version "LVD" and "UV"	55
	Dismantling the piston rod seal – version "LVD" and "UV"	55
	Fitting the piston rod seal – version "LVD" and "UV"	56
10.7.4	Disassemble and assemble actuator PA50/PA60 (side valve)	57
	Disassembling Actuator PA50/PA60	57
	Assembling Actuator PA50/PA60	62
10.8	Disassemble and assemble the internal assembly "EA"	62
10.8.1	Disassemble internal assembly "EA"	63
10.8.2	Assemble internal assembly "EA"	65
10.8.3	Torques for EA Valve Axes	66
10.9	Removing and Installing the "Shrunk-on" Valve Seat Seal	67
10.9.1	Removing the Shrunk-on Valve Seat Seal	67
10.9.2	Fitting the "Shrink-on Fit" Valve Seat Seal	68
10.10	Removing and Installing the "Divisible System" Valve Seat Seal	70
10.10.1	Disassemble the valve seat seal "system divisible" - valve version "EA"	70
10.10.2	Assemble the valve seat seal "system divisible" - valve version "EA"	71
10.10.3	Torques for divisible valve discs	72
10.11	Carrying out the "Internal Assembly" Leak Test (Bubble Test)	72
10.11.1	Bubble test valve version "EA"	72
10.12	Disassembling and Assembling Actuator PA80EA - PA255EA	74
10.12.1	Disassembling Actuator PA80EA - PA255EA	74
10.12.2	Assembling Actuator PA80EA - PA255EA	78
10.13	Maintenance	80
10.14	Checking the Feedback Unit	81
10.14.1	Setting the Feedback Unit	81
10.14.2	Valve Stroke	82
<b>11</b>	<b>Alarms</b>	<b>83</b>
11.1	Malfunctions and remedies	83
<b>12</b>	<b>Decommissioning</b>	<b>85</b>
12.1	Safety instructions	85
12.2	Disposal	85
12.2.1	General notes	85
<b>13</b>	<b>Appendix</b>	<b>86</b>
13.1	Lists	86
13.1.1	Abbreviations and terms	86

# 1 General Information

## 1.1 Information on the Document

The present Operating Instructions are part of the user information for the product. The Operating Instructions contain all the information you need to transport, install, commission, operate and carry out maintenance for the product.

### 1.1.1 Binding Character of These Operating Instructions

These Operating Instructions contain the manufacturer's instructions to the operator of the product and to all persons who work on or use the product regarding the procedures to follow.

Carefully read these Operating Instructions before starting any work on or using the product. Your personal safety and the safety of the product can only be ensured if you act as described in the Operating Instructions.

Store the Operating Instructions in such a way that they are accessible to the operator and the operating staff during the entire life cycle of the product. When the location is changed or the product is sold make sure you also provide the Operating Instructions.

### 1.1.2 Notes on the Illustrations

The illustrations in these Operating Instructions show the product in a simplified form. The actual design of the product can differ from the illustration. For detailed views and dimensions of the product please refer to the design documents.

### 1.1.3 Symbols and Highlighting

In these Operating Instructions, important information is highlighted by symbols or special formatting. The following examples illustrate the most important types of highlighting.



#### **Danger**

##### **Warning: Fatal Injuries**

Failure to observe the warning can result in serious damage to health, or even death.

► The arrow identifies a precautionary measure you have to take to avoid the hazard.



##### **Warning: Explosions**

Failure to observe the warning can result in severe explosions.

► The arrow identifies a precautionary measure you have to take to avoid the hazard.



### **Warning!**

#### **Warning: Serious Injuries**

Failure to observe the warning can result in serious damage to health.

- The arrow identifies a precautionary measure you have to take to avoid the hazard.



### **Caution!**

#### **Warning: Injuries**

Failure to observe the warning can result in minor or moderate damage to health.

- The arrow identifies a precautionary measure you have to take to avoid the hazard.

### **Notice**

#### **Warning: Damage to Property**

Failure to observe the warning can result in serious damage to the component or in the vicinity of the component.

- The arrow identifies a precautionary measure you have to take to avoid the hazard.

Carry out the following steps: = Start of a set of instructions.

1. First step in a sequence of operations.
  2. Second step in a sequence of operations.
    - Result of the previous operation.
- The operation is complete, the goal has been achieved.



### **Hint!**

**Further useful information.**

## **1.2 Manufacturer address**

GEA Aseptomag AG  
Industrie Neuhof 28  
CH-3422 Kirchberg

## **1.3 Customer service**

Phone: +41 (0)34 426 29 29  
Fax: +41 (0)34 426 29 28  
service.aseptomag@gea.com  
www.gea.com

## 1.4 EC Declaration of Incorporation



# Declaration of Incorporation

Kirchberg, 16.12.16

### According 2006/42/EC from 09.06.2006, appendix II B

**INCORPORATION OF PARTLY COMPLETED MACHINERY**

We herewith declare that the subsequently described partly completed machine complies with the below listed essential requirements of the machine directive 2006/42/EC. The technical documentation is compiled in accordance with part B of Annex VII. In response to reasonable request the relevant technical documentation will be provided to the national authorities in printed or electronic format (PDF).

Manufacturer:	<b>GEA Aseptomag AG Industrie Neuhof 28 CH-3422 Kirchberg</b>
Authorized person:	<b>GEA Aseptomag AG Engineering Department Industrie Neuhof 28 CH-3422 Kirchberg</b>
Commercial name of the machine:	<b>Valve</b>
Machine type:	<b>Aseptomag® Valve Technology</b>
Serial number:	<b>xxxx yy (x = serially numbered, y = year of manufacture)</b>
Respective EC standard:	<b>2006/42/EC</b>
Essential requirements:	<b>Appendix I, section 1 and 2.1</b>
Applied harmonized standards:	<b>DIN EN ISO 12100:2010</b>

The commissioning of this partly completed machine is prohibited until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machine Directive 2006/42/EC.



**Reimar Gutte**  
Management Board  
GEA Aseptomag AG



**i.A. Aron Stauffer**  
Teamleader Product Development  
Flow Components – Aseptic Valves

GEA Aseptomag AG  
Tel. +41 34 426 29 29 · Fax +41 34 426 29 28 · [gea.com](http://gea.com)  
Industrie Neuhof 28, CH-3422 Kirchberg

Seite 1 von 1

## 2 Safety

### 2.1 Intended use

Aseptic AXV type double chamber valves are mixproof globe valves for aseptic process systems and enable reliable separation of incompatible media, including during cleaning of the valve seats and when carrying out maintenance of the valve during ongoing operation. Media separation is performed by three integrated steam barriers (ISB) which are hermetically segregated from both product lines (respective adjacent ISB) by way of a seal, as well as from the atmosphere by way of two side valves (inlet and outlet).

For safe operation, it is mandatory that the following points are observed in the different process steps:

#### Home position

Both main valves are in the closed position. This allows reliable separation of both process lines from one another via the steam barriers.




Fig.1: Home position

#### Transfer

All side valves must be completely closed during media transfer through the main valve.




Fig.2: Transfer



### Cleaning of the steam barriers

The steam barriers must be scavenged with at least one sterile medium following a medium transfer. Once both main valves have been closed, all side valves can be opened (outlet valves first) to allow scavenging of the steam barriers. The media pressure applied at the inlet side may not exceed 4 bar.




Fig.3: Sterilisation after transfer

### CIP cleaning with seat venting

If seat venting is activated during CIP cleaning (preferably in cycles), the outlet valve of the respective steam barrier must be opened to allow drainage of the CIP medium. Moreover, it must be ensured that at least one steam barrier remains active during seat venting if the opposite product line is being operated sterile.




Fig.4: Cleaning valve seats A and B




Fig.5: Cleaning valve seats C and D

Pressure hammers and excessive control air pressure (>8 bar) can damage the bellow. The AXV double chamber valves should therefore close against flow direction of the medium wherever possible. Should this not be possible due to technical reasons related to the plant or process, it is recommended to switch the valve without pressure. Both measures prevent pressure hammers when the valve is opened or closed.

The valve is monitored, controlled and operated by the customer's system.



**Hint!**

**The manufacturer will not accept any liability for damage resulting from any use of the valve which is not in accordance with the designated use of the valve. The risk of such misuse lies entirely with the operator of the facility.**

---

### **2.1.1 Requirements for operation**

The prerequisite for reliable and safe operation of the component is proper transportation and storage as well as professional installation and assembly. Operating the unit within the limits of its designated use also involves adhering to the operating, inspection and maintenance instructions.

### **2.1.2 Pressure equipment directive**

The valve is a piece of pressure equipment (without safety function) as defined in the Pressure Equipment Directive: Directive 2014/68/EG. It is classified according to Annex II, article 4, section 3. In the event of any deviations, GEA Aseptomag AG will supply a specific Declaration of Conformity.

### **2.1.3 ATEX directive**

Aseptomag<sup>®</sup> valve technology can also be used in ATEX protected areas. However, the suitability of the component must be checked under consideration of the respective conditions. Additional information will be made available upon request.

### **2.1.4 Improper operating conditions**

The operational reliability of the valve cannot be ensured under improper operating conditions. Therefore avoid improper operating conditions.

Operating the valve is not permitted if

- Persons or objects are in the danger zone.
- Safety devices are not working or were removed.
- Malfunctions have been detected on the valve.
- Damage has been detected on the valve.
- Maintenance intervals have been exceeded.
- the position of the side valves is not adjusted to the process steps

## **2.2 Operator's Duty of Care**

The operating company of the component has a special responsibility for the proper and safe handling of the component within their company. Only use the component when it is in perfect operating condition in order to prevent danger to persons and property.

This operating manual contains information that you and your employees need for safe operation over the life of the component. Be sure to read these Operating Instructions carefully and ensure that the measures described here are observed.

The operator's duty of care includes planning the necessary safety measures and monitoring that these measures are observed. The following principles apply:

- Only qualified personnel may work on the component.
- The operating company must authorize personnel to carry out the relevant tasks.
- Order and cleanliness must be maintained at the work stations and in the entire area surrounding the component.
- Personnel must wear suitable work clothing and personal protective equipment. As the operating company must ensure that work clothing and personal protective equipment are used.
- Inform personnel regarding any properties of the product which might pose a health risk and the preventative measures to be taken.
- Have a qualified first-aid representative on call during the operation. This person must be able to initiate any necessary first-aid measures in case of an emergency.
- Clearly define procedures, competences and responsibilities for those working in the area of the component. Everybody must know what to do in case of an emergency. Instruct the staff in this respect at regular intervals.
- The signs on the component must always be complete and easy to read. Check, clean and replace the signs as necessary at regular intervals.
- Observe the Technical Data specified and the limits of use!



#### **Hint!**

**Carry out regular checks. This way you can ensure that these measures are actually observed.**

---

## **2.3 Subsequent changes**

You should never make any technical modifications to the valve. Otherwise you will have to undergo a new conformity process in accordance with the EC Machinery Directive on your own.

In general, only original spare parts supplied by GEA Aseptomag AG should be fitted. This ensures the reliable and economical operation of the valve.

## **2.4 General safety instructions and dangers**

The component is safe to operate. It was built according to state-of-the-art science and technology.

Nevertheless, dangers can arise from the component, if:

- the component is not used as intended
- the component is used improperly

- the component is operated under impermissible conditions

#### **2.4.1 Principles for safe operation**

Dangerous situations during operation can be avoided by safety-conscious and proactive behaviour of the staff.

To ensure safe operation of the valve the following principles apply:

- The Operating Instructions must be kept ready to hand at the valve's place of use. They must be complete and in clearly legible form.
- Only use the valve for its intended use.
- The valve must be functional and in good working order. Check the condition of the valve before starting work and at regular intervals.
- Wear tight-fitting work clothing for all work on the valve.
- Ensure that nobody can get hurt on the parts of the valve.
- Immediately report any faults or noticeable changes on the valve to the person responsible.
- Never touch the pipes and the valve when these components are hot! Avoid opening the valve unless the process plants have been emptied and depressurised.
- Observe the accident prevention regulations and all local regulations.

#### **2.4.2 Environmental Protection**

Harm to the environment can be avoided by safety-conscious and proactive behaviour of the staff.

For environmental protection the following principles apply:

- Substances harmful to the environment must not be discharged into the ground or the sewage system.
- Always observe the pertinent regulations relating to waste avoidance, disposal and utilization.
- Substances harmful to the environment must be collected and stored in suitable containers. Clearly mark the containers.
- Dispose of lubricants as hazardous waste.

#### **2.4.3 Electrical Equipment**

For all work on electrical equipment, the following principles apply:

- Access to electrical equipment should only be allowed to qualified electricians. Always keep unattended switch cabinets locked.
- Modifications of the control system can affect the safe and reliable operation. Modifications are only permitted with the express permission of the manufacturer.
- After completion of all work, check that the protective devices are fully functional.

## **2.5 Supplementary Regulations**

In addition to the instructions in this documentation the following also has to be observed:

- pertinent accident prevention regulations,
- generally accepted safety rules,
- national regulations applicable in the country of use,
- work and safety instructions applicable in the facility,
- installation and operating regulations for use in potentially explosive areas.

## **2.6 Qualification of personnel**

This section provides information on how the personnel working on the component must be trained.

Operating and maintenance personnel must

- have the necessary qualification to carry out their tasks,
- be instructed with regard to possible dangers,
- know and observe the safety instructions given in the documentation.

Only allow qualified electricians to carry out work on the electrical equipment or have a qualified electrician supervise the work.

Only allow specially trained personnel to carry out work on an explosion-protected system. When working on explosion-protected equipment observe the standards DIN EN 60079-14 for gases and DIN EN 50281-1-2 for dusts.

The following minimum qualifications are required:

- Training as a specialist for working independently on the component.
- Adequate instruction to work on the component under the supervision and guidance of a trained specialist

Each employee must meet the following requirements to work on the component:

- Personal suitability for the respective task.
- Sufficient professional qualification for the respective task.
- Received instruction about the functionality of the component.
- Received instruction about operating sequences on the component.
- Familiar with the safety devices and their function.
- Familiar with these Operating Instructions, especially with the safety instructions and the information which is relevant for the task on hand.
- Familiar with the basic regulations with regard to occupational health and safety and accident prevention.



When working with the component, a distinction is made between the following user groups:

User groups	
Staff	Qualifications
Operating personnel	<p>Adequate instruction and sound knowledge in the following areas:</p> <ul style="list-style-type: none"> <li>• Functionality of the component</li> <li>• Operating sequences on the pump</li> <li>• What to do in case of an emergency</li> <li>• Lines of authority and responsibilities with respect to the task</li> </ul>
Maintenance personnel	<p>Appropriate training and a sound knowledge of the structure and functionality of the component.</p> <p>Sound knowledge in the following areas:</p> <ul style="list-style-type: none"> <li>• Mechanical equipment</li> <li>• Electrical equipment</li> <li>• Pneumatic system</li> </ul> <p>Authorization with regard to safety engineering standards to carry out the following tasks:</p> <ul style="list-style-type: none"> <li>• Setting devices into operation</li> <li>• Earthing of devices</li> <li>• Marking of devices</li> </ul> <p>The relevant certificates of qualification must be submitted before work can be carried out on ATEX certified machines.</p>

## 2.7 Safety equipment

### 2.7.1 Signs

Hazardous locations on the component are marked by warning labels. The signs and instructions on the component must always be legible. Any illegible signs must be replaced immediately.

Signs on the valve	
Sign	Meaning
	<p>Sticker with warning on spring tension on side valve.</p>
	<p>Warning: risk of crushing. Attached on both sides of the lantern.</p>

## 2.8 Residual dangers

Dangerous situations can be avoided by safety-conscious and proactive behaviour of the personnel and by wearing personal protective equipment.

Residual dangers on the valve and measures		
Danger	Cause	Measure
Danger to life	Inadvertent switch-on of the valve	Effectively disconnect all components, effectively prevent switch-on.
	Electric power	Observe the following safety rules: <ol style="list-style-type: none"> <li>1. Isolate from the power supply.</li> <li>2. Take appropriate measures to prevent switch on.</li> <li>3. Test absence of voltage.</li> <li>4. Earthing and short-circuiting.</li> <li>5. Cover or safeguard any adjacent live parts.</li> </ol>
Danger of injury	Danger presented by moving or sharp-edged parts	The operator must exercise caution and prudence. For all work: <ul style="list-style-type: none"> <li>• Wear suitable work clothing.</li> <li>• Never operate the machine if the cover panels are not correctly fitted.</li> <li>• Never open the cover panels during the operation.</li> <li>• Never reach into openings.</li> </ul> As a precautionary measure, wear personal protective equipment in the vicinity of the valve: <ul style="list-style-type: none"> <li>• Protective gloves</li> <li>• Safety shoes</li> </ul>
Environmental damage	Operating materials with properties which are harmful to the environment	For all work: <ul style="list-style-type: none"> <li>• Collect lubricants and cleaning solutions in suitable containers.</li> <li>• Dispose of lubricants and cleaning solutions in accordance with the pertinent regulations.</li> </ul>

## 2.9 Danger zones




Fig.6: Danger zone at the valve

Please observe the following notes:

- In the event of malfunctions, shut down the valve (disconnect from the power and air supply) and secure it against being used.
- Never reach into the lantern (1) or the valve housing (2) when the valve is switching. There is a danger of injury to fingers.
- With a closed valve there is danger of injury when the clamp (3) is opened since the released closing pressure will suddenly lift the actuator. Therefore, release the closing pressure by opening the valve before detaching the clamp (3) by supplying the actuator (A) with compressed air.
- Before starting any service, maintenance or repair work, disconnect the valve from the power supply and secure it against inadvertently being switched back on again.
- Only allow a qualified electrician to carry out any work on the electrical power supply.
- Check the electrical equipment of the valve at regular intervals. Immediately remedy loose connections and molten cables.
- If work on live parts cannot be avoided, call in a second person, who can operate the main switch in case of an emergency.
- The housing sockets have very sharp edges. When transporting and assembling the valve be sure to wear suitable protective gloves.



### 3 Description

#### 3.1 Design of the Valve




Fig.7: Main components on valve, 1-4

Key	
No.	Designation
1	Housing
2	Internal assembly
2a	Valve seat A
2b	Valve seat B
2c	Valve seat C
2d	Valve seat D
3	Actuator
4	Clamp (safety device)




Fig.8: Main components on valve, 5-7

Key	
No.	Designation
5	Inlet valve (side valve)
6	Outlet valve (side valve)
7	Clamp to side valve (safety installation)

### 3.2 Valve Identification

Reference numbers from the following number systems are assigned to each part of components from GEA Aseptomag AG. The reference numbers can be used to clearly identify a component and its composition.

Number (Example)	Designation	Description
0001 14	Serial valve number	The valve serial number is the easiest and most definite way to identify a component from GEA Aseptomag AG. This number is unique and allows all components installed at the time of delivery to be identified. The first four digits represent a chronological, ascending number, the last two digits provide information about the year of manufacture. The valve's serial number is indicated on a round white sticker affixed to the actuator.
0001 14	Serial number main components	The serial number has the same structure as the valve's serial number, but it is placed on the relevant main component (housing, internal assembly, actuator) by laser marking / stamping.
V-50-1001	Drawing number	<p>The drawing number is a combination of two groups. The digits in front of the hyphen refer to where the components belong to. The next four numbers describe the part in more detail. For this purpose, the main component groups of a valve are assigned to various groups:</p> <ul style="list-style-type: none"> <li>• V-xx-0xxx = entire valves</li> <li>• V-xx-1xxx = valve housings</li> <li>• V-xx-2xxx = internal assemblies</li> <li>• V-xx-3xxx = actuators</li> <li>• V-xx-4xxx = feedback units / accessories</li> </ul>

Each of these main components is marked and can be uniquely identified.

! Other markings on components of the valve, such as on connectors, arise from the production process and are not relevant.




Fig.9: Designation on valve

Key			
No.	Example	Position	Details
1	V50-1235 1.4435 TC 333937	Valve housing	Drawing number of valve housing Material and re-stamping details
2	0548 10	Valve housing	Serial number of valve housing
3	V-50-1004	Clamp	Number of clamp drawing
4	V-50-2245 1424 10	Internal assembly	Drawing number of internal assembly Serial number of internal assembly
5	1216 10	Actuator	Sticker with valve serial number
6	PA100/50 NC V-50-3000 0977 10	Actuator	Designation of actuator Number of actuator drawing Serial number of actuator
7	PA60-15 DK OR NO V15-3050 0812 10	Inlet valve	Designation of actuator Number of actuator drawing Serial number of actuator
8	PA60/25 DK OR NC PT V25-3121 0813 10	Outlet valve	Designation of actuator Number of actuator drawing Serial number of actuator
9	V-15-1004	Clamp to side valve	Number of clamp drawing

### 3.3 Sealing Concepts

#### 3.3.1 "Shrink-on Fit" Version

- Undivided valve disc
- GEA Aseptomag standard
- For hard sealing materials such as TEFASEP, PTFE or reinforced PTFE




Fig.10: "Shrink-on Fit" Version seats A and C




Fig.11: "Shrink-on Fit" Version seats B and D

#### 3.3.2 System "separable"

##### Valve seat seals

TVT	Divisible valve disc, valve seat seal TEFASEP
TVE	Divisible valve disc, valve seat seal EPDM (form seal)

##### Concept for hard sealing materials

- Divisible valve disc
- GEA Aseptomag option for seats A and C
- For hard sealing materials like TEFASEP (TVT)
- Additional elastomer O-ring behind the valve seat seal




Fig.12: "Divisible" version - for hard sealing materials

##### Concept for elastomer sealing materials

- Divisible valve disc
- GEA Aseptomag option for seats A and C
- For elastomer sealing materials such as EPDM (TVE)
- Form-seal with moulded-on retention flag




Fig.13: "Divisible" version - for elastomer sealing materials

## 4 Transport and storage

### 4.1 Storage conditions

The valves, valve inserts or spare parts should be stored in a dry place, free of vibrations and dust, and protected from light. To avoid damage, leave the components in their original packaging if possible.

If, during transport or storage, the valve is going to be exposed to temperatures  $\leq 0^{\circ}\text{C}$ , it must be dried beforehand and suitable measures must be taken to protect it from damage.



#### Hint!

**We recommend that the valve should be stored at a temperature of  $\geq 5^{\circ}\text{C}$  for a period of 24 hours prior to any handling (disassembling the housings / activation of actuators) so that any ice crystals formed by condensation water can melt.**

---

### 4.2 Transport

For transport, the following principles apply:

- Only use suitable lifting gear and slings for transporting the package units/ valves.
- Observe the pictograms on the package.
- Handle valves with care to avoid damage caused by impact or careless loading and unloading. The outside synthetic materials are susceptible to breaking.
- Control tops (if fitted) must be protected from animal and vegetable fats.
- Only allow qualified staff to transport the valve.
- Movable parts must be properly secured.
- Only use approved, fully functional load lifting devices and lifting accessories which are suitable for the intended purpose. Observe the maximum load-bearing capacities.
- Secure the valve against slipping. Take the weight of the valve into account and the position of the point of gravity.
- Under no circumstances should anyone stand under a suspended load.
- Take care when transporting the valve. Do not grip sensitive parts of the unit to lift or push the unit or to support yourself. Avoid putting the unit down with a jerk.

#### 4.2.1 Scope of supply

On receipt of the valve check whether

- the details on the main valve components correspond to the data in the order and delivery documents,
- the equipment is complete and all components are in good order.

## 5 Technical data

### 5.1 Technical data

Operating data (for valve with sealing materials Tefasep and silicone)	
Max. operating temperature	150 °C (302 °F)
Max. sterilisation temperature	160 °C (320 °F) for max. 30 min.
Max. product pressure	6 bar (others on request)
Max. media pressure of sterile chamber	< 4 bar (if main valve is closed)
Control air pressure, actuator	6 bar, max. 8 bar
Nominal pressure	10 bar

Materials	
Parts in contact with product	1.4404 (AISI 316L) 1.4435 (AISI 316L) 1.4571 (AISI 316TI)
Actuator (exterior area)	1.4301 (AISI 304) 1.4305 (AISI 304)
Valve seat seal (product-contacting)	TEFASEP PTFE EPDM
Seal (product-contacting)	Silicone EPDM FEP silicone
Other materials in accordance with the valve specification.	

Surface finish	
Inside areas in contact with product	Surface roughness $R_a \leq 0.8 \mu\text{m}$ (standard)
Outer surfaces	Metal blank fine turned and/or polished
Inside areas (with the exception of the metal bellows) in contact with product can be electropolished/passivated or ground on request. These methods will bring up surface roughness to $R_a \leq 0.6 \mu\text{m}$ / $0.4 \mu\text{m}$ .	



Resistance of sealing materials	
Product contact seals	All sealing materials in the product contact area are suitable for applications in the food industry. The durability of the sealing materials depends on the type, temperature and contact time of the conveyed media. The final assessment of the suitability of the material is therefore the sole responsibility of the plant operator, even if the materials meet all common guidelines of the food industry (for further information see material certificates).
Compressed air supply	
Compressed air supply	6 bar, compressed air filtered (at least 0,5 µm), oil-free.
Cleaning	
Cleaning	The valve is suitable for CIP cleaning (Cleaning in Place)
Recommended cleaning speed in the valve	At least 2 m/s
Sterilisation	
Sterilisation	The valve is suitable for SIP sterilisation (Sterilisation in Place)
Sterilisation with	Hot water, max. 160 °C (320 °F) Steam, max. 160 °C (320 °F) Chemicals (e.g. H <sub>2</sub> O <sub>2</sub> )

## **6 Assembly and installation**

### **6.1 Safety instructions**

Hazardous situations during installation can be avoided by safety-conscious and proactive behaviour of the personnel.

For installation, the following principles apply:

- Only qualified personnel are allowed to set-up, install and commission the component.
- Ensure that adequate working and traffic areas are available at the place of installation.
- Observe the maximum load-bearing capacity of the installation surface.
- Observe the transport instructions and markings on the part(s) to be transported.
- Remove any nails protruding from transport crates immediately after opening the crate.
- Under no circumstances should anyone stand under a suspended load.
- Safety devices of the component may not work effectively during installation.
- Reliably secure sections of the plant which have already been connected against inadvertently being switched on.

### **6.2 Notes on installation**

The valve must be installed so that the housing can drain on its own.

The divert valve housing at the side valve must (if it exists) be connected to the pipe system via removable connections.

To prevent damage, make sure that

- the valve is installed in the pipe system free of tension and
- no foreign materials (e.g. tools, bolts, lubricants) are left in the system.
- the valve is installed so that the flow is directed against the valve disc.
- the valve is ideally installed in vertical position.

### **6.3 Welding In a Valve with Pipe Connection**

#### **6.3.1 Welding In and Installing a Valve**

This section describes how you weld in a valve with pipe connection.

Prerequisite:

- For valves with welding ends: Actuator and internal assembly have been removed, see Section 10.6.1, Page 44.



### **Caution!**

#### **Danger of injury due to spring force being released**

You can sustain injuries to your fingers when you put your hand into a valve if the valve has not been moved to the open position beforehand.

- ▶ Before starting any work, bring the valve to the "open" position.
- ▶ Wear protective gloves for all work.
- ▶ Always exercise caution and prudence.



### **Caution!**

#### **If pipes contain liquids, these can spurt out when the pipes are opened.**

Danger of injury as a result of hot or aggressive liquids.

- ▶ Drain all pipe system elements that lead to the valve location and, if necessary, clean or rinse them.
- ▶ Separate the pipe section in which the valve is to be fitted from the rest of the piping system to prevent medium from entering again.

Carry out the following steps:

1. Saw the pipe ends flat and square, deburr and degrease them.
2. Prepare the component housing so that the component housing can be welded into position free from stress and distortion.
3. Prepare the welding procedure: use the 141 TIG (tungsten inert gas) welding method with butt weld. I-joint according to DIN8532; hand or orbital weld.
4. Connect the forming gas.
5. Tack the component housing at several points distributed around the circumference under forming gas (ensure forming gas supply).

! Adjoining welding ends must not be separated by a gap. Otherwise the corrosion resistance of the welded joint and the pipe will be reduced when forming gas flows out.

6. Weld the housing into the pipe system.

→ The valve has been welded in and installed.

## **6.3.2 Welding post-treatment**

### **Interior**

As long as forming and welding were carried out professionally, post-treatment of the interior surfaces is not necessary.

### **Exterior area**

Depending on the requirements, post-treatment in the exterior area consists of:

- pickling,
- grinding,
- brushing,

- polishing.

6.4 Pneumatic connections

6.4.1 Overview switching positions




Fig.14: Switch positions

Function	Valve seat	Air connection	
Open	A + B / C + D	1	"D"
Venting	A / C	3	"E"
Venting	B / D	2	"C"
Control	Side valve	4	

→ Information on mounting the valve, see Section 3.1, Page 17.

## 6.4.2 Air Requirement

The air requirement depends on the type of actuator fitted. The following tables show guideline values at an air pressure supply of 6 bar per valve size and the corresponding actuator size used as a standard.

Air requirement AXV for spring-to-close actuators (NC)				
Nominal width of valve	Actuator	Air requirement [dm <sup>3</sup> ]		
		Total stroke	Venting Seats A / C	Venting Seats B / D
DN25 / 1"OD	PA80/25 EA	0.6	0.8	0.2
DN40 / 1½"OD	PA100/50 EA	1.0	1.3	0.3
DN50 / 2"OD	PA100/50 EA	1.1	1.3	0.3
DN65 / 2½"OD	PA135/65 EA	2.8	2.6	0.8
DN80 / 3"OD	PA180/80 EA	6.3	4.9	1.2
DN100 / 4"OD	PA180/100 EA	6.2	4.7	1.2
DN125	PA255/125-150 EA	17.0	14.0	2.8

Air requirement AXV for actuators NC and NO of side valve				
Valve	associated side valve			
Nominal width	Nominal width	Actuator	Air requirement [dm <sup>3</sup> ]	
			direction of action NC	direction of action NO
DN25 / 1"OD	DN15/15	PA50	0.2	0.1
DN40 / 1½"OD	DN15/25	PA60	0.6	0.5
DN50 / 2"OD	DN15/25	PA60	0.6	0.5
DN65 / 2½"OD	DN15/25	PA60	0.6	0.5
DN80 / 3"OD	DN15/25	PA60	0.6	0.5
DN100 / 4"OD	DN15/25	PA60	0.6	0.5
DN125	DN15/25	PA60	0.6	0.5

## 6.4.3 Establishing the Compressed Air Supply

A prerequisite for the reliable operation of the valve is that the compressed air hoses are cut exactly square.

Tools required:

- A hose cutter

Carry out the following steps:

1. Depressurize the pneumatic connection at the place where you are working.
2. Use the hose cutter to cut the pneumatic hoses square.

3. Connect a hose to the valve.
- The compressed air supply has been established.

## **6.5 Electrical connections**

Prerequisite:

- The valve has been fitted correctly, see Section 10.6.2.2, Page 51.



### **Danger**

#### **Live parts**

Electrical shock can result in serious personal injury or death.

- ▶ Only allow properly qualified staff to carry out work on the electrical equipment.
- ▶ Prior to establishing electrical connections check the maximum permissible operating voltage.



#### **Explosive gases or dusts**

An explosion can result in serious personal injury or death.

- ▶ Observe the installation and operating regulations for use in potentially explosive areas.

Carry out the following steps:

1. Connect in accordance with the control top diagram and the instructions in the corresponding operating instructions for the T.VIS control top or other models.
- The valve has been connected electrically.

## **7 Start-up**

### **7.1 Safety instructions**

#### **Initial commissioning**

For initial commissioning, the following principles apply:

- Take protective measures against dangerous contact voltages in accordance with pertinent regulations.
- The valve must be completely assembled and correctly adjusted. All screw connections must be securely tightened. All electrical cables must be installed correctly.
- Reliably secure machine parts which have already been connected against inadvertently being switched on.
- Relubricate all lubricating points.
- Make sure lubricants are used properly.
- After conversion of the valve, residual risks must be reassessed.

#### **Setting into Operation**

For commissioning, the following principles apply:

- Only allow properly qualified staff to set the valve into operation.
- Establish all connections correctly.
- The safety devices for the valve must be complete, fully functional and in perfect condition. Check the function before starting any work.
- When the valve is switched on, the danger zones must be free.
- Remove any liquids that have escaped without leaving residues.

### **7.2 Notes on commissioning**

Before starting commissioning observe the following:

- Make sure that there are no foreign materials in the system.
- Actuate all positions of the valve once by applying compressed air.
- When TEFASEP is used as a sealing material, the valve must be sterilised before the first product run and briefly brought to the closed position immediately after sterilisation to ensure optimum tightness. For detailed information, see Section 9.2, Page 33
- Clean and sterilise the pipe system prior to the first product run.
- During commissioning, regularly check all sealing points for leaks. Replace defective seals.

## **8 Operation and control**

### **8.1 Safety instructions**

Dangerous situations during operation can be avoided by safety-conscious and proactive behaviour of the personnel.

For operation, the following principles apply:

- Monitor the component during operation.
- Safety devices must not be changed, removed or taken out of service. Check all safety devices at regular intervals.
- All guards and hoods must be fitted as intended.
- The installation location of the component must always be properly ventilated.
- Structural changes to the component are not permitted. Report any changes to the component immediately to the person in charge.
- Always keep danger zones clear. Do not leave any objects in the danger zone. Only allow persons to enter the danger zone when the machine is de-energized.
- Regularly check that all emergency stop devices are working correctly.



## 9 Cleaning

### 9.1 Cleaning

The valve is suitable for CIP (Cleaning in Place); recommended cleaning speed in the valve is at least 2 m/s.

All parts in contact with product must be cleaned at regular intervals. Always observe the safety data sheets issued by the cleaning agent manufacturers. Only use cleaning agents which do not cause damage to the seals and the inner parts of the valve. When the pipe is cleaned, the cleaning medium also flows through and cleans the valve housings.

With respect to the cleaning method and parameters like detergents, temperatures, times, and intervals, the component manufacturer can merely make recommendations but cannot provide any generally applicable details. Method and parameters should be determined and defined by the operator in accordance with the relevant process and product.

The cleaning effect must be checked regularly by the operator!

### 9.2 Sterilisation

The valve is suitable for SIP sterilisation (sterilisation in place). The following data applies for valves equipped with TEFASEP® and silicone sealing materials.

Sterilisation is possible with:

- Hot water, max. 160 °C (320 °F)
- Steam at max. 160 °C (320 °F) for 20 to 30 min
- Chemicals (e.g. H<sub>2</sub>O<sub>2</sub>)



#### Hint!

**When TEFASEP® valve seat seals are used, hot sterilization is mandatory. Steam sterilization allows the seal to be perfectly fitted into the valve seat, thus ensuring optimum sealing against the maximum closing pressure specified.**

#### Operating conditions for steam sterilization:

- Medium: saturated steam
- Temperature: >121 °C (250 °F)
- Holding time: 20 ... 30 min

**The valve must be placed in the closed position immediately after steam sterilization for a short period (minimum 5 seconds). During commissioning, regularly check all sealing points for leaks. Replace defective seals and repeat the sterilization process.**

### 9.3 Passivation

Before commissioning a plant, passivation is commonly carried out for long pipes and tanks. Valve blocks are usually excepted from this.

Passivation is typically performed using nitric acid (HNO<sub>3</sub>) at approx. 80 °C (176 °F) at a concentration of 3 % and a contact time of 6 to 8 hours.

The ultimate temperatures, chemicals, concentrations and contact time to be used must be determined by the plant operator along with its chemical supplier.

## **10 Maintenance**

### **10.1 Safety instructions**

#### **Maintenance and repair**

Before carrying out maintenance and repair work on the component's electrical equipment, perform the following steps in accordance with the "5 safety rules":

- Isolate from the power supply
- Take appropriate measures to prevent switch on
- Test absence of voltage
- Earthing and short-circuiting
- Cover or safeguard any adjacent live parts.

For maintenance and repair, the following principles apply:

- Observe the intervals specified in the maintenance schedule.
- Only qualified personnel may carry out maintenance or repair work on the component.
- The component must be switched off and secured against being switched back on before maintenance or repair work. Work may only be started once any residual energy has been discharged.
- Block access for unauthorized persons. Put up notice signs which draw attention to the maintenance or repair work going on.
- Do not climb on the component. Use suitable access aids and working platforms.
- Wear suitable protective clothing.
- Only use suitable and undamaged tools to carry out maintenance work.
- When replacing parts only use approved, fully functional load lifting devices and lifting accessories which are suitable for the intended purpose.
- Before setting the unit back into operation, refit all safety devices as originally provided in the factory. Then check that all safety devices are working correctly.
- Make sure lubricants are used properly.
- Check pipes are firmly secured, also check for leaks and damage.
- Check that all emergency stop devices are working correctly.

#### **Disassembly**

For disassembly, the following principles apply:

- Only qualified personnel are allowed to dismantle the component.
- The component must be switched off and secured against being switched back on before it is dismantled. Work may only be started once any residual energy has been discharged.

- Disconnect all power and utility lines.
- Markings, e.g. on lines, must not be removed.
- Do not climb on the component. Use suitable access aids and working platforms.
- Mark the lines (if unmarked) prior to disassembly to ensure they are not confused when re-assembling.
- Protect open line ends with blind plugs against ingress of dirt.
- Pack sensitive parts separately.
- For longer periods of standstill, observe the storage conditions, see Section 4.1, Page 23.

## **10.2 Inspections**

Between the maintenance periods, the components must be checked for leakage and proper function.

### **10.2.1 Bellows**

Carry out the following steps:

1. Check the leakage cavity for soiling and continuous leakage of fluids.
- The bellows has been checked.

### **10.2.2 Piston rod seal**

Carry out the following steps:

1. Check the lantern for contamination and continuous leakage of fluids on the housing side.
- Piston rod seal is checked.

### **10.2.3 Pneumatic connections**

Carry out the following steps:

1. Check the operating pressure at the pressure reducing and filter station.
  2. Clean the air filter at regular intervals.
  3. Check that the air hoses sit firmly in the air connections.
  4. Check the lines for kinks and leaks.
- The pneumatic connection has been checked.

### **10.2.4 Electrical connections**

Carry out the following steps:

1. Check that the proximity switches are positioned correctly and the connections are clean.
- The electrical connection has been checked.

### **10.3 Maintenance intervals**

To ensure the highest operational reliability of the valve, all wearing parts should be replaced at longer intervals. Keep an adequate supply of all wearing parts (internal assemblies and seals) in your spare parts stock.





In practice, the actual maintenance intervals can only be determined by the user since they depend on the operating conditions.

Examples of relevant process parameters are:

- daily period of use,
- switching frequency,
- type and temperature of the product,
- type and temperature of the cleaning solution,
- ambient conditions.

If information regarding the definition of practical-oriented maintenance intervals is not available or is insufficient, the guideline values listed in the "Maintenance" chapter can be referred. This information is based on empirical values for GEA Flow Components and relates to installations working in two-shift operation.






## 10.4 List of tools






List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Pressurizing tool EA DN 25	 Fig.15	Valves EA DN 25 Inspection of metal bellows	0980.10060 S-12-0393
Pressurizing tool EA DN 40 - DN 100		Valves EA DN 40 - DN 100 Inspection of metal bellows	0980.10001 S-12-0313
Pressurizing tool EA DN 125		Valves EA DN 125 Inspection of metal bellows	0980.10113 S-12-0432
Torque wrench	 Fig.16	Assemble internal assembly EA & divisible valve disc	0980.50020 S-12-0086
Jaw insert SW13	 Fig.17	Side valve PA50	0980.50304
Jaw insert SW17	 Fig.18	Side valve PA60	0980.50306







List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Pressure control valve Ø 6 mm	 Fig.19	Inspection of metal bellows	9999.10090
Flexible head spanner Ø60-90mm, Pin Ø 5.5mm	 Fig.20	PA80-135 Remove/fit assembly spring	0980.10009 S-12-0332
Flexible head spanner Ø95-155mm, Pin Ø 6mm	 Fig.21	PA180-PA210 Remove/fit assembly spring	0980.50131 S-12-0568
Hand-operated press	 Fig.22	PA50 - 60 NC/NO Remove/fit PA	5050.55469 S-12-0406
the oven (no microwave, min. temp. 140 °C)	 Fig.23	Preheat hard valve seat seals	0981.50016 S-12-0084
Hex socket key AF5		Valves DN 10 - DN 65 Tighten/release clamp	0980.50121 S-12-0554

List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Hex socket key AF6	Fig.24	Valves DN 80 - DN 150 Tighten/release clamp	0980.50122 S-12-0555
Ratchet, square socket drive 1/2"	 Fig.25	Release divisible valve disks	0980.50124 S-12-0557
Mounting tool DN 25 DK TV	 Fig.26	DN 25 TV Loosen / tighten divisible valve disks	5050.53497 S12-0434
Mounting tool DN 40 + 50 DK TV		DN 40 + 50 TV Loosen / tighten divisible valve disks	5050.51255 S-12-0111
Mounting tool DN 65 + 80 DK TV	 Fig.27	DN 65 + 80 TV Loosen / tighten divisible valve disks	5050.51256 S-12-0024
Mounting tool DN 100 DK TV		DN 100 TV Loosen / tighten divisible valve disks	5050.51257 S-12-0102
Mounting tool Spring assembly PA100-180 EA	 Fig.28	PA100-180 EA Remove/insert spring package	0981.50015 S12-0211
Mounting tool Spring package PA210-255 EA		PA210-255 EA Remove/insert spring package	0981.50014 S12-0212



List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Mounting tool Bushing PA50-60 NC/NO	 Fig.29	Fit piston rod seal side valve Remove / fit PA50 - 60 (side valve)	5050.50988 S-12-0233
Mounting tool Clamping piece PA30-210	 Fig.30	PA30-210 Hold cylinder	5050.51064 S-12-0005
Mounting tool Clamping piece PA255	 Fig.31	PA255 Hold cylinder	5050.55468 S-12-0405
Mounting tool O-ring	 Fig.32	Remove/fit seals	5050.51258 S-12-0162
O-ring cutter heated	 Fig.33	Disassemble hard, shrunk valve seat seals	0980.50022 S-12-0083

List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Slotted screwdriver Size 1	 Fig.34	Remove piston seal (side valve) PA80 - PA255 Remove circlip from actuator base	--
Slotted screwdriver Size 4		PA80-255 Fit assembly spring	--
Spanner adapter SW10	 Fig.35	DN 25 EA Loosen / tighten internal assembly DN 25 EA TV Loosen / tighten divisible valve disks	0980.10153 S-12-0505
Spanner adapter SW13	 Fig.36	DN 40 - 100 EA Loosen / tighten internal assembly DN 40 EA TV Loosen / tighten divisible valve disks	5050.51604 S-12-0140
Spanner adapter AF17	 Fig.37	DN 50 - 65 EA TV Loosen / tighten divisible valve disks	5050.51605 S-12-0097
Spanner adapter SW30	 Fig.38	DN 80 - 125 EA TV Loosen / tighten divisible valve disks	5050.51606 S12-0107

List of tools (in alphabetical order)			
Tool	Figure	Intended Purpose	Material Number GEA Aseptomag AG
Vice with soft jaws or equivalent protective jaws	 Fig.39	For divisible internal assemblies and actuators	--
Protective gloves, heat-resistant	 Fig.40	Remove/fit hard valve seat seals	--
Seeger circlip pliers Inside diameter 40-100 mm, angled tip, 90°	 Fig.41	PA50 - 60 NC/NO Remove/fit PA	0980.50108 S-12-0541
Shut-off valve Ø 6 mm	 Fig.42	Inspection of metal bellows	9999.10091
Socket wrench bit AF14, square drive ½"	 Fig.43	DN 10 - 100 TV Release divisible valve disks	0980.00009 S-12-0663
Socket wrench bit AF17, square drive ½"	 Fig.44	DN 25 EA Loosen / tighten internal assembly	0980.00010 S-12-0664
Socket wrench bit AF22, square drive ½"		DN 50 - 100 EA Loosen / tighten internal assembly	0980.00011 S-12-0665

## 10.5 Prior to disassembly

Prerequisite:

- Make sure that while work is being performed on the open valve no process is in operation in the area concerned.

Carry out the following steps:

1. Drain all pipe system elements that lead to the valve and, if necessary, clean or rinse, and also depressurize them.
  2. Shut off the control air supply.
  3. Disconnect the power supply.
- Disassembly has been prepared.

## 10.6 Disassembling and Assembling the Valve

### 10.6.1 Dismantling and fitting the upper main valve

#### 10.6.1.1 Disassembling the Valve

Tools required:

- Hex socket key



#### **Caution!**

##### **Danger of injury due to spring force being released**

You can sustain injuries to your fingers when you put your hand into a valve if the valve has not been moved to the open position beforehand.

- ▶ Before starting any work, bring the valve to the "open" position.
- ▶ Wear protective gloves for all work.
- ▶ Always exercise caution and prudence.



#### **Caution!**

##### **Danger of injury due to media escaping after removing the clamp**

You can sustain injuries to your entire body if you open a valve that is still under pressure from the medium.

- ▶ Ensure that the valve is no longer under medium pressure before removing the clamp.
- ▶ Wear suitable protective clothing for all work.
- ▶ Always exercise caution and prudence.



#### **Hint!**

**The side valve version "UV" deviates from the side valve standard "AV" insofar as it has an additional valve housing, the "divert valve housing". The following work steps show both versions.**

Carry out the following steps:

1. Bring the valves to the "open" position.




Fig.45: Apply valves NC

2. Side valve UV: Side valve UV:




Fig.46: Separate pipe connection

! Ensure that all pipe connections to the divert valve housing have been removed before you carry out the next step.

3. Release the clamp of the side valve with a suitable hex socket key, but do not unhook the screw yet.

! For side valve of UV model, loosen only the clamp closer to the main valve.




Fig.47: Loosen clamp screw to the side valve

! Ensure that you can move the clamp by hand and without much effort before carrying out the next step. If this is not the case, carefully hit the clamp segments with a plastic mallet until the pressure is released and the clamp can easily be moved afterwards.

4. Secure the actuator of the side valve against sagging and falling down, and carefully remove the clamp from the side valve. Carefully remove side valve.  
! Do not damage the sealing surface on the valve body.




Fig.48: Remove side valve

5. Release the clamp of the main valve with a suitable hex socket key, but do not unhook the screw yet.




Fig.49: Loosening the clamp screw

! Ensure that you can move the clamp by hand and without much effort before carrying out the next step. If this is not the case, carefully hit the clamp segments with a plastic mallet until the pressure is released and the clamp can easily be moved afterwards.

6. Carefully take off the clamp from the valve.
7. Carefully lift the actuator with the internal assembly out of the housing.  
! Do not damage the sealing surface on the valve body.




Fig.50: Removing actuator and internal assembly

→ Internal assembly, actuator and side valves are now separated from the housing.

### 10.6.1.2 Assembling the Valve

Tools required:

- Hex socket key

Carry out the following steps:

1. Install the valve in the reverse order of disassembly, see Section 10.6.1.1, Page 44.

! Note "Torques for clamp", see Section 10.6.3, Page 53

2. Test the function of the valve after assembling.

! Every possible position must be activated and held for 3-5 seconds to assure proper assembly and sealing.

→ The valve has been assembled.

## 10.6.2 Dismantling and fitting the lower main valve

### 10.6.2.1 Disassembling the Valve

Tools required:

- Hex socket key

#### **Caution!**

#### **Danger of injury due to spring force being released**

You can sustain injuries to your fingers when you put your hand into a valve if the valve has not been moved to the open position beforehand.

- ▶ Before starting any work, bring the valve to the "open" position.
- ▶ Wear protective gloves for all work.
- ▶ Always exercise caution and prudence.

**⚠ Caution!**

**Danger of injury due to falling components**

The valve insert could drop out suddenly, causing injuries if the clamp is not loosened in the correct manner.

- ▶ Before loosening the clamp, secure the valve insert against falling.

**⚠ Caution!**

**Danger of injury due to media escaping after removing the clamp**

You can sustain injuries to your entire body if you open a valve that is still under pressure from the medium.

- ▶ Ensure that the valve is no longer under medium pressure before removing the clamp.
- ▶ Wear suitable protective clothing for all work.
- ▶ Always exercise caution and prudence.

**i Hint!**

**The side valve version “UV” deviates from the side valve standard “AV” insofar as it has an additional valve housing, the “divert valve housing”. The following work steps show both versions.**

Carry out the following steps:

1. Bring the valves to the "open" position.




Fig.51: Apply valves NC

2. Side valve UV: Side valve UV:






Fig.52: Separate pipe connection

! Ensure that all pipe connections for the divert valve housing have been removed before carrying out the next step.

3. Release the clamp of the side valve with a suitable hex socket key, but do not unhook the screw yet.

! For side valve of UV model, loosen only the clamp closer to the main valve.




Fig.53: Loosen clamp screw to the side valve

! Ensure that you can move the clamp by hand and without much effort before carrying out the next step. If this is not the case, carefully hit the clamp segments with a plastic mallet until the pressure is released and the clamp can easily be moved afterwards.

4. Secure the actuator of the side valve against sagging and falling down, and carefully remove the clamp from the side valve. Carefully remove side valve.

! Do not damage the sealing surface on the valve body.




Fig.54: Remove side valve



#### Hint!

**The side valves of the middle steam barrier are dismantled / mounted analogous to the side valves of the lower ISB represented here.**

5. Release the clamp of the main valve with a suitable hex socket key, but do not unhook the screw yet.




Fig.55: Loosening the clamp screw

**! Ensure that you can move the clamp by hand and without much effort before carrying out the next step. If this is not the case, carefully hit the clamp segments with a plastic mallet until the pressure is released and the clamp can easily be moved afterwards.**

6. Carefully take off the clamp from the valve.
7. Carefully lift the actuator with the internal assembly out of the housing.  
**! Do not damage the sealing surface on the valve body.**




Fig.56: Removing actuator and internal assembly

→ Internal assembly, actuator and side valves are now separated from the housing.

#### 10.6.2.2 Assembling the Valve

Tools required:

- Hex socket key

Carry out the following steps:

1. Install the valve in the reverse order of disassembly, see Section 10.6.2.1, Page 47.

**!** When attaching the clamp, tighten the screw only slightly. Make sure that the actuator and the internal assembly can be moved by hand without much effort.




Fig.57: Loosely attaching the clamp

2. Bring the valve to the "closed" position. Move the actuator and internal assembly by hand in all directions to centre the valve seat seal in the valve seat.




Fig.58: Centring the valve seat seal in the valve seat

3. Tighten the clamp screw. Then switch the valve 1-2 times and leave it in the "open" position. Tighten the screw again.  
! Note table "Torques for clamp", see Section 10.6.3, Page 53.




Fig.59: Centring and fastening the internal assembly

4. Test the function of the valve after assembling.  
! Every possible position must be activated and held for 3-5 seconds to assure proper assembly and sealing.  
→ The valve has been assembled.

#### 10.6.3 Torques for clamp

Clamp screw thread size	Recommended torque [Nm]
M6	10
M8	20

### 10.7 Disassemble and assemble the side valves

#### 10.7.1 Overview disassembly / assembly side valve

- Disassemble and assemble inside part (side valve) - versions "LVD" and "UV", see Section 10.7.2, Page 53.
- Disassemble and assemble piston rod seal (side valve) - version "LVD" and "UV", see Section 10.7.3, Page 55.
- Disassemble and assemble drive PA50/PA60 (side valve), see Section 10.7.4, Page 57.
- Disassemble and assemble valve seat seal (side valve) according to the valve seat seal of the main valve, see Section 10.9, Page 67.

#### 10.7.2 Disassemble and assemble inside part (side valve) - versions "LVD" and "UV"

##### 10.7.2.1 Disassemble piston rod seal (side valve) - versions "LVD" and "UV"

Requirement:

- The side valve cover has been separated from the housing, see Section 10.6.1.1, Page 44.

Tools required:

- Open-ended wrench

Carry out the following steps:

1. Bring the side valve to the "closed" position.
2. Screw valve axle out of the piston rod.

! If a temperature sensor is installed, unscrew it beforehand with care from the piston rod.




Fig.60: Releasing valve axis

3. Remove components of inside part:

→ Valve axle and valve cover for version LVD

→ Valve axle for version UV

Remove the housing seal without a tool.

! Do not damage sealing surface of valve cover / divert valve housing.




Fig.61: Remove components of inside part

→ The internal LVD has been disassembled.

4. Side valve UV: Loosen clamp with *Allen key* and remove.




Fig.62: Remove clamp

5. Side valve UV: Remove divert valve housing and valve cover. Remove the housing seal without a tool.

! Do not damage the sealing surfaces on the divert valve housing and on the valve cover.




Fig.63: Remove valve components

→ Inside part of UV has been disassembled.

#### 10.7.2.2 Assemble piston rod seal (side valve) - version "LVD" and "UV"



##### Hint!

**Pay attention to the following point when assembling the valve:**

- Thoroughly clean all parts and check for damage.

Tools required:

- Torque wrench with open-jawed spanner

Carry out the following steps:

1. Install the internal assembly in the reverse order of disassembly, see Section 10.7.2.1, Page 53.

! Grease well the valve axle of the inside part at the thread and 5 mm of the adjoining axle to prevent possible corrosion.

! Screw in the inside part by hand carefully and twisting slightly until the metallic stop into the piston rod of the pneumatic actuator, and tighten with *torque open-jawed spanner* to 40 Nm (15 Nm for actuator side valve PA50).

!Side valve UV: See table "Torques for clamp", see Section 10.6.3, Page 53.

→ The internal assembly has been assembled.

#### 10.7.3 Disassemble and assemble piston rod seal (side valve) - version "LVD" and "UV"

##### 10.7.3.1 Dismantling the piston rod seal – version "LVD" and "UV"

Prerequisite:

- Inside part side valve LVD or UV is dismantled, see Section 10.7.2.1, Page 53.

Tools required:

- Slotted screwdriver

Carry out the following steps:

1. Place the valve cover on a solid surface.
2. Position the tip of the slotted screwdriver in the groove of the inbuilt piston rod seal. Apply an even vertical downward pressure on the screwdriver. At the same time, move the rod inside using the thumb of the other hand, thereby pushing the seal out of the groove.

! Pay attention not to damage the surface of the groove.




Fig.64: Loosen the piston rod seal

3. Insert the slotted screwdriver in the generated gap between piston rod seal and valve cover and remove the seal from the groove using lever movement.

! Pay attention not to damage the surface of the groove.




Fig.65: Remove piston rod seal

→ Piston rod seal side valve is dismantled.

### 10.7.3.2 Fitting the piston rod seal – version "LVD" and "UV"



Tools required:

- Food-grade lubricant PARALIQ GTE 703
- Object with flat, smooth surface (the assembly tool sleeve depicted is recommended if available)
- New piston rod seal

Carry out the following steps:

1. Grease piston rod seal on the external surfaces with food-grade lubricating grease.
2. Position piston rod seal well centred above groove opening of the valve cover and put it on a solid, horizontal ground.




Fig.66: Position the piston rod seal

3. Position the flat object with the contact face downwards onto the piston rod seal. Using the palm of your hand, push the object all the way down in a straight line. The seal is inserted in the opening.

! Using your free hand, fix the valve cover and provide additional guidance for the flat object.




Fig.67: Insert piston rod seal

4. Using your thumbs, push the piston rod seal downwards in the opening simultaneously on both sides until it engages in the seal groove.

→ Piston rod seal side valve is installed.

#### 10.7.4 Disassemble and assemble actuator PA50/PA60 (side valve)

##### 10.7.4.1 Disassembling Actuator PA50/PA60

**Caution!****Danger of injury due to spring force being released**

You may be injured if the spring tension is released in an uncontrolled manner, causing actuator parts to be moved or thrown around rapidly.

- ▶ Load and unload the spring in a controlled and slow manner.
  - ▶ Wear protective gloves for all work.
  - ▶ Always exercise caution and prudence.
- 

Tools required:

- Hand-operated press
- Seeger circlip pliers
- Assembly tool bushing
- Assembly tool for O-ring

Carry out the following steps:

1. Using the bushing, press the base of the actuator downwards with the hand-operated press.




Fig.68: Lowering actuator base

2. Remove the circlip from the actuator base using the Seeger circlip pliers.




Fig.69: Removing the circlip

3. Slowly remove pressure from the actuator base.




Fig.70: Removing pressure from the actuator base

4. Lift off the actuator base from the cylinder.



Fig.71: Removing actuator base

5. Perform the following step in accordance with the actuator type:

- NC actuator: Lift out the piston rod with piston disc from the cylinder.
- NO actuator: Carefully draw the compression spring out of the cylinder.




Fig.72: Lifting out upper actuator components

6. Perform the following step in accordance with the actuator type:

- NC actuator: Carefully draw the compression spring out of the cylinder.
- NO actuator: Lift out the piston rod with piston disc from the cylinder.




Fig.73: Lifting out lower actuator components

7. Pull the circlip out of the groove and remove both parts of the lock washer from the piston rod.




Fig.74: Removing securing elements

8. Carefully slip off the spacer sleeve and piston disc from the piston rod.  
! Pay attention to the alignment of the piston disc (asymmetrical design) already when disassembling.




Fig.75: Pulling off actuator components

→ Actuator PA50/PA60 has been disassembled.

#### 10.7.4.2 Assembling Actuator PA50/PA60



##### Hint!

**Pay attention to the following points when assembling the actuator:**

- Replace all visible seals.
- Thoroughly clean and check the interior cylinder contact surfaces, O-ring grooves, piston rod and piston disc.
- When changing the seals, do not damage the seal groove.
- Use only replacement seals from the seal set indicated in the list of spare parts.
- Grease all seals and the associated contact surfaces with the food-grade lubricant PARALIQ GTE 703.

Carry out the following steps:

1. The actuator PA50/PA60 is assembled in the reverse order of disassembly, see Section 10.7.4.1, Page 57.



##### Hint!

**Seals in the product-contacting area are generally not lubricated. To facilitate assembly (better gliding properties and securing against turning), this type of elastomer seal may, however, be wetted using a food-grade lubricant.**

**! Wetting elastomer seals is not permitted when they are used in ATEX applications!**

→ Actuator PA50/PA60 has been assembled.

#### 10.8 Disassemble and assemble the internal assembly "EA"

### 10.8.1 Disassemble internal assembly "EA"



#### **Caution!**

##### **Danger of injury due to valve parts moved by compressed air!**

You can sustain injuries to your fingers when you put your hand into the valve while it is switching.

- ▶ Wear protective gloves for all work.
- ▶ Always exercise caution and prudence.

---

#### **Notice**

##### **Risk of damage to the metal bellow from torsion**

The metal bellow can get damaged, if forces other than those described in these assembly instructions are used on the internal assembly.

- ▶ Follow the instructions in this manual conscientiously.
  - ▶ Always exercise caution and prudence.
- 


Prerequisite:

- Internal assembly and actuator have been separated from the housing, see Section 10.6.1.1, Page 44

Tools required:

- Vice with smooth jaws or equivalent type of protected jaws
- Ratchet with square socket drive ½"
- Socket wrench bit
- Spanner adapter

Carry out the following steps:

1. Put the actuator in "closed" position (connection 1  D venting).
2. Clamp the pneumatic actuator at the width across flats of the piston rod into the vice.

! Do not damage piston rod!

## Maintenance

Disassemble and assemble the internal assembly "EA"

---





Fig.76: Clamping the actuator

3. Apply 6 bar of compressed air to connection 2  C of the actuator. Lift the circlip out of the groove and pull the lock washer out from the piston rod.




Fig.77: Removing securing elements

4. Position the spanner adapter with wrench socket at the width across flats of the internal assembly, loosen and carefully screw out from the piston rod of the pneumatic actuator.






Fig.78: Loosen internal assembly

5. Remove the housing seal without a tool.

! Do not damage the sealing surfaces on the housing and internal assembly.




Fig.79: Removing housing seal

→ The internal assembly has been disassembled.

### 10.8.2 Assemble internal assembly "EA"



#### Hint!

**Pay attention to the following points when assembling the internal assembly:**

- Thoroughly clean all parts and check for damage.
- Replace all dismantled seals.
- When changing the seals, do not damage the seal groove.
- Use only replacement seals from the seal set indicated in the list of spare parts.

Seals in the product-contacting area are generally not lubricated. To facilitate assembly (better gliding properties and securing against turning), this type of elastomer seal may, however, be wetted using a food-grade lubricant.

**! Wetting elastomer seals is not permitted when they are used in ATEX applications!**

---

Tools required:

## Maintenance

Disassemble and assemble the internal assembly "EA"

- Vice with smooth jaws or equivalent type of protected jaws
- Torque wrench with wrench socket
- Spanner adapter

Carry out the following steps:

1. Install the internal assembly in the reverse order of disassembly, see Section 10.8.1, Page 63.

! Grease well the valve axle of the inside part at the thread and 5 mm of the adjoining axle to prevent possible corrosion.

! Insert the inside part by hand carefully and twisting slightly until the metallic stop into the piston rod of the pneumatic actuator, and tighten with *torque wrench*.

! Note table "Torques for valve axes DK EA", see .

! Align the yoke opening of the bottom part of the actuator to the leakage socket of the internal assembly by turning the entire actuator. It is strictly forbidden to position forces at the internal assembly!




Fig.80: Align yoke opening with the leakage socket

→ The internal assembly has been assembled.

### 10.8.3 Torques for EA Valve Axes

Valve size	Thread size of valve axes	Torque [Nm]
DN25	M8 x 1	15
DN40	M12 x 1.25	40
DN50	M12 x 1.25	40
DN65	M12 x 1.25	40

Valve size	Thread size of valve axes	Torque [Nm]
DN80	M12 x 1.25	40
DN100	M12 x 1.25	40
DN125	M16 x 1.5	60

## 10.9 Removing and Installing the "Shrunk-on" Valve Seat Seal

### 10.9.1 Removing the Shrunk-on Valve Seat Seal

For information on valve seat seals, see Section 3.3, Page 21

Tools required:

- O-ring cutter
- Heat-resistant protective gloves

#### **Caution!**

##### **Health hazard due to toxic fumes!**

The O-ring cutter cuts the seal with a hot metal tip. At temperatures of more than 300 °C, toxic fumes can be released.

- Avoid directly inhaling the fumes.

#### **Caution!**

##### **Risk of injury due to hot and sharp-edged parts!**

The O-ring cutter cuts the seal with a hot metal tip. This process heats up the seal and possibly also metal parts of the valve.

- When removing the valve seat seal always wear heat-resistant protective gloves.

Carry out the following steps:

1. Place the heated metal tip of the O-ring cutter at right angles on the valve seat seal to be removed.
2. Cut through the valve seat seal at one point using the O-ring cutter.

! Pay attention not to damage the edge of the radial groove.



Fig.81: Cut through valve seat seal

3. Take out the cut valve seat seal.

→ The valve seat seal has been removed.

#### 10.9.2 Fitting the "Shrink-on Fit" Valve Seat Seal

---



##### Hint!

**Pay attention to the following points when assembling the valve seat seal:**

- Thoroughly clean all parts and check for damage.
- Replace all dismantled seals.
- When changing the seals, do not damage the seal groove.
- Use only replacement seals from the seal set indicated in the list of spare parts.

**! Valve seat seals made of hard sealing materials must not be greased!**

---

Tools required:

- Oven (no microwave)
- Heat-resistant protective gloves

Carry out the following steps:

1. Heat new valve seat seal *in oven* .
  - Temperature: 140 °C (guideline value)
  - Time: 3 - 5 minutes (guideline value)

**! Ensure that the seal can be deformed along the circumference without much effort. The required heating time depends on the respective *oven* and can vary accordingly.**



Fig.82: Oven

2. Use both thumbs to press the heated valve seat seal into the radial groove at one point.




Fig.83: Place the valve seat seal into the groove

3. Then use both thumbs/palms to press the valve seat seal in place in the radial groove.

! Make sure the valve seat seal "clicks" into the radial groove. The audible clicking noise indicates that the seal has been fitted correctly.

! The valve may not be totally leak-proof after a new TEFASEP® valve seat seal has been fitted. The valve seat seal will adjust itself optimally to the sealing surfaces only after the first sterilisation of the valve (see Chapter 9, Page 33). Afterwards it will ensure perfect sealing up to the maximum closing pressure or vacuum.



Fig.84: Mounting the valve seat seal

- The valve seat seal is still too rigid and cannot be mounted?
  - Reheat the valve seat seal as described in the previous instruction step.
- When mounting the valve seat seal, the seal does not "click" into place any more?

The valve seat seal has been overheated and can no longer be used.

  - Repeat the operation with a new valve seat seal.
  - Observe the data specified for heating the valve seat seal.
- The valve seat seal has been fitted.

## 10.10 Removing and Installing the "Divisible System" Valve Seat Seal

### 10.10.1 Disassemble the valve seat seal "system divisible" - valve version "EA"

#### Notice

##### **Risk of damage to the metal bellow from torsion**

The metal bellow can get damaged, if forces other than those described in these assembly instructions are used on the internal assembly.

- ▶ Follow the instructions in this manual conscientiously.
- ▶ Always exercise caution and prudence.

For information on valve seat seals see Section 3.3, Page 21.

Tools required:

- Ratchet with square socket drive  $\frac{1}{2}$ "
- Socket wrench bit
- Spanner adapter
- Assembly tool DK TV
- Vice

Carry out the following steps:

1. Clamp assembly tool in vice. Push the internal assembly at the socket surface of the valve disc into the assembly tool. Position the spanner adapter on the nut of the valve disc.




Fig.85: Clamping internal assembly

2. Place the ratchet with the wrench socket on the spanner adapter and loosen the nut of the valve disc.




Fig.86: Loosen the nut of the valve disc

3. Remove the seals from the internal assembly:

- Valve disc seal on version TVT (1)
- Seat seal (2)




Fig.87: Remove seal

TVT	Divisible valve disc, valve seat seal TEFASEP
TVE	Divisible valve disc, valve seat seal EPDM (form seal)

→ The valve seat seal has been removed.

### 10.10.2 Assemble the valve seat seal “system divisible” - valve version “EA”

Tools required:

- Torque wrench with wrench socket
- Spanner adapter
- Assembly tool DK TV
- Vice
- Food-grade lubricant PARALIQ GTE 703

Carry out the following steps:

1. The screwed-on valve seat seal is fitted in the reverse order of removal, see Section 10.10.1, Page 70.

! Prepare thermoplastic valve seat seals (TEFASEP, PTFE, ...) in the heater, see Section 10.9.2, Page 68.

! Valve seat seals made of hard sealing materials must not be greased.

! A light film of food-grade lubricant must be applied to elastomer valve seat seals before fitting.

! Note table "Torques for divisible valve discs", see Section 10.10.2, Page 71.

→ The valve seat seal has been fitted.

**Hint!**

**Wetting elastomer seals is not permitted when they are used in ATEX applications!**

**10.10.3 Torques for divisible valve discs**

Valve size	Thread size of valve disc	Torque [Nm]
DN25	M8 x 1	20
DN40	M10 x 1.25	50
DN50	M12 x 1.25	60
DN65	M12 x 1.25	60
DN80	M12 x 1.25	60
DN100	M12 x 1.25	60
DN125	M20 x 1.5	100

**10.11 Carrying out the "Internal Assembly" Leak Test (Bubble Test)****10.11.1 Bubble test valve version "EA"****Hint!**

**Observe the inspection interval! The metal bellows must be checked for leaks as part of the annual maintenance using the pressurizing tool.**

**Notice****Risk of damage to the metal bellow from torsion**

The metal bellow can get damaged, if forces other than those described in these assembly instructions are used on the internal assembly.

- Follow the instructions in this manual conscientiously.
- Always exercise caution and prudence.

Tools required:

- Pressurizing tool EA
- Compressed air supply
- Shut-off valve Ø 6 mm
- Pressure regulating valve Ø 6 mm
- Water bath



Carry out the following steps:

1. Screw on the pressurizing tool manually until the stop.



Fig.88: Screw on the pressurizing tool.

2. Loosen the pressurizing tool until leakage socket of internal assembly lies in opening.



Fig.89: Align opening with the leakage socket

3. Tighten adapter G1/4" by hand with internal assembly



Fig.90: Screw adapter

4. Apply max. 3 bar of compressed air to the pressurizing tool.  
! Air pressures > 3 bar can damage the metal bellows.
5. Immerse the internal assembly in a water bath for approx. 30 seconds.  
! While the internal assembly is immersed, check the internal assembly for leaks. Leakages will be indicated by air bubbles appearing on the surface.




Fig.91: Water bath

6. Remove the internal assembly from the pressurizing tool in reverse order.  
→ This completes the leak test.

## 10.12 Disassembling and Assembling Actuator PA80EA - PA255EA

### 10.12.1 Disassembling Actuator PA80EA - PA255EA

Tools required:

- Flexible head spanner
- Slotted screwdriver
- Assembly tool for clamping device
- Assembly tool for spring assembly
- Assembly tool for O-ring
- Vice

#### **Preparing disassembly**

Carry out the following steps:

1. Bring the actuator to the non-actuated position.
2. Remove the feedback unit.
3. Attach the clamping device assembly tool to the back of the actuator.



Fig.92: Attaching clamping piece

4. Grip the actuator in the vice using the clamping piece.




Fig.93: Clamping the actuator

→ Disassembly has been prepared

**Removing assembly spring**

Carry out the following steps:

1. Turn the actuator base counter-clockwise using a flexible head spanner, see illustration.

! Rotate the actuator base until the assembly spring begins to move out of the slot in the cylinder.




Fig.94: Releasing assembly spring

2. Turn the actuator base clockwise using the flexible head spanner.

! Rotate the actuator base until the assembly spring can be removed.




Fig.95: Unscrewing assembly spring

→ Assembly spring has been removed.

**PA80EA - PA255EA: dismantling the actuator**

Carry out the following steps:

1. Lift off the actuator base from the cylinder.



Fig.96: Removing actuator base

2. Pull the spring assembly upwards at the piston rod out of the cylinder.



Fig.97: Lifting out top spring assembly

3. Use the assembly tool for the spring assembly to pull the bottom spring assembly upwards out of the cylinder.



Fig.98: Lifting out bottom spring assembly

4. Lift the circlip out of the groove with a slotted screwdriver and remove it.




Fig.99: Removing circlip

5. Take the buffer segments out of the actuator base.



Fig.100: Removing securing elements

6. Lift the piston disc out of the actuator base.




Fig.101: Lifting out the piston disc

→ Actuator has been dismantled into its individual parts.

! Opening the spring assembly is not recommended for safety reasons.

→ Actuator PA80EA - PA255EA has been disassembled.

### 10.12.2 Assembling Actuator PA80EA - PA255EA

---



#### **Hint!**

**Pay attention to the following points when assembling the actuator:**

- Replace all visible seals.
- Thoroughly clean and check the interior cylinder contact surfaces, O-ring grooves, piston rod and piston disc.
- When changing the seals, do not damage the seal groove.
- Use only replacement seals from the seal set indicated in the list of spare parts.
- Grease all seals and the associated contact surfaces with the food-grade lubricant PARALIQ GTE 703.

---

#### **PA80EA - PA255EA: assembling the actuator**

Carry out the following steps:

1. Assemble the actuator in the reverse order of disassembly, see Section 10.12.1, Page 74.

→ Actuator has been assembled.

#### **Installing the assembly spring**

Tools required:

- Flexible head spanner
- Slotted screwdriver

Carry out the following steps:

1. Align the actuator base relative to the cylinder housing so that the hole in the base is visible through the slot in the cylinder.




Fig.102: Aligning hole to slot

2. Insert the angled part of the assembly spring into the hole of the actuator base.




Fig.103: Hooking in the assembly spring

3. Turn the actuator base 360° counter-clockwise using a flexible head spanner.  
→ The assembly spring is pulled into the cylinder.




Fig.104: Screwing in the assembly spring

4. As soon as both open ends of the assembly spring are visible in the slot area, the beginning of the assembly spring must be pressed into the hole in the actuator base with a slotted screwdriver.  
! Carefully continue to turn the actuator base at the same time.




Fig.105: Fastening the assembly spring

- The assembly spring moves out of the hole when it reaches the slot in the cylinder and actuator base was turned further?

- Continue to turn the actuator base counter-clockwise using the flexible head spanner until the hole is again located underneath the position pin of the assembly spring and the pin can be pressed in again with the slotted screwdriver.
5. Position the compressed air connection centrally over the slot in the cylinder.



Fig.106: Placing the air connection

- Assembly spring has been fitted.
- Actuator PA80EA - PA255EA has been assembled.

### 10.13 Maintenance

Well-planned maintenance is essential to ensure a long service life of the valve. Observe the following maintenance intervals. Prepare maintenance activities well:

- Keep a maintenance log for the valve.
  - Use the statistical analyses for your plant to plan maintenance intervals.
- Only allow qualified maintenance staff to carry out maintenance work.



#### Hint!

**Prior to any work on the open valve, ensure that it has stopped operation, see Section 10.5, Page 44.**

The following information and values are based on the experience of GEA Aseptomag AG and apply for installations working in 2-shift operation.

Activities to be performed once a month	
Component	Activity to be performed
Valve	Visual inspection

Activities to be performed after 3 months (only after initial commissioning or after a process change)	
Component	Activity to be performed
Product contact seals	Check of mechanical parts and visual inspection of condition
Internal assembly with bellows	Check of mechanical parts and visual inspection of condition Leak test of bellows (bubble test)



Activities to be performed after 3 months (only after initial commissioning or after a process change)	
Component	Activity to be performed
Actuator	Function check
Valve	Function check
Feedback	Function check
Pneumatic connections	Check of mechanical parts and visual inspection of condition Leak test
Electrical connections	Visual inspection

Activities to be performed once a year	
Component	Activity to be performed
Product contact seals	Seal replacement
Internal assembly with bellows	Check of mechanical parts and visual inspection of condition Leak test of bellows (bubble test)
Actuator	Check of mechanical parts and visual inspection of condition Function check
Valve	Check of mechanical parts and visual inspection of condition Function check
Feedback	Check of mechanical parts and visual inspection of condition Function check
Pneumatic connections	Check of mechanical parts and visual inspection of condition Leak test
Electrical connections	Check of mechanical parts and visual inspection of condition

Activities to be performed every 5 years	
Component	Activity to be performed
Actuator	Maintenance including seal replacement

## 10.14 Checking the Feedback Unit

After completing maintenance work, check the function of the feedback unit and readjust it if necessary.

### 10.14.1 Setting the Feedback Unit

Carry out the following steps:

1. Set the initiator for detection of the rest position.
2. Actuate the valve with compressed air.

→ For information on air connections see Section 6.4, Page 28.

If provided, adjust the initiator for the actuated position. For reference regarding the stroke to be expected see the "Valve Stroke" table Section 10.14.2, Page 82.

→ The feedback unit has been set.



#### Hint!

**If a control top is present, the information provided in the corresponding instruction manual must be observed.**

### 10.14.2 Valve Stroke

Strokes depending on the size (basic, theoretical values on drawing)				
Size	Valve stroke [mm]			
	Total stroke	Seat venting		Side valve
		Seat A / C	Seat B / D	
DN25 / 1"OD	5.5	1.5	1.5	5.5
DN40 / 1½"OD	10	1.5	1.5	24.5
DN50 / 2"OD	13.5	1.5	1.5	24.5
DN65 / 2½"OD	16.5	1.5	1.5	24.5
DN80 / 3"OD	23	2.5	1.5	24.5
DN100 / 4"OD	23	1.5	1.5	24.5
DN125	33.5	1.5	1.5	24.5

## 11 Alarms

### 11.1 Malfunctions and remedies

#### Notice

#### **Warning of damage to property/loss of product**

Ignoring malfunctions may cause considerable damage to property and loss of product. The safe operation of the valve in the event of a malfunction can no longer be taken for granted and in the worst case can result in a loss of sterility in the process.

► Make sure that malfunctions are quickly identified and promptly fixed.

In the event of malfunctions, immediately deactivate the valve and secure it against inadvertent reactivation. Malfunctions may only be remedied by qualified staff, who must observe the safety precautions. For malfunctions not listed in the table below, contact the manufacturer.

Malfunction	Cause	Remedy
Medium is leaking from the clamp.	The housing seal is not fitted correctly or damaged.	Fit the housing seal correctly or replace it if damaged.
Medium is leaking from the leakage holes of the internal assembly.	The bellows at the internal assembly is defective due to pressure shocks or cavitation.	<ul style="list-style-type: none"> <li>• Replace the complete internal assembly.</li> <li>• Send the defective internal assembly to the manufacturer for repair.</li> <li>• Check process.</li> </ul>
Medium leaks from leakage hole of the side valve.	<ul style="list-style-type: none"> <li>• Medium originates from product side: piston rod seal leaks.</li> <li>• Medium originates from actuator: actuator seals leak.</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the seals.</li> <li>• Check seal running surfaces.</li> </ul>
During pressure testing of the internal assembly, air escapes from the metal bellows.	The bellows on the internal assembly are defective.	<ul style="list-style-type: none"> <li>• Replace the complete internal assembly.</li> <li>• Send the defective internal assembly to the manufacturer for repair.</li> </ul>
Leak at the valve seat.	<ul style="list-style-type: none"> <li>• The valve seat seal is not fitted correctly or damaged.</li> <li>• Product deposits on the valve seat.</li> </ul>	<ul style="list-style-type: none"> <li>• Fit the valve seat seal correctly or replace it if damaged.</li> <li>• Check the housing.</li> </ul>

Malfunction	Cause	Remedy
The maximum valve stroke is not reached when the valve is actuated pneumatically.	Leakage in the actuator.	<ul style="list-style-type: none"> <li>• Check the sealing surfaces in the actuator for damage.</li> <li>• Replace the seals.</li> </ul>
Valve feedback not correct.	<ul style="list-style-type: none"> <li>• The feedback unit is not fitted correctly.</li> <li>• The proximity switch is not in the correct position or is defective.</li> <li>• Fault in the power supply.</li> </ul>	<ul style="list-style-type: none"> <li>• Check that the feedback unit has been fitted correctly.</li> <li>• Check the position of the proximity switch and re-adjust if necessary.</li> <li>• Check the wiring.</li> </ul>
Actuator is filling with water.	<ul style="list-style-type: none"> <li>• Unfavourable fitting position of the vent screw on the actuator.</li> <li>• Unfavourable effect of the exterior cleaning of the plant.</li> </ul>	<ul style="list-style-type: none"> <li>• If possible, position the vent screw so that it faces downwards.</li> <li>• When the valve is installed in the vertical position, ensure that the vent screw faces away from the cleaning direction if possible.</li> </ul>
The TEFASEP valve seat seal is not tight after commissioning or maintenance.	<ul style="list-style-type: none"> <li>• The valve seat seal has not been fitted correctly.</li> <li>• With new seal: The valve has not been actuated during/immediately after sterilization.</li> </ul>	<ul style="list-style-type: none"> <li>• Fit the valve seat seal properly.</li> <li>• Actuate the valve during/immediately after sterilisation.</li> </ul>

## **12 Decommissioning**

### **12.1 Safety instructions**

For shutting down, the following principles apply:

- Switch off the compressed air.
- Switch off the component with the main switch.
- Padlock the main switch (if fitted) in the off position to prevent it from being switched back on. The key to the padlock must be deposited with the person responsible until the machine is restarted.
- For longer periods of standstill, observe the storage conditions, see Chapter 4, Page 23.

### **12.2 Disposal**

#### **12.2.1 General notes**

Dispose of the component in an environmentally safe manner. Observe the statutory waste disposal regulations applicable at the place of installation.

The component consists of the following materials:

- Metals
- Synthetic materials
- Electronic parts
- Lubricants containing oil and grease

Separate the different materials and dispose of them correctly sorted. Also observe the instructions regarding disposal in the operating instructions for the individual components.

## 13 Appendix

### 13.1 Lists

#### 13.1.1 Abbreviations and terms

Abbreviation	Explanation
°	Symbol for the grade of a scale [degrees] All degree data is assumed to be angle degrees unless explicitly specified otherwise.
°C	Unit of measurement of temperature [degree Celsius]
°F	Unit of measurement of temperature [degree Fahrenheit]
AISI	American Iron and Steel Institute; material designation
ATEX	Atmosphères Explosibles Directive of the European Union on explosion protections
bar	Unit of measurement of pressure [bar] All pressure data is assumed to be gauge pressure [barg] unless explicitly specified otherwise.
CFR	Code of Federal Regulations; collection of US federal regulations
DIN	German standard issued by DIN (Deutsches Institut für Normung e.V., German Institute for Standardisation)
dm <sup>3</sup>	Unit of measurement of volume [cubic decimetre]
DN	DIN nominal width
EA	Singe ventilation of both valve seats
EN	European Standard
EPDM	Ethylene Propylene Diene Rubber Material designation, short designation according to DIN/ISO 1629
FDA	U.S. Food and Drug Administration Food monitoring and drug administration in the USA
FEP	Fluorinated ethylene propylene; material designation, short name
H <sub>2</sub> O <sub>2</sub>	Hydrogen peroxide; chemical formula
ISB	Integrated Steam Barrier
ISO	International Organisation for Standardisation
ACSC	Air-closing/spring-opening; direction of action air
LVD	Loose valve cover; components on valve version with separable valve axle
m/s	Unit of measurement of speed/velocity [metres per second]
min.	Unit of measurement of time [minute]
mm	Unit of measurement of length [millimetre]
µm	Unit of measurement of length [micrometre]

Abbreviation	Explanation
NC	Normally Closed; direction of action spring-closing/air-opening
Nm	Unit of measurement of work [newton metre] Unit of torque 1 Nm = 0.737 lbft Pound-Force (lb) + Feet (ft)
NO	normally open; direction of action air-closing/spring-opening
OD	Outside diameter; short name for outside diameter for inch tubes according to DIN 11866-C
PA	Pneumatic actuator
PTFE	Polytetrafluoroethylene Material designation, short designation according to DIN/ISO 1629
SW	Width across flats; indicates the size of spanners
T.VIS	Tuchenhagen Valve Information System
TEFASEP	Sealing material for the valve seat seal
TV	Divisible valve disc; to valve seat seal system "divisible"
TIG	Tungsten inert gas welding

## We live our values.

Excellence · Passion · Integrity · Responsibility · GEA-versity

GEA Group is a global engineering company with multi-billion euro sales and operations in more than 50 countries. Founded in 1881, the company is one of the largest providers of innovative equipment and process technology. GEA Group is listed in the STOXX® Europe 600 Index.

### GEA Switzerland

GEA Aseptomag AG  
Industrie Neuhof 28  
CH-3422 Kirchberg

Tel +41 (0)34 426 29 29  
Fax +41 (0)34 426 29 28

[service.aseptomag@gea.com](mailto:service.aseptomag@gea.com)  
[gea.com](http://gea.com)