

HYGIANA III/III Adapta®

Operating manual

Translation of the original operating manual

BA.001.ADY.001.09.16.GB

**EC - Declaration of conformity for machines
in accordance with EC Machinery Directive 2006/42 /EC, Annex II 1. A**

Manufacturer: **HILGE GmbH & Co. KG
Hilgestraße 37-47
55294 Bodenheim, Germany**

We, as manufacturer, declare in sole responsibility that the machinery

Product: Centrifugal pump

Model: HYGIANA

Series Adapta®

complies to all relevant provisions of this and the following directives:

Relevant EC Regulations: 2006/42/EC EC Machinery Directive

Applied harmonized standards, in particular: EN 809:1998/A1+AC(D)
EN ISO 12100:2010

Remarks: We also declare that the special technical documentation for this incomplete machine has been created in accordance with Annex VII, Part B and we obligate to provide these upon reasoned request from the individual national authorities by data transfer.

Authorized person for compiling and handing over technical documentation:

**HILGE GmbH & Co.KG
Dr. Boris Kneip
Hilgestraße 37-47
55294 Bodenheim, Germany**

Bodenheim, 16 September 2016

i.v. B. Kneip

Dr. Boris Kneip
Development & Engineering Manager

1 Introduction	5
1.1 Target group	5
1.2 Symbols and formatting	5
1.3 References to the document	5
2 Safety	5
2.1 Operator notes	5
2.1.1 Unpacking the pump	5
2.1.2 Storing the pump	5
2.2 Safety instructions in the operating manual	5
2.3 Identification of instructions in the operating manual	6
2.3.1 Structure of safety instructions	6
2.4 Qualification and training of personnel	6
2.5 Dangers caused by failure to follow the safety instructions	6
2.6 Safety-conscious work	6
2.7 Safety instructions for the operator/user	6
2.8 Unauthorised modifications and spare parts	7
2.9 Improper operation	7
2.10 Transport	7
2.11 Cleaning	7
2.11.1 CIP	7
2.11.2 SIP	8
2.12 Repair contract	8
3 Product description	9
3.1 Pump overview	9
3.2 Description	9
3.2.1 Areas of application	9
3.3 Proper usage	9
3.3.1 Pumped liquids	9
3.3.2 Minimum flow rate, Q _{min}	9
3.3.3 Connections and pipelines	9
3.3.4 Motor operation	9
3.3.5 Design	9
3.4 Technical data	10
3.4.1 Type key	10
3.4.2 Pump serial number	10
3.4.3 Nameplate	10
3.4.4 Performance data	10
3.4.5 Noise emissions	10
3.4.6 Weights	10
3.4.7 Maximum operating temperatures	11
3.4.8 Maximum operating pressure	11
4 Mounting, installation and connection	11
4.1 Inspection before pump installation	11
4.1.1 How to check free running of the impeller	11
4.2 Set-up and alignment of the pump	12
4.3 Installation in the pipeline	12
4.3.1 Operation of the mechanical seal	12
4.3.2 Space requirements	13
4.3.3 Reduction of noise and vibration	13
4.4 Connection of flushing system	14
4.4.1 Double mechanical seal, back-to-back arrangement	14
4.4.2 Double mechanical seal - tandem arrangement	14
4.5 Electrical connections	14
4.5.1 Star connection	15
4.5.2 Delta connection	15
4.5.3 Frequency converter operation	15
4.5.4 Checking the direction of rotation after connection	15
5 Start-up / shut-down	16
5.1 Start-up	16
5.1.1 Check application conditions	16
5.1.2 Starting up the pump	16
5.1.3 Functional check of the mechanical seal	16

5.2 Shutting down the pump	16
5.2.1 Cleaning the pump after shut-down	16
6 Maintenance/servicing	17
6.1 Safety instructions for installation, inspection and maintenance work	17
6.2 Maintenance of the pump	17
6.3 Maintenance of the motor	17
6.3.1 Motors without lubrication fittings	17
6.3.2 Motors with lubrication fittings	17
6.4 Maintenance of the Adapta® bearing housing	18
6.4.1 Bearing housing	18
6.4.2 Design of bearing housing, sizes 1 and 2	18
6.4.3 Design of bearing housing, size 3	18
6.5 Assembly	18
6.5.1 Parts overview	19
6.5.2 Bearing housing, sizes 1 and 2	19
6.5.3 Bearing housing, size 3	21
6.5.4 Coupling and motor	22
6.5.5 Instructions for disassembly	22
6.5.6 Instructions for assembly	22
6.5.7 Assembly of the bearing housing, sizes 1 and 2	23
6.5.8 Assembly the bearing housing, size 3	26
6.5.9 Mechanical seal arrangements	30
6.5.10 Assembly of the single mechanical seal	30
6.5.11 Assembly of impellers and casings	32
6.6 Troubleshooting	35
6.7 Disposal	35
6.8 HILGE assembly tool kit	36
6.8.1 Content and use	36
7 Certificate of non-objection	37

1 Introduction

Overview

This section describes the requirements that are important for reading and understanding this operating manual. The symbols and formats that make the reading easier are also described.

1.1 Target group

This operating manual is intended for:

- the operators of the pump
- maintenance and repair personnel.

It is assumed that all such personnel will have the basic technical background required for the start-up, maintenance, and repair of pump systems.

Sections intended only for specially authorised personnel are indicated by a preceding notation to this effect.

1.2 Symbols and formatting

The following symbols and formats are intended to make it easier to read this document:

- enumerations and listed items.

- Instructions

Instructions that must be carried out in a specific sequence are numbered in the corresponding order.

- Safety instructions

The system used to identify safety instructions is described in section 2.3 on page 6.

1.3 References to the document

- Copyright

This document may not be copied, translated into other languages, or made available to third parties without our explicit written consent.

- Technical changes

Design variants, technical data, and spare part numbers are subject to technical changes.

We reserve the right to make changes for the sake of further technical development.

2 Safety

Overview

This section describes what you have to consider for your own safety. Read this important section attentively and follow the instructions!

2.1 Operator notes

2.1.1 Unpacking the pump

In order to avoid transport damage, all of our pumps are professionally packed when they leave our warehouse.

If, after carefully unpacking and closely reviewing the shipment, you nevertheless detect damage, please immediately inform the transporter (railway, post office, freight forwarder, shipping company). Please file your damage claim with them. The transport risk is assumed by the customer as soon as the shipment leaves our warehouse.

2.1.2 Storing the pump

If you do not use the pump straight away, correct storage conditions are just as important as careful installation and appropriate maintenance in order to ensure smooth subsequent operation. The pump should be protected against cold, moisture and dust, and should also be shielded against mechanical impacts.

Trained personnel are required for proper installation and maintenance.

2.2 Safety instructions in the operating manual

Read all safety instructions!

The operating manual contains all the basic information required for the set-up, operation, and maintenance of the pump. The installer as well as the technical personnel or operator responsible for the pump must therefore read this operating manual before installing and starting the pump. The operating manual must always be available at the site where the pump/system is used.

The general safety instructions presented in this section as well as the specific safety instructions in later sections must be followed.

2.3 Identification of instructions in the operating manual

Symbols

The safety instructions presented in this operating manual are identified as shown below.



Fig. 1: Symbols for safety instructions

Signal words

The following signal words are used to classify the safety instructions:

DANGER (A)

Characterises an imminent hazard with a high risk which can cause death or serious bodily injury.

WARNING (B)

Characterises a possible hazard with a medium risk which can cause death or bodily injury if it is not avoided.

CAUTION (C)

Characterises a hazard with a minor risk which can cause minor or medium-level bodily injury if it is not avoided.

Do not remove instructions from pump

Instructions attached directly to the pump, such as a direction-of-rotation arrow, must be noted and kept in completely legible condition.

Damaged or illegible instructions must be replaced.

2.3.1 Structure of safety instructions

The safety instructions are structured as follows and use the symbols and signal words shown here:



SIGNAL WORD

Description of danger!

- ▲ Possible consequence.
- ▶ Action to eliminate the danger.

Example:



DANGER

Electric shock if electrical parts are touched!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Before attempting to diagnose any fault, make sure that the main switch has been switched off. It must be ensured that the power supply cannot be accidentally switched on.

2.4 Qualification and training of personnel

The employees operating, maintaining, inspecting, and installing the pump must have the appropriate qualifications for this work. The operator must define in detail the tasks for which the employees are responsible, the tasks of which they are in charge, and the manner in which they are supervised.

If the employees do not have the necessary knowledge, they must be instructed and trained accordingly. This can be done, if

necessary, by the manufacturer/supplier under contract to the operator. The operator must also ensure that the employees fully understand the contents of the operating manual.

2.5 Dangers caused by failure to follow the safety instructions

If these safety instructions are not followed, employees, the pump and the environment will be in danger.

Failure to follow the safety instructions can lead to the loss of the right to file claims for damages.

Failure to follow instructions can, for example, lead to the following hazards:

- breakdown of important functions of the pump/system
- failure of recommended methods of maintenance and repair
- endangerment of personnel by electrical, mechanical, and chemical hazards
- endangerment of the environment by leakage of hazardous materials.

2.6 Safety-conscious work

The safety instructions given in this operating manual, the existing national regulations for accident prevention, and any applicable internal working, operating, and safety instructions of the operator must be followed.

2.7 Safety instructions for the operator/user



WARNING

Hot or cold mechanical components!

- ▲ Serious bodily injury.
- ▶ Take structural measures to prevent contact with them!



WARNING

Trapping hazard!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Do not remove protection against contact with moving parts (e.g. coupling guard) while the pump is in operation.
- ▶ Replace defective safety equipment immediately.



WARNING

Contact with hazardous substances (e.g. inhalation)!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Drain away leakage of hazardous pumped liquids in such a way that there is no danger to personnel or to the environment.
- ▶ Follow legal regulations.
- ▶ If shaft seal fails, switch off the pump. Replace seal before next start-up.



WARNING

Tripping hazard from electric power cable!

- ▲ Death, serious bodily injury.
- ▶ Route the electric power cable in such a way that no one can trip over it (in case of portable pumps).



WARNING

Electrical hazard!

- ▲ Death, serious bodily injury.
- ▶ Use only approved electric cables and plugs.

2.8 Unauthorised modifications and spare parts

No modifications or changes to the pump may be made without the written approval of the manufacturer. In the interest of safety, only original spare parts and accessories authorised by the manufacturer may be used. The use of other parts can exempt the manufacturer from liability for damage.

2.9 Improper operation

The operational reliability of the pump can be guaranteed only when it is used properly, as indicated in the relevant sections of the pump operating manual and the order papers.

The given limit values may not be exceeded under any circumstances.

2.10 Transport



WARNING

Falling loads!


- ▲ Death, serious bodily injury, damage to property.
- ▶ Transport work must only be performed by appropriately qualified persons, and all safety instructions must be observed.
- ▶ Use suitable load carrying equipment with sufficient capacity to transport the pump.
- ▶ Make certain there are no persons under the suspended load.
- ▶ Make certain the pump is aligned horizontally when it is lifted.



CAUTION

Incorrect lifting points!

- ▲ Damage to property.
- ▶ Fasten the rope to suitable lifting points.
- ▶ Never fasten a rope to the pump housing or suction/discharge port.
- ▶ If pump is equipped with shroud, remove shroud before transporting.



TM05 6441 4712

Fig. 2: Attachment points (example)

2.11 Cleaning

To ensure the quality of sensitive liquids, pumps must be cleaned immediately after each use. Only this will remove adhesions and sedimentary deposition and avoid the contamination of products. To reach the best possible cleaning result, Hilge pumps are optimised with regard to gaps and dead spaces. They are designed in accordance with DIN EN 13951, and they are resistant to the detergents mentioned below. The cleaning happens inside the plant, without the need for disassembly or removal of parts.

Generally, distinction is made between CIP and SIP. The procedures must be based on state-of-the-art technology and guidelines of the EC. In every case the user must make sure that the cleaning and/or sterilisation processes used as well as the operating temperature and operating steps meet the targets set and are used for that purpose.

2.11.1 CIP

CIP means Cleaning In Place. The pump is completely flushed through with a detergent. The detergent used must be suitable for the cleaning task in question. The following table shows permitted detergents, their allowed concentration and specifications according to DIN 11 483 part 1.

Type of detergent	Chemical description	Max. concentration	Max. temperature* [°C]	Permitted pH value	Max. permitted Cl content when mixed with water [mg/l]	Max. permitted contact time [h]
Alkalis	NaOH	5 %	140 ⁽¹⁾	13-14	500	3
	NaOH and NaClO	5 %	70	≥ 11	300	1
	NaClO or KClO	300 mg/l active chlorine	20	≥ 9		2
			60			0.5
Acids	H ₂ SO ₄	1.0 / 1.5 % ⁽²⁾ 3.5 % ⁽³⁾	60		150 ⁽²⁾ 250 ⁽³⁾	1
	H ₃ PO ₄ or HNO ₃	5 %	90		200 ⁽²⁾ 300 ⁽³⁾	1
	C ₂ H ₄ O ₃	0.0075 %	90		300	0.5
		0.15 %	20			2
Iodophore	50 mg/l active iodine	30	≥ 3		3	

⁽¹⁾ Depends on the maximum permitted temperature of the pump

⁽²⁾ CrNi-steel (1.4301)

⁽³⁾ CrNiMo-steel (1.4401 / 1.4571)

**Warning****Damage caused by detergent!**

- ▲ Death, serious bodily injury, damage to property.
- ▶ Use only suitable detergent.
- ▶ Always note the safety instructions of the product information of the detergent.
- ▶ Always wear suitable safety equipment when working with detergent.
- ▶ Do not exceed the maximum permitted concentration of the detergent.
- ▶ Corrosive acids should be avoided, because they promote pitting corrosion.

Detergents containing hydrochloric acid (HCl) and/or hydrofluoric acid (HF) are not allowed. If you want to use special detergents and cleaning methods, please contact the supplier for information relating to the pump materials used. For a residue-free removal of the detergent, the pump must be thoroughly flushed with water. The maximum permitted temperature can be found in section

Technical data**Warning****Hot surfaces!**

- ▲ Death, serious bodily injury, damage to property
- ▶ Do not touch the pump during cleaning. Pump surfaces can be very hot.

Disposal of detergent

Dispose of detergent in a professional and environmentally friendly way.

2.11.2 SIP

SIP means Sterilisation In Place. The pump will be sterilised by hot steam. For the hot-steam sterilisation or sanitisation, minimum temperatures of 121 °C must be in contact with all surfaces. The maximum permitted operating temperature can be found in section *Technical data*.

The pump should never be operated during the SIP process. After the SIP process, a cool-down phase of minimum one hour is needed.

**WARNING****Hot surfaces!**

- ▲ Death, serious bodily injury, damage to property.
- ▶ Do not touch the pump during the sterilisation and cool-down phases. Pump surfaces can have a temperature of more than 100 °C!

**Warning****Dry running!**

- ▲ Damage to property.
- ▶ Never operate the pump during the SIP process. The mechanical shaft seal will be destroyed.

**Warning****Pressure surge!**

- ▲ Death, serious bodily injury, damage to property.
- ▶ Before sterilisation, always evacuate the system completely of pumped liquid!

2.12 Repair contract

The duty to follow the legal regulations on work safety and the regulations on environmental protection means that all commercial enterprises must protect their employees, the public at large, and the environment from the harmful effects of hazardous materials.

Examples of legal regulations on work safety:

- the Workplace Act (ArbStättV)
- the Hazardous Materials Act (GefStoffV)
- the accident prevention regulations (BGV A1)
- regulations for environment protection e.g. the Recycling and Waste Law (KrW/AbfG), the Water Economy Law (WHG)
- all applicable laws, rules, guidelines, regulations etc. in the country of operation.

Certificate of non-objection

The certificate of non-objection attached to the shipment is a component of the inspection/repair contract. This does not affect our right to refuse acceptance of this contract for other reasons.

The certificate of non-objection can be found on page 37.

HILGE products and their parts will only be inspected and/or repaired if the certificate of non-objection is present and has been correctly completed by authorised and qualified technical personnel.

Pumps which have been operated in liquids exposed to radiation will not be accepted.

If any additional safety measures are required even after the careful draining and cleaning of the pump, the necessary information must be provided.

3 Product description

Overview

In this section you will get to know the pump as well as its design and application. The section "Technical Data" describes the limits of application. You must know and observe these limits.

3.1 Pump overview




Fig. 3: HYIANA III Adapta®

- 0107 - discharge housing
- 0153 - suction port
- 0156 - discharge port
- 0180 - Adapta® foot
- 0330 - bearing housing
- 0801 - flanged motor.

3.2 Description

The pump is a multi-stage end-suction centrifugal pump with a modular design. All parts which come in contact with the medium are in accordance with „hygienic design“ guidelines.

3.2.1 Areas of application

Standard design

Pumps of the standard design are used for:

- industrial applications
- CIP processes
- surface treatment for environmental technologies
- all systems and processes employed in the production of food-stuffs, including dairy products and beverages.

3.3 Proper usage



WARNING

Improper usage!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Pump only liquids that are specified in the order. The pump has been specially designed for that purpose.
- ▶ Operate the pump only in the electrical network specified in the order.

3.3.1 Pumped liquids

Only pure or slightly contaminated liquids may be pumped. These liquids may not chemically or physically attack the pump materials or reduce their strength. If liquids with a viscosity greater than that of water are to be pumped, make sure that the motor will not be overloaded. The pump may not be operated beyond the maximum permissible values. Even short periods of pressure overload (e.g. as a result of a pressure surge) should be avoided.

3.3.2 Minimum flow rate, Q_{\min}

Do not operate the pump below the minimum flow rate of $Q_{\min} = 10\text{-}15\% Q_{\text{opt}}$.

3.3.3 Connections and pipelines

The nominal diameters of the system pipelines should be equal to or greater than the nominal diameters of the pump, i.e. DNE (suction side) and DNA (pressure side), and the elements that are to be connected to the pump must conform exactly to the design standard/specification of the mating connector piece installed on the pump. The suction line must be absolutely leakproof and if possible laid out in such a way that no air pockets can form. Avoid tight elbows and do not install valves immediately upstream of the pump. On the suction side, provide a straight pipe section with a minimum length of five times the pipe diameter. The suction head of the system may not exceed the suction head guaranteed by the pump.

3.3.4 Motor operation

Do not start and stop the motor more than 15 times per hour.

3.3.5 Design

All information and descriptions in this operating manual concerning the use and operation of the pumps are based exclusively on the standard designs.

These rules do not apply to special designs, customer-specific modifications, or random external influences that may occur during use and operation.

3.4 Technical data




WARNING

Overloading the pump!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Use the pump only under the indicated operating conditions.
- ▶ Also avoid brief overpressure situations (e.g. caused by pressure surges).

3.4.1 Type key

The HILGE pump designation is structured as shown below:



3.4.2 Pump serial number

The pump can be identified by the pump serial number. When ordering spare parts, always state the pump serial number.

3.4.3 Nameplate




Fig. 4: Example of HILGE nameplate

- 1 - pump type
- 2 - pump serial number
- 3 - capacity [Q]
- 4 - head [H]
- 5 - motor power [P]
- 6 - speed [n]
- 7 - number of operating manual.

NOTE: The nameplate can deviate from the nameplate shown.

3.4.4 Performance data

The performance data of the pump, head and flow rate are determined in accordance with ISO 9906:2012, grade 3B and documented on the acceptance records.

3.4.5 Noise emissions

Measured values according to DIN EN ISO 3746 for pump units. Uncertainty of measurement: 3 dB(A).

Motor power kW	L _{pfa} [dB (A)]	Number of poles
1,5	67	2
2,2	67	
3	73	
4	73	
5,5	73	
7,5	74	
11	74	
15	75	
18,5	76	
22	76	
30	77	
37	77	

Noise emissions caused by a pump are significantly affected by its application and construction. For this reason, no guarantee of accuracy is given for the values indicated here.

3.4.6 Weights

Design features of the described standard pumps:

Caution:

The weights can - depending on design and accessories - differ from those presented. The manufacturer gives you when given the pump / order number precise information.

- HYGIANA I and II combi foot mounting
- Single mechanical seal
- SIEMENS motor

Motor power [kW]	Motor size	Stages	Weight [kg]
1.5	090S	2	33
		3	35
2.2	090L	2	38
		3	40
		4	43
3	100L	2	43
		3	45
		4	47
4	112M	3	50
		4	52
5.5	132M	5	65
		6	67

TM05 6440 4912

Motor power [kW]	Motor size	Stages	Weights [kg]
5.5	132M	2	81
		3	87
7.5	132M	2	90
		3	96
11	160M	2	110
		3	116
		4	122
15	160M	3	125
		4	131
		5	137
18.5	160L	5	158

Motor power [kW]	Motor size	Stages	Weight [kg]
18.5	160L	2	240
		3	270
22	180M	2	245
		3	280
30	200L	2	250
		3	290
		4	340

3.4.7 Maximum operating temperatures



Exceeding the maximum permitted operating temperature!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Never exceed the specified operating temperatures!

The following table lists the maximum permissible temperatures.

Design	Temp. [°C]
Standard design	95
Special design	150
Sterilisation (SIP)	140

3.4.8 Maximum operating pressure



WARNING

Pressure overload!

- ▲ Death, serious bodily injury, damage to property.
- ▶ The pump must be operated according to the order data.
- ▶ Never exceed the specified maximum operating pressures.

Pump operating pressure

The maximum permissible operating pressure depends on various factors:

- pump type
- design of connections
- design of mechanical seal.

For the values that apply to your pump, please refer to the order documents.

4 Mounting, installation and connection

Overview

This section describes how to mount, install and connect the pump. You get to know what to consider when you connect the pump to the electric mains supply and how to improve the flow in order to avoid dry running of the shaft seals.

4.1 Inspection before pump installation

4.1.1 How to check free running of the impeller

1. Remove motor shroud (if applicable).
2. Remove fan cover of motor.
3. Consider direction of rotation (arrow).
4. Rotate shaft slowly by hand via the fan.
The shaft must rotate easily. If the impeller rubs against the pump housing, it has been damaged (for example during transport).
If the impeller rubs against the housing, contact HILGE Service.
If the impeller runs freely:
5. Re-fit fan cover of the motor.
6. Re-fit motor shroud (if applicable).

4.2 Set-up and alignment of the pump



WARNING

Misalignment of the pump due to improper foundation!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Ensure that the foundation on which the pump is set up is clean and flat and has sufficient load capacity.
- ▶ Mount the pump – especially when it is to be set up vertically – with the use of suitable heavy-duty anchors. As the centre of gravity is higher, the pump can tip
- ▶ The mounting points provided must be bolted to the foundation according to the standard rules of mechanical engineering to ensure the satisfactory set-up of the pump.

Align the pump in this way

1. Use an engineer's spirit level laid across the machined surface of the discharge port to align the pump.
2. After aligning the pump, tighten the mounting bolts uniformly in a crosswise manner.

4.3 Installation in the pipeline



WARNING

Mechanical overload!

- ▲ Death, bodily injury, damage to property.
- ▶ Do not use the pump or its connecting sleeves to support the pipeline (EN 809 5.2.1.2.3 and EN ISO 14847).
- ▶ In addition to the general rules of machine-building and system construction, also follow the instructions provided by the manufacturer of the connecting elements used (e.g. flanges) when installing the pump in the pipeline or system. These specifications will contain data on torques, maximum permissible angular offset and tools/auxiliary materials to be used.
- ▶ After connecting the pipes, check the alignment of the coupling.
- ▶ It is absolutely necessary to avoid twisting the pump.



CAUTION

Mechanical overload due to foreign objects!

- ▲ Damage to property.
- ▶ The suction and discharge ports are sealed with sheets of plastic, and the flushing and drain lines with plastic caps. These must be removed before the pump is installed in the system.



CAUTION

Dry running!

- ▲ Damage to property.
- ▶ The suction line must be absolutely leakproof and laid in such a way that no air pockets can form.
- ▶ Avoid tight elbows and valves immediately upstream of the pump. They will interfere with the incoming flow to the pump and thus with the NPSH of the system.
- ▶ The nominal pipe diameters of the system should be equal to or greater than the connectors of the pump.
- ▶ A foot valve should be used in suction operation mode.
- ▶ To prevent air pockets from forming, the suction line must be laid so that it rises to the pump, whereas a gravity feed line must be laid with a slight downward gradient to the pump.
- ▶ If local conditions do not allow the suction line to ascend continuously, install a venting device at the highest point of the line.
- ▶ An isolating valve should be installed in the suction line near the pump. This valve must be completely open during operation and may never be used as a control valve.
- ▶ An isolating valve should be installed in the discharge line, near the pump, to control the flow rate.




Fig. 5: Installation in the pipeline

Above: gravity feed mode | **below:** suction operation mode | **P** - pump | **M** - motor

4.3.1 Operation of the mechanical seal

Mechanical seals require a lubricating film in the sealing gap which prevents contact between the two sliding surfaces. Generally, this lubricating film consists of the pumped liquid or an externally supplied flushing or barrier liquid.

Due to the frictional heat between the sliding surfaces, the lubricating film will evaporate to the atmosphere. If the pumped liquid is water, watery liquids or volatile liquids, the leakage will thus not be visible. For perfect operation, the amount of leakage is usually only a few ml/h, but - depending on other circumstances - it may rise.

Particularly during the run-in period, and independent of size, shape or design, mechanical shaft seals may discharge a low leakage. In some cases it may be necessary to tolerate a small, visible leakage or to counteract this with appropriate measures.

TM05 6442 4912

Dry running

To achieve a proper sealing, mechanical seals require a lubricating film between the sliding surfaces.

Dry running occurs if the lubricant film between the sliding surfaces is missing or wears away. The frictional heat generated by direct contact of the sliding surfaces will damage the mechanical seal. Depending on the material combination, this will happen within a few seconds.




Fig. 6: Lubricating film between the sliding surfaces

P Pump side | **A** Atmospheric side

L Lubricating film | **0433.00** Mechanical seal

4.3.2 Space requirements



WARNING

Overheating!

- ▲ Damage to property.
- ▶ Ensure sufficient ventilation.
- ▶ Make sure not to reabsorb warm cooling air. Consider other heat sources in the area.
- ▶ Maintain minimum distances.

Pay attention to motor power. Maintain the minimum distances.




Fig. 7: Minimum distances

4.3.3 Reduction of noise and vibration

Noise and vibration are generated by the flow in pipes and fittings. The effect on the environment depends on correct installation and the state of the rest of the system. One way of reducing noise and vibrations is by installing expansion joints.




Fig. 8: Expansion

- A - expansion joints
- B - foundation
- C - vibration dampers.

Function of expansion joints:

- Dampening of expansions/contractions in the pipework caused by changing the temperature of the pumped liquid
- reduction of mechanical strains in connection with pressure surges in the pipework
- insulation of mechanical structure-borne noise in the pipework (only rubber bellows expansion joints).

Do not install expansion joints to compensate for inaccuracies in the pipework such as centre displacement of flanges. Fit expansion joints at a distance of minimum 1 to 1½ times the nominal flange diameter away from the pump on the suction as well as on the discharge side. This will prevent the development of turbulence in the expansion joints, resulting in better suction conditions and a minimum pressure loss on the pressure side. At high viscosity or velocities, we recommend that you install larger expansion joints corresponding to the pipework.



WARNING

Vibration!

- ▲ Damage to property.
- ▶ Make sure that pipes and pumps are fixed firmly to foundation or building. Insufficiently rigid structures may cause oscillations if operating conditions are changed, e.g. by fluctuations in hydraulic and/or motor forces.

Vibrations may have the following effects:

- damage to pump and motor bearings
- damage to the mechanical shaft seal
- increased coupling wear
- damage to shaft/hub connections
- cracks in the pump connections
- loosening bolts
- cable breaks at the motor connection
- tarnishing of impeller caused by friction heat.

4.4 Connection of flushing system

HILGE pumps with double mechanical seal are equipped with a seal cartridge.

Depending on the seal design, the barrier or flushing fluid flows inside this seal cartridge.

The connection must be carried out as shown in fig. 9. So you can ensure that the fluid can flush the mechanical seal effectively.




Fig. 9: Flushing connection

K.0298V1

- A - inlet line
- B - outlet line
- N - direction of rotation (pump)



WARNING

Dry running!

- ▲ Damage to property!
- ▶ Connect the lines of the flushing system so as to guarantee a liquid supply.
- ▶ Always keep the filling level of the liquid pot between the upper and lower marks.
- ▶ In case of unpressurised flushing, ensure that the pressure in the cartridge seal never exceeds 0.2 bar.

Connect the flushing system in this way:

1. Connect feed line A. Note the dependence between arrangement and direction of rotation.
2. Connect outlet line B.
3. Check tightness of connections.

4.4.1 Double mechanical seal, back-to-back arrangement

Barrier liquid

In order to ensure proper functioning, the mechanical shaft seals require a barrier liquid. The purpose of the barrier liquid is:

- pressurising the seal chamber
- preventing the pumped liquid from penetrating into the sealing gaps
- protecting against dry-running
- lubricating and cooling the mechanical shaft seals.

Use a pure barrier liquid which is compatible with the pumped liquid.

How to ensure proper functioning:

1. Open feed line of barrier liquid.
2. Bleed cartridge seal.

3. Ensure liquid is circulating at required pressure.

The pressure of the barrier liquid should be at least 1.5 - 2 bar above the highest pressure of the pumped liquid. The temperature of the barrier liquid should not be above 60 °C on exit and should on no account exceed the boiling point.

4.4.2 Double mechanical seal - tandem arrangement

Flushing liquid

To continue functioning, the mechanical seals require a flushing liquid, some of its purposes being:

- preventing leaks
- protecting against dry-running
- lubricating and cooling the mechanical seals
- cutting off the air from substances which react unfavourably with oxygen.

Use a pure flushing liquid which is compatible with the pumped liquid.

Ensure proper functioning in this way:

1. Open feed line for flushing liquid.
2. Bleed cartridge seal.
3. Ensure unpressurised circulation.

Use a pure flushing liquid which is compatible with the pumped liquid.

In case of abrasive liquids, provide a reservoir into which the flushing liquid is discharged directly.

4.5 Electrical connections



WARNING

Electric shock!

- ▲ Death, serious bodily injury.
- ▶ The electrical connections must be made by a qualified electrician.
- ▶ VDE specifications and any local regulations must be followed, especially those pertaining to safety measures.



DANGER

Motors with frequency converters (Tronic) - risk of electric shock from live parts!

- ▲ Death and serious bodily injury.
- ▶ Even if the power supply is switched off, touching electrical components can lead to electric shock.
- ▶ Before touching electrical components, disconnect the power supply and wait at least four minutes.



WARNING

Capacity overload!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Check that the operating voltage corresponds to the voltage stated on the nameplate of the motor!
- ▶ Install an electrical circuit breaker.



CAUTION

Transients during frequency converter operation

- ▲ Damage to property.
- ▶ Use a motor which is suitable for frequency converter operation.
- ▶ Use a dU/dt filter or a motor with reinforced windings to avoid transients.

4.5.1 Star connection

Star connection of three-phase system for high voltage.
Connect the pump as specified in the order documents. The figure below shows star connection.




Fig. 10: Star connection

TM05 6448 4912

4.5.2 Delta connection

Delta connection for low voltage.
Connect the pump as specified in the order documents. The figure below shows delta connection.




Fig. 11: Delta connection

TM05 6447 4912

4.5.3 Frequency converter operation

All three-phase motors can be connected to a frequency converter. Frequency converter operation can subject the motor insulation to enhanced strain. This may lead to more motor noise than normal as a result of eddy currents caused by transients.

Large motors operated via a frequency converter are subject to bearing currents. For motors size 37 kW and higher in pumps that are operated by an external frequency converter, HILGE recommends the use of insulated motor bearings to avoid increased wear of motor bearings by bearing currents.

Please consider the following operating conditions if the pump is operated using a frequency converter:

Operating conditions	Actions
Noise-sensitive applications	Install a dU/dt filter between the motor and the frequency converter (reduces transients and thus also noise).
Highly noise-sensitive applications	Install a sinus filter.

Operating conditions	Actions
Cable length	Use a cable that satisfies the conditions specified by the frequency converter manufacturer. The length of the cable between the motor and the frequency converter impacts motor load. Keep the cable as short as possible. Use a sinus filter for cable lengths of 150 m and up.
Supply voltage up to 500 V	Check if the motor is suitable for frequency converter operation.
Supply voltage between 500 V and 690 V	Install a dU/dt filter between the motor and the frequency converter (reduces transients and thus also noise), or check whether the motor has reinforced insulation.
Supply voltage of 690 V and up	Install a dU/dt filter between the motor and the frequency converter and check whether the motor has reinforced insulation.

Please follow the manufacturer's instructions when installing and operating a frequency converter.

4.5.4 Checking the direction of rotation after connection



CAUTION

Danger of dry running!

- ▲ Damage to property.
- ▶ Before checking the direction of rotation, fill and vent the pump.
- ▶ Connect the motor and briefly (for about 2 seconds) check the direction of rotation. Note the direction-of-rotation arrow (red) on the pump. If the pump turns in the wrong direction, the mechanical seal can be destroyed.

Check the direction of rotation in this way:

1. After electrical connection, mount all safety equipment again.
2. Check tightness of hydraulic connection.
3. Open isolating valves.
4. Fill pump (system).
5. Observe the direction-of-rotation arrow.
6. Switch on motor for a short time (1-2 seconds).
7. Compare directions (motor/arrow).
8. Correct connection if necessary.

Operation with frequency converter

See the manufacturer's documentation.

5 Start-up / shut-down

Overview

This section describes how to start up and shut down the pump. You get to know which inspections contribute to failure-free operation and increased life of the pump.

5.1 Start-up

5.1.1 Check application conditions

Check the application conditions of the pump in this way:

1. Compare the data of the following documents with the provided application conditions of the pump:
 - purchasing documents (confirmation of the order)
 - nameplate
 - operating manual.
2. Make sure that the pump will operate under the specified conditions only. These conditions apply to (e.g.) pressure, temperature, and pumped liquid.

5.1.2 Starting up the pump

Start-up the pump in this way:

1. Check tightness of connection.
2. Make sure that all safety equipment is installed.
3. Make sure that all electrical connections are correct.
4. Open the isolating valves in the system.
5. Fill the pump together with the system.
6. Vent the pump and system.
7. Fully open the isolating valve on the suction side.
8. Close the isolating valve on the discharge side.
9. Start the pump.
10. Slowly open the isolating valve on the discharge side.



CAUTION

Overheating and pressure overloading!

- ▲ Damage to property.
- ▶ Never operate the pump against a closed isolating valve. Operation with a closed isolating valve must on no account continue for longer than 30 seconds.
- ▶ Never exceed the permissible operating conditions.

If the discharge head does not rise after the pump has been turned on:

1. Switch off the pump.
2. Vent the pump (system) again.
3. Repeat steps 7. to 10.

5.1.3 Functional check of the mechanical seal

Check the function of the mechanical seal in this way:

1. Watch the pump and check the mechanical seal for fault-free functioning (leak test).
 2. An intact mechanical seal works virtually without leakage.
- If the pumped liquid or flushing liquid leaks:

1. Switch off the pump.
2. Replace the mechanical seal.

Observe safety instructions in chapter 6.1.

5.2 Shutting down the pump



WARNING

Pressure surge!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Always close isolating valves slowly!

A pressure surge is an abrupt pressure increase in the system. This pressure increase can, for example, be caused by a quick blocking of the flow in the discharge pipe. In the event of a pressure surge the maximum permissible pump pressure is temporarily exceeded considerably.

Shut down the pump in this way:

1. Switch off the pump.
2. Close the isolating valve on the discharge side.
3. Close the isolating valve on the suction side.
4. Switch off the flushing system (if applicable).
5. Make sure that the pump is depressurised.
6. Switch off the pressure in the barrier system (if applicable).

5.2.1 Cleaning the pump after shut-down



CAUTION

Jamming!

- ▲ Damage to property.
- ▶ Clean the pump appropriately after shut-down.

6 Maintenance/servicing

Overview

This section gives important information about maintenance and servicing of the pump. Read this section before you carry out maintenance work or troubleshooting measures!

6.1 Safety instructions for installation, inspection and maintenance work



WARNING

Unprofessional work!

- ▲ Death, bodily injury, damage to property.
- ▶ The operations manager must ensure that all installation, inspection and maintenance work is carried out by authorised and qualified technical personnel, who have acquired the required knowledge through study of the operating instructions.



DANGER

Electric shock if electrical parts are touched!

- ▲ Death, bodily injury.
- ▶ Always turn off the power supply to the pump before rectifying any fault.



DANGER

For motors with frequency converters (Tronic) - risk of electric shock from live parts!

- ▲ Death and serious bodily injury.
- ▶ Even if the power supply is switched off, touching electrical components can lead to electric shock.
- ▶ Before touching electrical components, disconnect the power supply and wait at least four minutes.



WARNING

Pressurised spray!

- ▲ Death, bodily injury, damage to property.
- ▶ Depressurise the pump before rectifying any fault.



WARNING

Hot components!

- ▲ Death, bodily injury, damage to property.
- ▶ Always allow the pump to cool down before rectifying any fault.



WARNING

Unintentional switching on of the pump!

- ▲ Death, bodily injury, damage to property.
- ▶ Take appropriate measures to ensure that the pump cannot be unintentionally turned on again.



WARNING

Contact with or inhalation of hazardous substances!

- ▲ Death, bodily injury, damage to property.
- ▶ Pumps or systems which convey hazardous liquids must be decontaminated.



WARNING

Missing protection and safety equipment!

- ▲ Death, bodily injury, damage to property.
- ▶ Immediately after completing the work, re-install the protection and safety equipment and make sure it functions correctly.



CAUTION

Unsuitable tools!

- ▲ Damage to property.
- ▶ In accordance with the design standard (3A0.01 to 3A3.37), ensure that all parts of the pump can be assembled without damage (e.g. scratches).
- ▶ Use HILGE assembly tool kit.



CAUTION

Frost!

- ▲ Damage to property.
- ▶ When there is danger of frost, drain the pump completely.

6.2 Maintenance of the pump

The pump is a low-maintenance pump. In addition to cleaning, the only point to be kept in mind is the wear to the rotating mechanical seal.

6.3 Maintenance of the motor

6.3.1 Motors without lubrication fittings

Motors without lubrication fittings are greased for life. The grease service lifetime is based on the bearing service lifetime. The prerequisite is that the motor is used according to catalogue specifications.

6.3.2 Motors with lubrication fittings

On motors equipped with lubrication fittings, information regarding re-lubrication intervals, grease types, grease volumes and additional information as needed is listed on the lubricating plate or nameplate.




Fig. 12: Example of lubricating plate, MGE motor

- 1 - drive-end bearing
- 2 - grease type
- 3 - ambient temperature
- 4 - ambient temperature
- 5 - non-drive-end bearing
- 6 - grease quality
- 7 - lubricating interval
- 8 - lubricating interval.

TM04 2075 1908

6.4 Maintenance of the Adapta® bearing housing

6.4.1 Bearing housing

Different bearing housing sizes are used depending on the size of the pump and motor. Sizes 1 and 2 are identical. Please see chapter *Design of bearing housing, sizes 1 and 2* and chapter *Design of bearing housing, size 3* for information regarding bearing housing design.

Bearing replacement

In order to ensure proper pump operation, please replace the bearing after approximately 15,000 to 20,000 operating hours.

Premature bearing replacement

In case of enduring, external impacts causing wear, such as dust, splashing water, corrosive ambient air and high temperatures, we recommend you to replace bearings after approximately 5000 operating hours.

Grease

The cavities between the rolling bodies of the bearings are completely filled with grease from factory. The grease is encapsulated by V-rings 0507.02 and 0507.05, and is intended for normal environmental conditions. The following chapters list the grease volumes to be observed during installation.

Grease types

We recommend that you use the greases listed below or verified equivalents to lubricate the roller bearings.

Manufacturer	Bearing temperature ≤ 120 °C	Bearing temperature ≤ 60 °C - risk of water ingress
ARAL	HL 3	FM 3
BP	BP ENERGREASE LS 3	ENERGREASE PR 3 ENERGREASE LS 3
CALTEX	CALTEX MULTI- FAK 2	CALTEX CUP GREASE 3 CALTEX MULTIFAK 2
ESSO	BEACON 3	ESTAN 2 R BEACON 3
GULF	UNIREX N3 GULFCROWN GREASE No. 2 GULFCROWN GREASE No. 3	UNIREX N3 GULFCROWN GREASE No. 2 GULFCROWN GREASE No. 3
MOBIL - OIL	MOBILUX GREASE No. 3	GARGOYLE GREASE B No.3 MOBILUX GREASE No. 3
SHELL	SHELL ALVANIA FETT 3	SHELL UNEDO FETT 3 SHELL ALVANIA FETT 3
VALVOLINE	VALVOLINE LB 2 OKS 4200 (> 120 / ≤ 180 °C)	VALVOLINE LB 2
OKS		
SKF	LGMT 3/1	LGMT 3/1

6.4.2 Design of bearing housing, sizes 1 and 2

The bearing housing has two angular-contact ball bearings. They are arranged in pairs and are installed in an O-type configuration as fixed bearings to absorb axial and radial forces from all directions.

Grease volumes for roller bearings during installation

This information pertains to complete filling of the bearings.

Bearing housing size	1	2
Part no.	0326.00	0326.00
Number of bearings	2	2
Volume [cm ³]	9	25
Quantity [g]	8.5	23.7

6.4.3 Design of bearing housing, size 3

The bearing housing has two angular-contact ball bearings 0326.00 and a cylindrical roller bearing 0327.00. The two single-row angular-contact ball bearings make up the motor-side bearing. They are arranged in pairs and are installed as fixed bearings in an X-type configuration to absorb axial and radial forces from all directions.

The pump-side bearing consists of a single-row cylindrical roller bearing absorbing only radial bearing forces. The bearing permits axial movements in both directions.

Grease quantities for roller bearings during assembly

This information pertains to complete filling of the bearings.

Size	3
Part no.	0326.00 + 0327.00
Number of bearings	2+1
Volume [cm ³]	33
Weight [g]	31.25

Relubrication of the bearings

Lubricate the roller bearings according to the following table. The values indicated refer to normal operating conditions.



CAUTION

Incorrect lubrication of roller bearings!

- ▲ Damage to property.
- ▶ Make certain to avoid applying too much or too little grease to the bearings!

Bearing	Lubricating intervals [hours]	Weight [g]
0326.00	Approx. 1,000	11
0327.00	Approx. 3,000	10

6.5 Assembly




DANGER

Disregard of instructions!

- ▲ Death, bodily injury or damage to property.
- ▶ Before assembly or maintenance work of the pump, see section 6.1.

6.5.1 Parts overview



K.0446V1

Fig. 13: Parts overview

Qty.	Part no.	Description
1	0107.00	discharge casing
1	0112.02	diffusor casing
1	0112.03	diffusor casing
1	0162.00	suction cover
1	0211.00	pump shaft
1	0230.01	impeller
1	0230.02	impeller
1	0230.03	impeller
1	0412.11	O-ring
1	0412.12	O-ring
1	0412.13	O-ring

Qty.	Part no.	Description
1	0433.00	mechanical seal
1	0504.00	spacer ring
1	0504.01	spacer ring
1	0513.01	insert ring
1	0513.02	insert ring
1	0513.03	insert ring
1	0515.01	clamp ring
4	0905.01	tie bolt
4	0920.22	hexagon nut
1	0922.00	impeller nut
4	0934.03	spring washer

6.5.2 Bearing housing, sizes 1 and 2




Fig. 14: Parts overview, bearing housing up to motor size 180

Qty.	Part no.	Description
1	0211.00	Pump shaft
2	0326.00	Angular-contact ball bearing
1	0330.00	Bearing housing
1	0360.01	Bearing cover
1	0507.00	Deflector
1	0507.02	Deflector (V-ring)
1	0507.05	Deflector (V-ring)
4	0560.00	Pin
2	0686.00	Guard
1	0900.00	Screw

Qty.	Part no.	Description
4	0901.30	Hexagon head screw
4	0901.04	Hexagon head screw
4	0920.32	Hexagon nut
1	0926.00	Grooved nut
4	0934.05	Spring washer
1	0940.00	Key
1	0940.01	Key
1	0970.00	Nameplate
4	1002.02	Pan-head slotted screw

TM06 1130 1814

6.5.3 Bearing housing, size 3





Fig. 15: Parts overview, bearing housing from motor size 200

Qty.	Part no.	Description
2	0326.00	Angular-contact ball bearing
1	0327.00	Cylindrical roller bearing
1	0330.00	Bearing housing
1	0360.00	Bearing cover
1	0360.01	Bearing cover
1	0504.00	Spacer ring
1	0507.00	Deflector
1	0507.02	Deflector (V-ring)
1	0507.05	Deflector (V-ring)
4	0560.00	Pin
1	0636.00	Grease nipple
1	0636.01	Grease nipple
2	0686.00	Guard

Qty.	Part no.	Description
1	0900.00	Screw
4	0901.03	Hexagon head screw
4	0901.04	Hexagon head screw
4	0920.09	Hexagon nut
1	0932.00	Circlip
1	0932.02	Circlip
4	0934.05	Spring washer
4	0934.25	Spring washer
1	0940.01	Key
1	0940.00	Key
1	0970.00	Nameplate
4	1002.00	Pan-head slotted screw

TM06 1131 1814

6.5.4 Coupling and motor



TIM05 2740 0912

Fig. 16: Parts overview, coupling and motor

Qty.	Part no.	Description
1	0211.00	Pump shaft
1	0346.00	Intermediate ring
4	0554.08	Washer
1	0680.00	Shroud (SUPER-version only)
1	0801.00	Motor
1	0840.00	Coupling
1	0840.01	Coupling
1	0867.02	Coupling insert

Qty.	Part no.	Description
4	0902.06	Stud
1	0904.00	Set screw
1	0904.01	Set screw
4	0904.05	Set screw
4	0920.23	Hexagon nut
4	0920.09	Hexagon nut
4	0934.06	Spring washer
1	0940.01	Key

6.5.5 Instructions for disassembly

**DANGER**

Disregarding important instructions!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Before you disassemble the pump, note section 6.1 *Safety instructions for installation, inspection and maintenance work* on page 17.

**CAUTION**

Important!

- ▲ Damage to property.
- ▶ Use tools from the HILGE assembly tool kit in order to disassemble the pump without damage and scratches.

6.5.6 Instructions for assembly

**DANGER**

Disregarding important instructions!

- ▲ Death, serious bodily injury, damage to property.
- ▶ Before you assemble or do maintenance work on the pump, note section 6.1 *Safety instructions for installation, inspection and maintenance work* on page 17.

**CAUTION**

Important!

- ▲ Damage to property.
- ▶ Use tools from the HILGE assembly tool kit in order to assemble the pump without damage or scratches.
- ▶ To ensure a good sealing, use only O-ring seals with the original dimensions.
- ▶ Never use grease containing mineral oil when assembling the wet-end parts. Wet-end parts come into contact with the pumped liquid.
- ▶ When replacing mechanical seals, always replace all parts.
- ▶ To tighten impeller nut 0922.00, use either a screw device or the impeller nut installing device as the torque applied to tighten it must be absolutely concentric. Otherwise the pump shaft 0211.00 will be bent.

6.5.7 Assembly of the bearing housing, sizes 1 and 2


- Slide the angular-contact ball bearings 0326.00 onto the pump shaft 0211.00. If the bearings have been replaced, replace the grooved nut. Lock the bearings 0326.00 by tightening the grooved nut 0926.00. Torque: 120-140 Nm.



MF-426

Fig. 17: Shaft, bearings and grooved nut

- Push the pump shaft 0211.00 into the bearing housing 0330.00.



MF-696

Fig. 19: Adapta bearing housing

- Mount the bearing cover 0360.01 using spring washers 0934.05 and hexagon head screws 0901.04. Torque: 8 Nm.



MF-358

Fig. 21: Bearing cover

- Push the V-ring 0507.02 with greased lip onto the pump shaft 0211.00; make sure that the sealing lip bears against the bearing housing 0330.00.



MF-698

Fig. 23: V-ring on pump side

- Fill the cavities of the bearing 0326.00 to about 100 % with grease. As you do so, observe section on page 18.



MF-398

Fig. 18: Ball bearings

- Coat the inner face of the bearing cover 0360.01 with grease. Push the bearing cover over the pump shaft 0211.00.



MF-399

Fig. 20: Bearing cover


- Push the V-ring 0507.05 with greased lip onto the pump shaft 0211.00; make sure that the sealing lip bears against the bearing cover 0360.01.



MF-359

Fig. 22: V-ring on motor side

- Insert key 0940.01 into pump shaft 0211.00. Do not use a hammer to do this! The bearings could be damaged.



MF-360

Fig. 24: Key


9. Push the coupling half 0840.00 onto the pump shaft 0211.00 and align the coupling half 0840.00 to the pump shaft 0211.00.



MF-362

Fig. 25: Coupling half

10. Fix the coupling half 0840.00 by means of the set screw 0904.00. Torque: 4 Nm.



MF-363

Fig. 26: Set screw

11. Fit the bearing housing 0330.00 to the stainless steel foot 0180.00 using hexagon head screws 0901.00, hexagon nuts 0920.02 and spring washers 0934.02.



MF-687

Fig. 27: Stainless steel foot

Foot mounting can be different from the one shown.


13. Check coupling inserts 0867.02 for wear and change them where required.



MF-427

Fig. 29: Coupling inserts


12. Insert the key 0940.01 into the motor shaft.



MF-688

Fig. 28: Key


14. Push the coupling half 0840.01 onto the motor shaft, align it to the motor shaft and slightly tighten the set screw 0904.01.



MF-689

Fig. 30: Coupling half on motor side

15. Join motor 0801.00 and bearing housing 0330.00. To do this, put the coupling halves 0840.00 and 0840.01 into each other.



MF-686

Fig. 31: Coupling


16. Fix bearing housing 0330.00 and motor using hexagon nuts 0920.09 and spring washers 0934.06.
Torque: M10 - 37 Nm
Torque: M12 - 65 Nm



MF-690

Fig. 32: Bearing housing

17. Align coupling half 0840.01. The permitted axial offset of the coupling halves in relation to each other: 2-4 mm.
Check by means of a feeler gauge.
18. Fix coupling half 0840.01 using the set screw 0904.00.
Torque: 4 Nm



MF-691

Fig. 33: Feeler gauge


19. Push deflector 0507.00 onto the pump shaft 0211.00.



Mount the deflector 0507.00 in such a way that the distance to the adjacent parts eliminates contact.

6.5.8 Assembly the bearing housing, size 3


1. Push the outer ring of the cylindrical roller bearing 0327.00 on the pump side into the bearing housing 0330.00.



MF-589

Fig. 34: Bearing housing, cylindrical roller bearing


2. Grease the outer ring of the cylindrical roller bearing 0327.00. As you do so, observe section on page 18.



MF-383

Fig. 35: Cylindrical roller bearing


3. Grease the cylindrical roller bearing 0327.00 from the motor side of the bearing housing 0330.00. As you do so, observe section on page 18.



MF-585

Fig. 36: Cylindrical roller bearing


4. Push the angular-contact ball bearings 0326.00 as X-type configuration onto the pump shaft 0211.00.
5. Mount the spacer ring 0504.00 and the circlip 0932.02 on the motor side.
6. Grease the cylindrical roller bearing 0326.00. As you do so, observe section on page 18. Push the inner ring of the cylindrical roller bearing 0327.00 on the pump side onto the shaft.



MF-570

Fig. 37: Angular-contact ball bearing

7. Push the pump shaft 0211.00 and the angular-contact ball bearings 0326.00 into the bearing housing 0330.00.



MF-590

Fig. 38: Pump shaft

8. Mount the spacer ring 0504.01 and the circlip 0932.00 on the pump side.



MF-777


Fig. 39: Circlip

9. Clean the motor side bearing cover 0360.01.
10. Coat the inner surface of the bearing cover 0360.01 with grease.
11. Mount the bearing cover 0360.01 using spring washers 0934.05 and hexagon head screws 0901.04.
Torque: 10 Nm



MF-385
Fig. 40: Bearing cover

12. Clean the pump side bearing cover 0360.00.
13. Coat the inner surface of the bearing cover 0360.00 with grease.
14. Mount the bearing cover 0360.00 using spring washers 0934.25 and hexagon head screws 0901.03.
Torque: 10 Nm



MF-384
Fig. 41: Bearing cover

15. Push the V-rings 0507.02 and 0507.05 with the greased lips onto the pump shaft; make sure that the sealing lips bear against the bearing covers 0360.00 and 0360.01.




MF-587
Fig. 42: V-ring on pump side

16. Insert the key 0940.01 into pump shaft 0211.00.
Do not use a hammer to do this. The bearings could be damaged.




MF-588
Fig. 43: Key

17. Grease the coupling seat on the pump shaft 0211.00.
Use Klüberpaste UH1 96-402 from HILGE assembly tool kit (fig. 87).



MF-572
Fig. 44: Pump shaft

18. Check coupling inserts 0867.02 for wear and change them where required.
19. Push the coupling half 0840.00 onto the pump shaft 0211.00 and align it to the pump shaft.



MF-571
Fig. 45: Coupling half

20. Tighten the set screw 0904.01.
Torque M4: 3 Nm.




MF-563
Fig. 46: Set screws

21. Grease the studs 0902.06. Use Klüberpaste UH1 96-402 from HILGE assembly tool kit.



MF-564
Fig. 47: Studs


22. Screw the four studs 0902.06 into the bearing housing 0330.00.



MF-552

Fig. 48: Bearing housing with studs

23. Grease the contact surfaces of bearing housing 0330.00, motor 0801.00 and the studs 0902.06. Use Klüberpaste UH1 96-402 from HILGE assembly tool kit.



MF-565

Fig. 49: Bearing housing with studs


24. Insert the key 0940.01 into the motor shaft.



MF-961

Fig. 50: Key

25. Check coupling inserts 0867.02 for wear and change them where required.



MF-959

Fig. 51: Coupling inserts


26. Push the coupling half 0840.01 onto the motor shaft, align it to the motor shaft and slightly tighten the set screw 0904.01.



MF-960

Fig. 52: Coupling half on motor side


27. Join motor 0801.00 and bearing housing 0330.00. To do this, put the coupling halves 0840.01 and 0840.00 into each other.



MF-566

Fig. 53: Coupling


28. Fix bearing housing 0330.00 and motor using hexagon nuts 0920.09 and spring washers 0934.06.



MF-567

Fig. 54: Bearing housing


29. Align the coupling 0840.00. The permitted axial offset of the coupling halves in relation to each other: 4 mm.



MF-569

Fig. 55: Axial offset

30. Fix the coupling half 0840.00 using the set screw 0904.00.
Torque M4: 3 Nm.



MF-568

Fig. 56: Bearing housing

In order to continue the assembly, see the following descriptions of mechanical seals.

6.5.9 Mechanical seal arrangements

Following mechanical seal arrangements are available:




Fig. 57: Single mechanical seal

- A - pump side
 - B - atmosphere side
- Figure / parts can differ insignificantly.

K.0284V1




Fig. 58: Double mechanical seal, tandem

- A - pump side
 - B - atmosphere side
- Figure / parts can differ insignificantly.

K.0284V1

Mechanical seal type	Fig.	Description on page
Single mechanical seal	57	30
Double mechanical seal, tandem	58	supplemental sheet
Double mechanical seal, back to back	without	supplemental sheet

6.5.10 Assembly of the single mechanical seal

1. Coat the thread of the tie bolts 0905.01 with Loctite type 243 (HILGE assembly tool kit, (fig. 87)).
2. Hand-screw the tie bolts 0905.01 into the Bloc lantern 0340.00.



Fig. 59: Tie bolts

MF-553

3. Grease the back side of the discharge casing 0107.00. Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this.



Fig. 60: Discharge casing

MF-672

4. Assemble the discharge casing 0107.00 onto the shaft 0211.00.



Fig. 61: Discharge casing

MF-381

5. HYGIANA III: Use hexagon nuts 0920.32 and washers 0554.31 in order to join discharge casing 0107.00 and lantern 0340.00. Torque: M8 - 19 Nm.




Fig. 62: Discharge casing HYGIANA III

K.0295V1

6. Spray the stationary ring of the mechanical seal 0433.00 and the shaft 0211.00 with clean water.
Use spray bottle from HILGE assembly tool kit (fig. 87).



Fig. 63: Stationary ring of the mechanical seal

MF-653

7. Slide the assembly sleeve from HILGE assembly tool kit ((fig. 87) onto the shaft extension.



HILGE assembly tools avoid damages of the mechanical seal during the further assembly.



Fig. 64: Assembly sleeve

MF-656

8. Push the stationary ring of the mechanical seal 0433.00 into the seat of the discharge casing 0107.00. Use installation sleeve from HILGE assembly kit to do this.



Fig. 65: Stationary ring of the mechanical seal

MF-466

9. Slide the rotating part of the mechanical seal 0433.00 in complete assembly onto the shaft 0211.00 up to the stop. Use installation sleeve from HILGE assembly kit to do this.



Fig. 66: Rotary ring of mechanical seal

MF-469

For assembly of the impellers and casings read on at page 32.

6.5.11 Assembly of impellers and casings



ATTENTION

- ▲ Bending of pump shaft
- ▶ To tighten impeller nut 0922.00, use either a screw device or the impeller-fastening-aid which is mentioned below. The torque applied to tighten must be absolutely concentric.!

1. Insert key 0940.00.



Fig. 67: Key

MF-470

2. Grease the pump shaft 0211.00.
Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this (fig. 87).



Fig. 68: Pump shaft

MF-471



Impeller assembly




Fig. 69: Impeller arrangement

K.0296V1

A - closed impeller type

B - closed impeller type

C - last impeller

HYGIANA I: open or closed impeller with short collar

HYGIANA II: open or closed impeller

HYGIANA III: open impeller

3. Fit the impeller 0230.01.




Fig. 70: Impeller

MF-472

4. Fit insert ring 0513.01 into the discharge casing 0107.00.




Fig. 71: Spring

MF-473

5. Insert the O-ring 0412.11 into the discharge casing 0107.00.



Fig. 72: O-ring

MF-474

6. Insert the diffusor casing 0112.02.




Fig. 73: Diffusor casing

MF-475

To mount the following pump stages follow steps 3. to 6.

Take the different part numbers of impellers, diffusor casings and O-rings into account.



The pump can be equipped with two different types of impeller nuts:

- impeller nut with threaded insert
- impeller nut with lock washers

7. Grease the Nord-Lock washer 0930.00 by using Klüberpaste UH1 96-402 from the HILGE assembly tool kit.




Fig. 74: Nord-lock washer

MF-366

This manual describes the procedure to mount the impeller nut with lock washers.

If the pump is equipped with an impeller nut with a threaded insert take the following into account:

- As the impeller nut is being fitted, it must be possible to feel the self-locking action. It must be possible to tighten the nut without any problems. Tighten manually for the first two turns, so that the helicoil insert sits correctly on the shaft.
- Tightening torques:
 - M10 - 20 Nm (HYGIANA I)
 - M20 - 150 Nm (HYGIANA II / III)

8. Insert the Nord-Lock washer 0930.00 into the impeller nut 0922.00.



Fig. 75: Nord-Lock washer in impeller nut

MF-367

9. If all impellers are mounted, screw on the impeller nut 0922.00 by hand.




Fig. 76: Impeller nut

MF-446

10. Mount the clamp ring 0515.01.




Fig. 77: Clamp ring

MF-447

11. Grease the threads of the tie bolts 0905.00.

Use Klüberpaste UH1 96-402 from HILGE assembly tool kit for this, (fig. 87).



Fig. 78: Clamp ring

MF-448

12. Screw the hexagon nuts 0920.22 and tighten them. So the joints and O-rings can be set and the impeller nut can be tightened.




Fig. 79: Clamp ring

MF-449

13. Tighten the impeller nut 0922.00 using the following adjustments:
Torques:
M10x1.5: 20 Nm
M20x1.5: 100 - 120 Nm.




Fig. 80: Impeller nut

MF-450

15. Fit the last insert ring 0513.03 into the diffusor casing 112.03.




Fig. 82: Insert ring

MF-451

17. Fit the suction cover 0162.00 into the diffusor casing 112.03.




Fig. 84: Suction cover

MF-453

19. Check that the shaft can rotate smoothly.



Fig. 86: Check

MF-455

14. Remove hexagon nuts 0920.22 and clamp ring 0515.01.




Fig. 81: Clamp ring

MF-447

16. Fit the last O-ring 0412.13 into the diffusor casing 112.03.




Fig. 83: O-ring

MF-452

18. Mount the clamp ring 0515.01 and fix it by using the spring washers 0934.03 and hexagon nuts 0920.22.
Torques: 60-70 Nm




Fig. 85: Clamp ring

MF-454

6.6 Troubleshooting

Problem	Cause	Remedy
Pump does not deliver or delivers at a reduced rate.	<ol style="list-style-type: none"> 1. Incorrect electrical connection (two phases). 2. Wrong direction of rotation. 3. Air in suction line or in pump.¹ 4. Back pressure too high. 5. Suction head too high, NPSH feed too low. 6. Lines clogged or foreign material in the impeller. 7. Air inclusion as a result of a defective seal. 8. Disturbed inflow condition due to tees, valves, bends or container outlet. 	<ol style="list-style-type: none"> 1. Check the electrical connections and correct, if necessary. 2. Reverse the phases of the power supply (reverse the polarity). 3. Vent the suction line or the pump and refill. 4. Reset the operating point according to the data sheet. Check the system for contamination. 5. Raise the liquid level on the suction side. Open the isolating valve in the suction line completely. 6. Open the pump and fix the problem. 7. Check the pipeline seals, the pump housing seals and the shaft seals. Replace, if necessary 8. Check positioning and design of the parts and correct, if necessary.
Motor safety switch turns motor off. Motor is overloaded.	<ol style="list-style-type: none"> 1. Pump seized up because of clogging. 2. Pump seized up because pump body was twisted by the pipelines. Check for damage. 3. Pump continues to run beyond rated operating point. 4. Density or viscosity of pumped medium is higher than the value stated in the order. 5. Motor safety switch not properly adjusted. 6. Motor running on two phases. 	<ol style="list-style-type: none"> 1. Open the pump and fix the problem. 2. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 3. Set the operating point according to the data sheet. 4. If it is acceptable that the performance is lower than the value stated, decrease the flow rate on the pressure side. Otherwise, use a more powerful motor. 5. Check the setting. Replace the safety switch if necessary. 6. Check the electrical connections. Replace defective fuses.
Pump produces too much noise. Pump runs roughly and vibrates.	<ol style="list-style-type: none"> 1. Suction head too high, NPSH feed too low. 2. Air in suction line or in pump.¹ 3. Back pressure lower than stated. 4. Impeller out of balance. 5. Internal parts worn. 6. Pump is twisted (causing contact noises). Check for damage. 7. Bearings defective. 8. Insufficient, excessive or incorrect lubricant in bearings. 9. Motor cooling fan is defective. 10. Gear ring of coupling (power transmission) is defective.² 11. Foreign material in pump. 12. Pipe fastening or installation stands are too unstable. 	<ol style="list-style-type: none"> 1. Raise the liquid level on the suction side. Open the isolating valve in the suction line completely. 2. Vent the suction line or the pump and refill. 3. Set the operating point according to the data sheet. 4. Clean, inspect, and rebalance the impeller. 5. Replace the parts. 6. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 7. Replace the bearings. 8. Adjust the amount of lubricant or use a different type of lubricant. 9. Replace the motor cooling fan. 10. Replace the gear ring of the coupling. Realign the coupling. 11. Open the pump and clean it (install a screen in front of self-priming pumps, if necessary). 12. Check pipe fastening and installation stands and reinforce.
Leakage at pump housing, at connections, at mechanical seal, at stuffing box or at gland seal.	<ol style="list-style-type: none"> 1. Pump is twisted (causing leaks at the pump housing or connections). 2. Housing seals and seals of the connections defective. 3. Rotating mechanical seal dirty or stuck. 4. Rotating mechanical seal worn. 5. Stuffing box packing rings worn out. 6. Shaft surface or shaft safety sleeve worn down. 7. Elastomer unsuitable for the pumped liquid. 	<ol style="list-style-type: none"> 1. Install the pump so that there is no stress on it. Support the pipelines at fixed points. 2. Replace the housing seals or the seals of the connections. 3. Inspect and clean the rotating mechanical seal. 4. Replace the mechanical seal. 5. Tighten the stuffing box, add more packing rings, or replace the packing rings. 6. Replace the shaft or the shaft safety sleeve. Repack the stuffing box. 7. Use an elastomer suitable for the pumped medium and the temperature.
Impermissible temperature increase at the pump, bearing housing or motor.	<ol style="list-style-type: none"> 1. Air in suction line or in pump.¹ 2. Insufficient, excessive or incorrect lubricant in bearings. 3. Pump and bearing housing are twisted. 4. Axial thrust too high.¹ 5. Motor safety switch is defective or not properly adjusted. 6. Valve on pressure side closed. 	<ol style="list-style-type: none"> 1. Vent the suction line or the pump and refill. 2. Adjust the amount of lubricant or use a different type of lubricant. 3. Install the pump so that there is no stress on it. Support the pipelines at fixed points. Check the alignment of the coupling. 4. Inspect the relief holes in the impeller and the split rings at the inlet. 5. Check the adjustment. Replace the motor safety switch if necessary. 6. Open the valve on the pressure side.

1. Does not apply to self-priming pumps.
2. Applies to CN base plate design.

6.7 Disposal

If this is not possible, contact the nearest GEA Hilge company or service workshop.

This product or parts of it must be disposed of in an environmentally sound way:
Use the public or private waste collection service.

6.8 HILGE assembly tool kit

Remove and install the mechanical seals safely and reliably using tools from the HILGE assembly tool kit.




Fig. 87: HILGE assembly tool kit

TM05 6455 5112

6.8.1 Content and use

item (fig.)	Description	HYGIANA I	HYGIANA II	HYGIANA III
1a	assembly sleeve Ø 19	●		
1b	assembly sleeve Ø 28		●	
2	spray bottle	●	●	●
4b	assembly sleeve Ø 38			●
5	ejector for mechanical seal - stationary ring	●	●	●
6	Klüberpaste UH1 84-201	●	●	●
7	socket wrench SW 32		●	
7	plastic socket spanner insert SW 27		●	
8	Optimol Paste TA	●	●	●
9	socket wrench SW 24	●		
9	plastic socket spanner insert SW 17	●		
10	screw locking Loctite Typ 243	●	●	●
11	socket wrench SW 14	●	●	
11	plastic socket spanner insert SW 10	●	●	
12b	mechanical seal installation sleeve with plastic adapter Ø 38 und Ø 40			●
12b	plastic adapter Ø 38			●
12c	mechanical seal installation sleeve with plastic adapter Ø 28 und Ø 30		●	
12c	plastic adapter Ø 28		●	
12d	mechanical seal installation sleeve with plastic adapter Ø 19 und Ø 22	●		
12d	plastic adapter Ø 19	●		
14	cross handle with 1/2" rectangle	●	●	
	HILGE assembly tool kit	●	●	●

7 Certificate of non-objection

- Delivery date:
Reason for inspection / repair contract

Overview

This section contains a certificate of non-objection. In the event of inspection or repair send the pump including this certificate to HILGE.

Certificate of non-objection

The following pump and its accessories, together with this certificate of non-objection, are herewith contracted out by the undersigned for inspection/repair:

Pump data

- Model:
- No.:

The pump (please mark with a cross)

___ was not used in liquids hazardous to health

___ was used for the following:

Please state the last liquid pumped, if known:

The pump was carefully drained and also cleaned inside and out before it was shipped/made available. (please mark with a cross).

___ No special safety measures are required in the course of further handling.

___ The following safety measures pertaining to flushing liquids, residual liquids, and disposal are required:

We confirm that the information given above is correct and complete and that shipment is in compliance with legal regulations.

Company (address):

Telephone:

Fax:

Email:

Name (incl. title)

(please print):

Date:

Company stamp /
signature:

We live our values.

Excellence · Passion · Integrity · Responsibility · GEA-versity

GEA Group is a global engineering company with multi-billion euro sales and operations in more than 50 countries. Founded in 1881, the company is one of the largest providers of innovative equipment and process technology. GEA Group is listed in the STOXX® Europe 600 Index.

GEA Deutschland

Hilge GmbH & Co. KG

Hilgestraße 37 - 47

55294 Bodenheim, Germany

Tel +49 6135 7016-0

Fax +49 6135 1737

hilge@gea.com

gea.com