GEA SMARTPUMP



GEA Hilge TP

Single-stage Centrifugal Pumps for Standard Applications



Sustainable and Economical Application Under Hygienic Conditions

The energy-efficient and hygienic GEA Hilge TP centrifugal pumps in the GEA SMARTPUMP line are available in a variety of model sizes, optimally configured for different applications.

The GEA Hilge TP is a centrifugal pump designed for the hygienic pumping of biologically demanding media. Low flow velocities and gentle discharge of media through the spiral housing enables extremely gentle product handling. Eleven different pump types are available covering a capacity range up to 1057 gpm and flow heads up to approx. 430 ft., fine tuned for each task.


The spiral housing for the GEA Hilge TP series is made of coldrolled steel. This material has an excellent surface quality, which is essential for optimum cleaning in CIP/SIP processes.

The GEA Hilge TP pump series is 3A and EHEDG certified. Typical wall thicknesses of 8 mm (TP 1020 6 mm) provide high strength.


TECHNICAL DATA

GEA Hilge TP	60 Hz
Flow	1057 gpm (240 m³/h)
Head	427 ft (130 m)
Media temperature	284°F (140°C)
Operating pressure	232 psi (16 bar)

GEA HILGE TP PERFORMANCE CURVE, 60 Hz 2-POLE, 3500 RPM




GEA HILGE TP PERFORMANCE CURVE, 60 Hz 4-POLE, 1750 RPM





FEATURES AND BENEFITS



- 1 Gapless sealing
- 2 Sterile mechanical seal

Applications

The GEA Hilge TP series has been designed for a variety of applications within:

Breweries

Dairies

Cosmetics

- Beer • Wort
- Milk • Cream
- Extracts

- Yeast
- Yogurt
- Emulsions Distillates

- Water
- · Whey
- · CIP Solutions
- Brine
- · CIP Solutions

Application options GEA Hilge TP

- Conveying
- · Filling lines
- Filtration

- Circulation
- Filling
- Evaporation
- Pressure boosting
 Emptying
- Cleaning

Technical benefits

- · Operating pressure max. 232 psi
- · Low NPSH value avoids early cavitation to the pump
- Energy-efficient operation, thanks to optimized speed control and/or impeller trimming

Constructive characteristics

- · Open impeller design optimized for gentle product handling
- · All parts stainless steel, wetted components made of AISI 316L
- Surface roughnesses of $R_a \le 31.5~\mu in$ (0.8 μm) can be achieved by mechanical treatment of the surface (higher surface qualities on request)
- · Premium efficient motors and washdown motors

Special characteristics

- · Gentle product handling
- · Low wear part stock requirement thanks to modular concept
- · Acceptance test certification 3.1 (optional)
- 3A and EHEDG certified
- · Sealings comply to FDA and USP Class VI

Mechanical seal optimized for hygienic applications

- · Mechanical seal unit can be removed from the front
- · Flushing unit easy to retrofit
- · Pump shaft protected by wear sleeve
- · Only two mechanical seal sizes for the entire pump series
- Seal face material options: carbon/silicon carbide (standard), silicon carbide/silicon carbide
- · Various elastomers with FDA approval (EPDM, FKM)

Sealing of GEA Hilge TP centrifugal pumps according to EHEDG standards

The elastomer sealing is executed according to EHEDG standards. The special groove enables the seal to be kept reliably in place at all times. The shape of the groove is based on FEM analyses. The metallic stop allows a defined compression of the seal, ensuring gap-free sealing against the product chamber without dead corners.







We live our values.

Excellence • Passion • Integrity • Responsibility • GEA-versity

GEA is a global technology company with multi-billion euro sales operations in more than 50 countries. Founded in 1881 the company is one of the largest providers of innovative equipment and process technology. GEA is listed in the STOXX® Europe 600 Index. In addition, the company is included in selected MSCI Global Sustainability Indexes.