



GEA Farm Technologies

# CapriTwin – the new goat cluster



GEA Milking & Cooling | WestfaliaSurge

**GEA** Farm Technologies – The right choice.

## Goat milking made easy using the new CapriTwin cluster

Specially developed for use in milking systems with overhead milking line, the new cluster is highly effective. Wether using the automatic control or the with simple hand removal, the CapriTwin cluster milks at turbo-speed.

The CapriTwin cluster is comprised of a small, handysized milk collecting piece, transparent teat cup sleeves and single-piece silicon teat cup liners with integral air inlet nozzles. The modified milk collecting piece electronicallyblocks the vacuum via the control unit dependent upon milk flow.

The one piece silicon teat cup liner within the transparent teat cup provides a good view. Smooth surfaces ensure hygienic cleanliness during and after milking.

Air inlet nozzle for high milk quality. The specific position of the air inlet nozzle ensures that the air and milk flow quickly and gently in the same direction to the milk collecting piece.





The core-element is the guide basin. Optimally designed and perfectly positioned it guides the milk smoothly along the wall into the large bottom vessel.



Milk collecting piece for automatic vacuum shut-off is simple to handle and in conjunction with the new control-unit family, enables quick milking.



The CapriTwin cluster from GEA Farm Technologies assures both clean and hygienic milking.

Milk collecting piece top part for manual vacuum shut-off. Simple switching of the lever from milking to removal position makes milking easier.

Additional weight for CapriTwin Adjustable weight distribution (4 weights each of 33 g) according to the requirements



and the goat breed.

Cluster holder ensures reliable cleaning of the teat cup.

#### Milk collecting piece

The powerful mini amongst the giants. Light, handy and very easy to use. That's just how GEA Farm Technologies milk collecting piece introduces itself with its unmistakeable design.

### **GEA Farm Technologies** The right choice.





#### GEA Farm Technologies GmbH

Siemensstraße 25 - 27, D-59199 Bönen Tel. +49 (0) 23 83 93 7-0, Fax +49 (0) 23 83 93 8-0 www.gea-farmtechnologies.com