



GEA G-Plex®


Vi control, condition monitoring, and more
for GEA Grasso screw compressors

Key features

- Use G-Plex, in combination with your existing control systems, to achieve enhanced efficiency and safe operation
- Enabler for GEA Cloud® and other cloud-based digital solutions
- Main interface via Wi-Fi connection using your own mobile device
- Dynamic service intervals
- Onboard I/O
- Prewired sensors and actuators

Key functions & benefits

- Increased efficiency with automated variable Vi / capacity control
- Reduce maintenance costs by managing the variable service intervals based on running and standstill conditions
- Increased awareness of system operation via condition monitoring, safety alerts, and historical data logging, based on available sensors
- Clearly visualized compressor performance data via operator's mobile device
- Full communication via commonly used Modbus TCP using a LAN Ethernet connection



GEA G-Plex®

Vi control, condition monitoring, and more for GEA Grasso screw compressors

GEA G-Plex® is a new, proprietary, user-friendly, electronic module that provides built-in, automatic, optimal volume ratio (Vi) control and on-site and off-site monitoring of the performance of the compressor. G-Plex helps to increase efficiency and reduce energy usage while providing real-time information about compressor operating conditions. Easy to integrate in an existing control system via hardwiring and/or use of Modbus TCP communication.



GEA G-Plex	
Degree of protection	IP 54, NEMA 12
Housing material	Powder-coated carbon steel
Dimensions (w x h x d)	210 / 305 / 65 mm (8.3 / 12 / 2.6 in.)
Weight	2,6 kg / 5.7 lb.
Power input	24 V DC, +/- 20%, including separate PE
Power consumption	7 Amps (max. 2.6 Amps - controller & sensors / max. 4.4 Amps - solenoid outputs)
Operating temperature	5 to 45°C / 41 to 113°F
Storage temperature	-20 to +70°C / -4 to +158°F
Humidity	Minimum 10 to 90% @ 25°C / 77°F
Certifications / approvals	CE, UL, FCC, CCC, (UKCA), RoHS
Ethernet connections	2x RJ45, 100 Mbit
Wi-Fi	2.4GHz IEEE 802.11b/g/n
Communication protocol for external devices	Modbus TCP/IP
Operating system	LINUX
Real-time clock	Yes
Sensors (standard solution)	Primary slide position (4-20mA) Secondary slide position, depending on compressor execution (4-20mA) Suction & discharge pressure (4-20mA)
Additional sensors (extended solution)	Oil pressure (4-20mA) Suction, discharge & oil temperature (PT1000-2L)
Actuators	Maximum six capacity solenoids with amplifier (24 V DC)
Digital inputs	Economizer active*1
Digital outputs	Shutdown status*2 Warning status (optional)*2 Compressor running status (optional)*2
Analog inputs	Capacity set point (0-10 V DC) Motor speed (4-20mA)*3
Analog outputs	Actual primary slide position (0-10 V DC)

*1: Required when economizer option is active

*2: Switching relays not included

*3: Required with frequency-controlled compressors

Products and services may not be available in all areas.
Please contact your local GEA office for additional information.

GEA Refrigeration Technologies GmbH

Holzhauser Str. 165
13509 Berlin, Germany
Tel +49 30 43592-600