

Sealing Set VARIVENT® Mixproof Valve Type B

Item	Qty	Designation	Material	2"	DN 65/80 2.5"/3"	DN 100 4"	DN 125	DN 150 6"
1	1	Sealing ring	Ø EPDM FKM HNBR	22 924-084 924-082 924-311	28 924-085 924-083 924-313	28 924-085 924-083 924-313	35 924-088 924-087 --	35 924-088 924-087 --
5	4	O-ring	Ø EPDM FKM HNBR	60x3 930-144 930-171 930-633	85x4 930-150 930-176 930-634	113x4 930-156 930-178 930-863	138x4 930-372 930-409 --	158x5 930-260 930-259 --
6	1	O-ring	Ø NBR	8x1.6 930-004	8x1.6 930-004	8x1.6 930-004	9x3 930-007	9x3 930-007
**7	1	V-ring	Ø EPDM FKM HNBR	52-6 932-021 932-033 932-088	76-6 932-024 932-035 932-090	104-6 932-028 932-039 932-100	128-6 932-060 932-062 --	148-6 932-042 932-041 --
**8	2	V-ring	Ø EPDM FKM HNBR	44-6 932-019 932-032 932-084	68-6 932-023 932-034 932-089	96-6 932-027 932-038 932-099	120-6 932-059 932-063 --	140-6 932-045 932-044 --
22	1	O-ring	Ø EPDM FKM HNBR	22x3 930-268 930-164 930-639	28x3 930-243 930-244 930-640	28x3 930-243 930-244 930-640	35x3 930-356 930-357 --	35x3 930-356 930-357 --
23	1	O-ring	Ø EPDM FKM HNBR	38x3 930-246 930-247 930-631	38x3 930-246 930-247 930-631	38x3 930-246 930-247 930-631	56x3 930-266 930-265 930-631	56x3 930-266 930-265 930-631
24	1	O-ring	Ø EPDM FKM HNBR	16x3 930-235 930-162 930-638	16x3 930-235 930-162 930-638	16x3 930-235 930-162 930-638	22x3 930-268 930-164 930-639	22x3 930-268 930-164 930-639
29	1	O-ring	Ø NBR	20x3 930-026	20x3 930-026	20x3 930-026	25x3 930-035	25x3 930-035
29.1	1	O-ring	Ø NBR	20x3 930-026	20x3 930-026	20x3 930-026	20x3 930-026	20x3 930-026
65	1	Sealing ring	Ø EPDM FKM HNBR	46 924-305 924-307 924-333	69 924-296 924-308 924-331	97 924-254 924-309 924-332	122 924-262 924-319 --	142 924-261 924-320 --
Sealing set cpl.			EPDM FKM HNBR	221-511.37 221-519.16 --	221-511.38 221-519.17 --	221-511.39 221-519.18 --	221-511.40 221-519.19 --	221-511.41 221-519.20 --

Grease RIVOLTA F.L.G. MD-2 100g tube not included in the sealing set

413-136

** Do not grease item 7 and 8

Storing instructions: storage in accordance with DIN 7716

Relative humidity approx. 65 %, temperature 15-25 °C and protected from light

When replacing seals, observe the instructions in the Operating Instructions!