



GEA Farm Technologies

IQLiner

... unique!



GEA Farm Services | [WestfaliaSurge](#)

GEA Farm Technologies – The right choice.

IQLiner - The unique fit

The liner is prevented from turning as it locks into the anti-twist device fitted in the teat cup. The clear fitting marks further simplify the fitting process. The result: Secure and problem-free assembly



The narrowing directly beneath the teat cup and the specially precasted milk hose ensure maximum cluster flexibility. The result: Optimum fitting that ensures trouble-free milking



The nozzleless connection to the claw and the omission of the sight glass double the flexible area. The result: Maximum flexibility and adaptability to the different udder shapes

The bulge at the end of the short milk hose ensures that the teat cups drop away evenly during the removal process and this guarantees that the cluster is always ready for further use. The result: Optimum adhesion for maximum throughput



For the milkers of today and tomorrow: The new liner from GEA Farm Technologies is called IQLiner and is unique in that it is fitted individually onto the IQ cluster! Take advantage of the optimum adhesion and flexibility on the udder! The well thought-out benefits of our IQLiner ensure animal-friendly milking together with the best possible teat conditions and the wellproven rubber material works as reliably as ever.

Teat-size dependent head shapes (round, straight and large) are available in order to ensure that the cluster fits optimally on the udder.



Your benefits at a glance:

- Different head shapes available to match all teat sizes
- Optimum adhesion that ensures problem-free milking with high throughput
- A fast, teat-friendly complete milking process
- The top quality, flexible rubber material ensures a long service life (750 hours) and the best possible hygiene
- Fast, low-effort and tool-free assembly
- An explicit product description is engraved on the head



GEA Farm Technologies GmbH

Siemensstraße 25 - 27, D-59199 Bönen
Tel. +49 (0) 23 83 93 7-0, Fax +49 (0) 23 83 93 8-0
www.gea-farmtechnologies.com